


JVC

SERVICE MANUAL

CD PORTABLE COMPONENT SYSTEM

PC-X103BK E/EN



**COMPACT
dISC
DIGITAL AUDIO**

Area Suffix

E	Continental Europe
EN	Northern Europe

■ Self-diagnosis function

This model has a convenient self-diagnosis function for CD section.

Contents

■ Safety Precautions	2	6. Block Diagram	50
■ Instructions	5	7. Standard Schematic Diagrams	58
1. Location of Main Parts	25	8. Location of P.C. Board Parts and Parts List	62
2. Removal of Main Parts	30	9. Exploded View of Enclosure Assembly	72
3. Main Adjustment	38	10. Exploded View of Mechanism Assembly	76
4. Wiring Connection	42	11. Packing Illustration and Parts List	80
5. Troubleshooting	43		


Safety Precautions

1. The design this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Service should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the product have special safety — related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the parts list of service manual. Electrical components having such features are identified by shading(▨) and (△) on the schematic diagram and parts list in the service manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement part shown in the parts list of service manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps , tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after reassembling.
5. Leakage current check (Electrical shock hazard testing)

After re — assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock. Do not use a line isolation transformer during this check.

- Plug the AC line cord directly into the AC outlet. using a "Leakage current tester", measure the leakage current from each exposed metal part of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC(r.m.s.)
- Alternate check method

Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500 ohms 10W resistor paralleled by a 0.15 μ F AC type capacitor between an exposed metal part and a known good earth ground. Measure the AC voltage across the resistor with the AC voltmeter. Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75V AC(r.m.s.). This corresponds to 0.5mA AC(r.m.s.).






Warning (UK ONLY)

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

IMPORTANT FOR LASER PRODUCTS**PRECAUTIONS**

1. CLASS 1 LASER PRODUCT
2. **DANGER:** Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. **CAUTION:** Do not open the rear cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
4. **CAUTION:** The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent the emission of radiation when the CD tray is open. It is dangerous to defeat the safety switches.
5. **CAUTION:** Use of controls for adjustments and the performance of procedures other than those specified herein may result in exposure to hazardous radiation.

Name/Rating plate

**REPRODUCTION OF LABELS AND THEIR LOCATION**

DANGER: Invisible laser radiation when open and interlock failed or defeated
AVOID DIRECT EXPOSURE TO BEAM. (e)

ADVARSEL: Usynlig laserstråling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå utsættelse for stråling. (d)

VARNING: Osynlig laserstråling när denna del är öppnad och spärren är urkopplad. Beträcka ej strålen. (s)

VARO: Avataessa ja suojaikatos avatettaessa ole alttiina näkymätöntä lasersäteilytä. Älä katso säteileen. (l)



ADVERSEL: Usynlig laserstråling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå utsættelse for stråling.

VAROITUS: Varmuuskytkimen ollessa pois päältä kuna itse avataan, siellä kehittyy näkymätöbtä lasersäteilä. Älä pane itseäsi sääteilyn altiiksi.

VARNING: Osynlig laserstråning uppstår vid komponentens öppning när säkerhetsbrytaren är frånslagen.

ADVARSEL: Usynlig laserstråling ved åpning når sikkerhetsbryteren er ude af funktion. Unngå utsettelse for stråling.

WARNING:
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,
DO NOT EXPOSE THIS APPLIANCE TO RAIN OR
MOISTURE.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.




The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

■ Important control point concerning safety

1. Check the power transformer marking, and check that the power transformer is securely installed.

Parts number : VTP57J2-12B




2. Check the power cord marking, and check that the power cord is not externally damaged.

Cord mark: < VDE >

Attachment plug: KS-419C or SE-1

Connect plug: KS-15F or SE-4



3. Check the AC socket marking, and check that the AC socket is tightly fixed in the P.C.board when installed.


HSC1466

4. Check that there is sufficient space for the primary and adjacent secondary terminal parts on the P.C.board (There should be no protrusions of solder or terminal wires.)

5. Check the rated fuse display, and check that the fuse is secure in the fuse holder. F992: T2.5A/250V


F993: T2.5A/250V

6. Check that the wires are neatly arranged so that they do not interfere with sections involving power, moving parts, heat generation, or those with sharp-edged parts.






7. The following parts are important for safety in such operations as those involved with heat generation. Use the specified parts and check original shape. Heat generating parts should be suspended above the P.C.board not fallen down. Parts marked with [] are safety control parts.

IC502, IC304, [Q581], [Q915], Q931, Q901, R929.



8. Confirm the following parts specified

in the UL and CSA.: C361 (vending type)



■ Instructions


JVC

CD PORTABLE COMPONENT SYSTEM
SISTEMA PORTATIL DE COMPONENTES DE CD
SISTEMA DI COMPONENTI PORTATILE A CD


PC-X106/X103 E

PC-X106/X103E

CD PORTABLE COMPONENT SYSTEM



PC-X103



PC-X106

INSTRUCTIONS

MANUAL DE INSTRUCCIONES
MANUALE DIISTRUZIONI


IMPORTANT FOR LASER PRODUCTS

PRECAUTIONS

1. CLASSE 1 LASER PRODUCT
2. DANGER: invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. CAUTION: Do not open the rear cover. There are no user serviceable parts inside this unit. Have all servicing (if qualified) done by a qualified service personnel.
4. CAUTION: compact disc player uses invisible laser radiation and is equipped with safety switches which prevent the emission of radiation when the CD tray is open. It is dangerous to defeat the safety switches.
5. CAUTION: Use of controls or adjustments and the performance of procedures other than those specified herein may result in exposure to hazardous radiation.

REPRODUCTION OF LABELS AND THEIR LOCATION

ROTULOS Y SU UBICACION




IMPORTANT PARA PRODUCTOS LASER

PRECAUCIONES

1. PRODUTO LASER CLASSE 1
2. PERICOLO: Quando l'apparecchio è aperto ed i dispositivi di sicurezza non funzionano o sono stati disattivati, vengono prodotte invisibili radiazioni laser. Evitare l'esposizione diretta allo stesso.
3. ATTENZIONE: Non aprire il coperchio posteriore. All'interno dell'apparecchio possono trovarsi pezzi che possono essere pericolosi per la salute. Per questo motivo, l'apparecchio deve essere sempre tenuto sotto controllo da un personale di assistenza qualificato.
4. ATTENZIONE: Il lettore CD utilizza invisibili radiazioni laser ed è fornito di intertori di sicurezza che impediscono l'emissione di radiazioni quando il cassetto del CD è aperto. È pericoloso disattivare questi intertori.
5. ATTENZIONE: L'uso di comandi, per la regolazione e di procedure diverse da quanto specificato possono causare esplosioni o reazioni esplosive.

ETICHETTE E LORO POSIZIONE



CARATTERISTICHE

PRECAUCIONES

CARACTERISTICAS

CONTENTS

Thank you for purchasing this JVC product. Please read these instructions carefully before starting operation to be sure to obtain optimum performance and a longer service life from the unit.

INDICE

INDICE

Features	3
Safety precautions	4
Handling precautions	5
Attaching/detaching the speakers	6
Connections	7
Power supply	8
Names of parts and their functions	10
Remote control unit	13
Switching the power on/off	15
Volume, tone and other controls	17
Concerning compact discs	18
Playing compact discs	19
Cassette tape	23
Cassette playback	24
Reproduction of cassettes	24
Reproduction alternativa (PC-X106 exclusive)	25
Recording	26
Dubbing (syncro start dubbing) (PC-X106 only)	26
Grabación (con comienzo sincronizado) (PC-X106 exclusive)	32
Wake up timer operations	33
Sleep timer operations	35
Maintenance	36
Troubleshooting	37
Specifications	38
Deteczione di problemi	39
Defi tecnic	39
AVVERTENZA: NON ESPORRE L'APPARECCHIO A RISCHI DI INCENDI O INCENDI O SCOSSE ELETTRICHE.	
ADVERTENCIA: PARA EVITAR RIESGOS DE INCENDIOS O ELECTRICOS, NO EXPOGA ESTE APARATO A LA LLUVIA O A LA HUMEDAD.	
WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.	
Especificaciones	

SPECIFICATIONS


SPECIFICACIONES

Quando questa unità è collegata ad una presa di rete c.a., essa consuma una piccola quantità di corrente per il funzionamento del telecomando e del timer o per il mantenimento della memoria del microprocessore, anche quando il tasto POWER è regolato su STANDBY.

Cuando esta unidad esté conectada a un tomacorriente de CA, consume una pequeña cantidad de corriente para operar el control remoto y el temporizador, y para la memoria de apoyo del microprocesador. Una vez que el botón POWER esté colocado en STANDBY,

When this unit is plugged into an AC outlet, it consumes a small current to operate the remote control and timer, or to back up the memory of the microprocessor, even when the POWER button is set to STANDBY.

**PRECAUZIONI PER
L'USO**



Non utilizzare questa unità nella luce solare diretta e non lasciarla in automobile chiuse (o yacht, ecc.) dove può essere esposta a temperature elevate sopra i 40°C.

PRECAUCIONES DE MANIPULACION



No utilice esta unidad a la luz directa del sol ni la deje en un automóvil cerrado (ya sea, etc.) donde podría estar expuesta a temperaturas superiores a 40°C.

HANDLING PRECAUTIONS

Do not use this unit in direct sunlight
leave the unit in closed automobile
yachts, etc.) where it would be exposed
high temperatures above 40°C.

PRECAUZIONI PER LA
SICUREZZA

PRECAUCIONES DE SEGURIDAD

Prevención contra electrochoques, riesgos de incendios y daños

1. Aunque el botón POWER esté ajustado en STANDBY, circula una pequeña cantidad de corriente. Para ahorrar energía y por

- desconecte el cable de alimentación del tomacorriente cuando no lo utilice la unidad por mucho tiempo.

1. Noto que el cable de alimentación con las extremidades de la clavija C y el cable de tierra están desenchufados de la clavija Y del tomacorriente.

2. Consulte a su vendedor más cercano cuando describa una falla desconocida de contacto en el cable.

3. No doble, tire o enrolle demasiado el cable.

4. No efectúe ninguna modificación en el cable.

5. No saque los tornillos para desamarrar la funda de aislante que cubre dentro de la misma la parte metálica del conductor.

6. No intente cortar el cable con un objeto metálico dentro de la unidad.

7. Siempre conecte el cable lo antes posible si hay posibilidad de tormentas eléctricas.

8. Si entra agua dentro de la unidad, desenchufe el cable del tomacorriente y comuníquese a su vendedor.

9. No bloquee los orificios de ventilación de la unidad para que el aire pueda salir.

10. Utilice la unidad en un lugar bien ventilado.

12. Como el PC-1062A-013 utiliza un portátil CD accionado por motor, asegúrese de no colocar el CD o con un objeto el movimiento del mismo.

SAFETY PRECAUTIONS

Prevention of Electric Shock, Fire Hazards	Prevention contra electroshock, riesgos de incendio
1. Ensure that the POWER button is set to STANDBY when a small current is required to save power and/or safety when not using the unit for an extended period of time.	1. Ponerse en modo de reposo para ahorrar energía y/o seguridad cuando no se usa la unidad por mucho tiempo.
2. Do not handle the power cord with wet hands.	2. No tocar el cable de alimentación con las manos húmedas.
3. When unplugging from the wall outlet, always grasp and pull from the plug, not the power cord.	3. Al desenchufar el cable del tomacorriente, sujetar y tirar del enchufe, no del cable.
4. Consult your nearest dealer when damage, disconnection, or contact failure is found in the power cord.	4. Consultar a su vendedor más cercano cuando descubra una falla en el cable de alimentación.
5. Do not bend the cord sharply, or pull it tight.	5. No doblar el cable o estirarlo demasiado el
6. Do not handle the power cord with wet hands.	6. No manipular el cable de alimentación con las manos húmedas.
7. Do not modify the power cord in any manner.	7. No modificar el cable de alimentación de ninguna manera.
8. Do not remove screws to disassemble the unit and do not touch anything inside the unit to avoid static.	8. No sacar los tornillos para desarmar la unidad ni tocar nada dentro de la misma para evitar accidentes.
9. Do not insert any metallic objects into the unit.	9. Desenchufar el cable lo antes posible si hay posibilidad de tormentas eléctricas.
10. Unplug the power cord when there is a possibility of lightning.	10. Si llueve agua dentro de la unidad, desenchufar el cable del tomacorriente y comunicarse con su vendedor.
11. Do not leave the power cord from the outlet unit.	11. Desenchufar los cables de ventilación de la unidad si el usuario piensa salir. No instalar la unidad en un lugar mal ventilado.
12. Since the PC-X106X/103 uses a motor-driven CD player, make sure your hand or other object does not obstruct tray movement.	12. Consulte el PC-X106X/103 usando un portacasettes de CD accionado por motor, asegúrese de que su mano o otro objeto no obstruya el movimiento de la bandeja.
13. Power button	13. Cuando se conecta el cable de alimentación, el botón de encendido se ilumina de color rojo indicando que la unidad ya está lista para usar.

Iniezione di alimentazione. Chiudendo il caro di alimentazione e collegato ad una presa di rete c.a. l'indicatore di accensione si illumina al rosso per indicare il modo di **SUPERB**. Questo indicatore non si illumina quando viene tornata all'indicazione normale. Inoltre l'attivazione viene riconosciuta dall'indicatore che inverte per indicare l'attivazione dell'alimentazione per la alimentazione in c.c. che in c.c. si illumina sia per

- STANDBY (este indicador no se enciende cuando se suministra corriente continua); cuando se conecta la alimentación el indicador se pone en verde indicando que la alimentación está conectada. (este indicador se enciende con ambas configuraciones, la alternaria y la continua).

When the indicator turns green, it indicates that power is supplied to the indicator. When the power is switched off, the indicator turns green showing that the power is on (this indicator lights with both AC and DC power supplies).

Quando il caro di alimentazione è collegato all'indicatore rosso

Quando il caro di alimentazione è collegato all'indicatore rosso, si consiglia di seguire le indicazioni riportate nel **Capitolo 10**.

Quando il caro di alimentazione è collegato all'indicatore verde

Quando il caro di alimentazione è collegato all'indicatore verde, si consiglia di seguire le indicazioni riportate nel **Capitolo 11**.

Dato che i diffusori incorporano del manganino, non possono nascritti o schede magnete, ma si può essere in quanto i materiali magnetici potrebbero venire cancellati. Tenere l'unità lontana da televisori. Questa unità viene installata in prossimità di un televisore, l'immissione telefonica elettrica viene disposta. Se ciò dovesse accadere, allontanare l'unità dal televisore. Si può non fornire sufficiente ad eliminare la interferenza, effetto di utilizzando una linea diversa. Il televisore deve essere installato in un luogo dove non ci sono altri televisori.

- 6. Pulida dell'esterno dell'unità**
Se estrovi dell'unità rosso sporco, strofinate con un panno umido di acqua e detergente. Non mai danneggiare la finitura dell'unità.

7. Limpieza de la caja
Si ensucia la caja, limpiala con un paño seco y una toalla blanca en el ducha. Si esto no sirve, acaba de acabo de sacarla y la limpias con un paño.

8. Cuando escuches con auriculares
No escuches con el volumen muy alto porque podrían dañarte las oídos.

9. Ajusto con lo cuffia
Abassate il volume in modo da non danneggiare le orecchie.

10. Mantén la manija
Para motivi di sicurezza, non guidare mentre si lascia con le cuffie.

11. Manico per il trasporto
Non sollevare o abbassare il manico con la mano telescopica estendida para evitar que se dane. Colocada de tal modo que no interfiera con la operación.


6. Cleaning the cabinet
If the cabinet gets dirty, wipe it with a soft, dry cloth. Never use a rough cloth as this could damage the surface finish.
B. When listening with headphones
Do not listen at high volumes as it could damage your hearing.

C. For safety, do not drive while listening to this unit.


D. Carrying handle
Do not raise or lower the carrying handle with the telescopic antenna extended, to avoid damaging the antenna. Place the carrying handle so that it does not interfere with operation.

ATTACHING/DETACHING
THE SPEAKERS

When using the speakers attached to the main unit Align the bottom of the speaker against the top of the main unit and press down on the speaker to attach it.



When using the speakers detached from the main unit
While pressing the lock lever at the rear bottom of speaker in the direction of the arrow, lift the speaker up to detach from the main unit.



- 8. Pulizie dell'esterno dell'unità**
Se è esterno dell'unità rosso sporco, strofinate con un panno umido di acetato diluita. Non usate liquidi abrasivi.

9. Acciuffo con cerniere.
No assicura che il volume può andare dal basso sulle orecchie.


10. Manica di trasporto.
Non levante la maniglia con la antenna telescopica esistente per evitare che se cala. Colloca di lato modo che non interfiere con la operazione.

11. Abassare il volume in modo da non danneggiare le orecchie.
Per motivi di sicurezza, non guidare mentre si ascolta con le cuffie.

12. Manico per il trasporto.
Non sollevare o abbassare il manico con la manica telescopica esistente onde impedire di danneggiare la stessa. Posizionare il manico in modo che non interferisca con il manico stesso.

**EDUCACION/RETIRO DE LO
MAIS VOZES**

When using the speakers attached to the main unit Align the bottom of the speaker against the top of the main unit and press down on the speaker to attach it.









- Abbracci e baci**
Abbassare il volto
danneggiare le orecchie,
Per motivi di sicurezza, non guidare
mentre si lascia con le cuffie.
Alcuni consigli
Per il trasporto
non sollevare o abbassare il manico co-
me una telescopica esistente onde non
rimaneggiare l'antenna stessa. Posizionare
il manico in modo che non interferis-
ca con le cuffie.

LICAZIONE/RIMOZIONE DEI
VUSORBI


ndo si utilizza l'unità principale con
ori applicati



- | CONEXIONES | COLLEGAMENTI | NOTA: |
|---|--|---|
| <p>Nota: Since the speakers sound differently according to where they are placed, carefully place them for optimal effect within the length of the provided speaker cords. It is recommended that the left and right speakers be placed symmetrically in relation to the main unit.</p> | <p>Nota: Como los altavoces suenan diferente de acuerdo a donde sean colocados, libere los con precaución para obtener un efecto óptimo dentro de la longitud de los cables suministrados. Se recomienda colocar los altavoces izquierdo y derecho simétricamente en relación a la unidad principal.</p> | <p>Dato: Note que los difusori suonano in modo diverso a seconda della loro posizione, posizionarli con attenzione per ottenere un effetto ottimale entro il campo permesso dalla lunghezza dei cavi forniti. Si raccomanda di posizionare i diffusori sinistro e destro simmetricamente rispetto all'unità principale.</p> |
| | | <p>Nota: Non attivare l'alimentazione prima del conn-</p> |
| | | <p>• No conecte la alimentación hasta haber</p> |

CONNECTIONS	CONEXIONES	COLLEGAMENTI
<ul style="list-style-type: none"> Do not switch the power on until all connections are completed. 	<ul style="list-style-type: none"> No conecte la alimentación hasta haber completado todas las conexiones. 	<ul style="list-style-type: none"> Non attivare l'alimentazione prima del completamento dei collegamenti.
 <ul style="list-style-type: none"> When connecting the speaker cords, connect the one marked with a line to the (\ominus) terminal first. Cuando conecte los cordones de los altavoces, conecte primero el cordón marcado con una linea al terminal (\ominus). Quando si collegano i cavi di diffusori, collegare per primo il cavo contrassegnato da una linea al terminale (\ominus). 	 <ul style="list-style-type: none"> Marked with line Marcado con una linea Marcato con una linea 	 <ul style="list-style-type: none"> After connecting the speaker cords, bundle any slack and attach the speaker cords to the back panel. Doblar el exceso de los cordones de los altavoces y amarrarlos al soporte dentro del espacio para los cordones de los altavoces, ubicado en el panel trasero. Dopo aver collegato i cavi dei diffusori, mettere le parti libere dei cavi nello spazio aperto sul pannello posteriore. 

NAMES OF PARTS AND THEIR FUNCTIONS	NOMBRE DE LAS PARTES Y SUS FUNCIONES
CD player/General section	
Sección de reproductor de CD/general	<p>① POWER button ② POWER indicators GREEN: POWER ON RED: STANDBY (señal) ③ REMOTE SENSOR section ④ ACTIVE HYPER-BASS PRO Indicator ⑤ Display window ⑥ WAKE UP indicator ⑦ SLEEP Indicator ⑧ PAYBACK indicator ⑨ PHONO input ⑩ RDS indicator ⑪ RAND/ONE playback indicator ⑫ Function play/track number display ⑬ Wake up/standby time display ⑭ Headphone jack (1/8") ⑮ Connect headphones (with impedance 16Ω-1KΩ) to this jack. The speakers are automatically switched on when the headphones are connected. ⑯ WAKE UP button ⑰ ACTIVE HYPERBASS PRO button ON: The Active Hyper-Bass Pro indicator will light. Set to this position to listen to the Active Hyper-Bass Pro sound. OFF: The Active Hyper-Bass Pro indicator goes out. Set to this position when Active Hyper-Bass Pro sound is not required. ⑱ VOLUME button A: Use to increase the volume. B: Use to decrease the volume. (control range from VOL 0 to VOL 25). ⑲ SOUND button ⑳ CD tray ⑳ CD open/close button (▲) ⑳ CD operating buttons ⑳ Search button (◀, ▶) ⑳ Play/pause button (▷, ■)</p>
Sección lettore CD/generale	<p>① Tasto di alimentazione (POWER) VERDE: POWER ON (acceso) ROSSO: STANDBY (in attesa di corrente) ② Sezione REMOTE SENSOR ③ Indicatore ACTIVE HYPER-BASS PRO Vantaggio della indicazione WAKE UP ④ Indicatore della riproduzione (▶) ⑤ Indicatore della pausa (■) ⑥ Indicatore del programma (PROGRAM) ⑦ Indicatore del programma (PROGRAM) ⑧ Indicatore di lettura casella (ALL) ⑨ Indicatore di lettura ribelle (ALL) ⑩ Display di funzionamento brano ⑪ Display di tempo di lettura automatico Press per la cuffia (1) Immagine stereo di 3,5 mm di diametro. Conecta una cuffia con una impedenza di 16-1-KΩ a este jack. Los altavoces se conectan automáticamente a los altavoces. Botón WAKE UP/TIMER Tasto SLEEP TIMER Tasto ACTIVE HYPER-BASS PRO ON: L'indicatore Active Hyper-Bass Pro si illumina. Riproduce su questa posizione per accendere il suono Active Hyper-Bass Pro. OFF: Se apaga el indicador Active Hyper-Bass Pro. Colocarlo en esta posición para apagar el sonido Active Hyper-Bass Pro. No tiene función si el botón es VOL 0 (MUTE). + Utilizado para aumentar el volumen. - Utilizado para reducir el volumen. (los límites de ajuste van de VOL 0 a VOL 25). Botón SOUND Portátil de CD ② Tasto di apertura/chiusura del cassetto del CD (□) ③ Tasto di funzione del lettore CD ④ Tasto di incarico (◀, ▶) ⑤ Tasto di arresto/cancillazione (□) ⑥ Tasto di ferma/pausa (▷, ■)</p>
Sezione lettore CD/generale	<p>① Tasto di alimentazione (POWER) VERDE: POWER ON (acceso) ROSSO: STANDBY (in attesa di corrente) ② Sezione REMOTE SENSOR ③ Indicatore ACTIVE HYPER-BASS PRO Vantaggio della indicazione WAKE UP ④ Indicatore della riproduzione (▶) ⑤ Indicatore della pausa (■) ⑥ Indicatore del programma (PROGRAM) ⑦ Indicatore del programma (PROGRAM) ⑧ Indicatore di lettura casella (ALL) ⑨ Indicatore di lettura ribelle (ALL) ⑩ Display di funzionamento brano ⑪ Display di tempo di lettura automatico Press per la cuffia (1) Immagine stereo di 3,5 mm di diametro. Conecta una cuffia con una impedenza di 16-1-KΩ a este jack. Los altavoces se conectan automáticamente a los altavoces. Botón WAKE UP/TIMER Tasto ACTIVE HYPER-BASS PRO ON: El indicador Active Hyper-Bass Pro se enciende. Colóquelo en esta posición para escuchar el sonido Active Hyper-Bass Pro. OFF: Se apaga el indicador Active Hyper-Bass Pro. Colóquelo en esta posición para apagar el sonido Active Hyper-Bass Pro. No tiene función si el botón es VOL 0 (MUTE). + Utilizado para aumentar el volumen. - Utilizado para reducir el volumen. (los límites de ajuste van de VOL 0 a VOL 25). Botón SOUND Portátil de CD ② Tasto di apertura/chiusura del portadisco del CD (□) ③ Tasto di funzione del lettore CD ④ Tasto di incarico (◀, ▶) ⑤ Tasto di arresto/cancillazione (□) ⑥ Tasto di ferma/pausa (▷, ■)</p>
Sección de la platina/sintonizador	<p>① POWER button ② POWER indicators GREEN: POWER ON RED: STANDBY (señal) ③ REMOTE SENSOR section ④ ACTIVE HYPER-BASS PRO Indicator ⑤ Display window ⑥ WAKE UP indicator ⑦ SLEEP Indicator ⑧ PAYBACK indicator ⑨ PHONO input ⑩ RDS indicator ⑪ RAND/ONE playback indicator ⑫ Function play/track number display ⑬ Wake up/standby time display ⑭ Headphone jack (1/8") ⑮ Connect headphones (with impedance 16Ω-1KΩ) to this jack. The speakers are automatically switched on when the headphones are connected. ⑯ WAKE UP button ⑰ ACTIVE HYPERBASS PRO button ON: The Active Hyper-Bass Pro indicator will light. Set to this position to listen to the Active Hyper-Bass Pro sound. OFF: The Active Hyper-Bass Pro indicator goes out. Set to this position when Active Hyper-Bass Pro sound is not required. ⑱ VOLUME button A: Use to increase the volume. B: Use to decrease the volume. (control range from VOL 0 to VOL 25). ⑲ SOUND button ⑳ CD tray ⑳ CD open/close button (▲) ⑳ CD operating buttons ⑳ Search button (◀, ▶) ⑳ Play/pause button (▷, ■)</p>
Sezione registratori/sintonizzatori	<p>① Tasto di alimentazione (POWER) VERDE: POWER ON (acceso) ROSSO: STANDBY (in attesa di corrente) ② Sezione REMOTE SENSOR ③ Indicatore ACTIVE HYPER-BASS PRO Vantaggio della indicazione WAKE UP ④ Indicatore della riproduzione (▶) ⑤ Indicatore della pausa (■) ⑥ Indicatore del programma (PROGRAM) ⑦ Indicatore del programma (PROGRAM) ⑧ Indicatore di lettura casella (ALL) ⑨ Indicatore di lettura ribelle (ALL) ⑩ Display di funzionamento brano ⑪ Display di tempo di lettura automatico Press per la cuffia (1) Immagine stereo di 3,5 mm di diametro. Conecta una cuffia con una impedenza di 16-1-KΩ a este jack. Los altavoces se conectan automáticamente a los altavoces. Botón WAKE UP/TIMER Tasto ACTIVE HYPER-BASS PRO ON: El indicador Active Hyper-Bass Pro se enciende. Colóquelo en esta posición para escuchar el sonido Active Hyper-Bass Pro. OFF: Se apaga el indicador Active Hyper-Bass Pro. Colóquelo en esta posición para apagar el sonido Active Hyper-Bass Pro. No tiene función si el botón es VOL 0 (MUTE). + Utilizado para aumentar el volumen. - Utilizado para reducir el volumen. (los límites de ajuste van de VOL 0 a VOL 25). Botón SOUND Portátil de CD ② Tasto di apertura/chiusura del portadisco del CD (□) ③ Tasto di funzione del lettore CD ④ Tasto di incarico (◀, ▶) ⑤ Tasto di arresto/cancillazione (□) ⑥ Tasto di ferma/pausa (▷, ■)</p>



REMOTE CONTROL UNIT	UNIDAD DE CONTROL REMOTO	UNITÀ DI TELECOMANDO
<p>● BAND button Presione para activar el modo TUNER.</p> <p>● Press to select TUNER mode. ● PRESET TUNING button (FM/AM).</p> <p>● TUNING buttons (UP/DOWN) ● Agregar indicador display</p> <p>● Pantalla de visualización de la radio (FM/AM)</p> <p>● Indicador (FM/AM)</p> <p>● Radio frequency display</p> <p>● Preset station display</p> <p>● STEREO Indicator</p> <p>● MONO indicator</p> <p>● BEAT CUT button (See page 32.)</p>	<p>● Tasto BAND Premendo per selezionare il modo TUNER. Premendo anche per selezionare una banda di frequenza FM/AM).</p> <p>● Tasto di sintonia preselezionata (PRESET TUNING)</p> <p>● Tasto di sintonización de preajustes (PRESET TUNING)</p> <p>● Botón de sintonización de preajustes automático (AUTO PRESET)</p> <p>● Botones de sintonización (TUNING) (PRESET TUNING)</p> <p>● Pantalla de visualización de la radio (FM/AM)</p> <p>● Indicador de modo de cinta (REC)</p> <p>● Indicador REC</p> <p>● Indicador de banda (FM/AM)</p> <p>● Indicación de frecuencia de radio</p> <p>● Display della stazione preselezionata</p> <p>● Indicador STEREO</p> <p>● Indicador MONO</p> <p>● Tasto di soppressione del battimento (BEAT CUT) (Vedere pag. 32.)</p>	<p>● Tasto BAND Premiendo para seleccionar el modo TUNER. Presionando también para seleccionar una banda de frecuencia FM/AM).</p> <p>● Tasto de sintonía preselección (PRESET TUNING)</p> <p>● Tasto de sintonización de preajustes (PRESET TUNING)</p> <p>● Botón de sintonización de preajustes automático (AUTO PRESET)</p> <p>● Botones de sintonización (TUNING) (PRESET TUNING)</p> <p>● Pantalla de visualización de la radio (FM/AM)</p> <p>● Indicador REC</p> <p>● Indicador de modo de cinta (REC)</p> <p>● Indicador de banda (FM/AM)</p> <p>● Indicación de frecuencia de radio</p> <p>● Display della stazione preselezionata</p> <p>● Indicador STEREO</p> <p>● Indicador MONO</p> <p>● Tasto di soppressione del battimento (BEAT CUT) (Vedere pag. 32.)</p>
<p>● PRESET button</p>	<p>● Tasto PRESET</p>	<p>● Tasto PRESET</p>
<p>● TUNING window</p> <p>● TUNING window</p>	<p>● TUNING window</p> <p>● TUNING window</p>	<p>● TUNING window</p> <p>● TUNING window</p>
<p>● Radio indicator</p> <p>● Radio indicator</p>	<p>● Indicador (FM/AM)</p> <p>● Indicador (FM/AM)</p>	<p>● Indicador (FM/AM)</p> <p>● Indicador (FM/AM)</p>
<p>● Radio frequency display</p>	<p>● Radio frequency display</p>	<p>● Radio frequency display</p>
<p>● Preset station display</p>	<p>● Preset station display</p>	<p>● Preset station display</p>
<p>● STEREO Indicator</p>	<p>● STEREO Indicator</p>	<p>● STEREO Indicator</p>
<p>● MONO indicator</p>	<p>● MONO indicator</p>	<p>● MONO indicator</p>
<p>● BEAT CUT button (See page 32.)</p>	<p>● BEAT CUT button (See page 32.)</p>	<p>● BEAT CUT button (See page 32.)</p>
<p>● Panel posteriore</p>	<p>● Panel trasero</p>	<p>● Pannello posteriore</p>
<p>● Rear panel</p>	<p>● Panel trasero</p>	<p>● Pannello posteriore</p>
<p>● Antenna telescopica</p>	<p>● Antena telescópica</p>	<p>● Antenna telescopica</p>
<p>● DC IN 12 V CC</p>	<p>● Presa DC 12 V CC</p>	<p>● Presa DC 12 V CC</p>
<p>● AC IN</p>	<p>● Presa AC</p>	<p>● Presa AC</p>
<p>● Batteria component cover</p>	<p>● Coperchio del vano batterie</p>	<p>● Coperchio del vano batterie</p>
<p>● SPEAKER terminals</p>	<p>● Terminali SPEAKER</p>	<p>● Terminali SPEAKER</p>
<p>● Connect the provided speakers to these terminals.</p>	<p>● Collegare i diffusori forniti a questi terminali.</p>	<p>● Collegare i diffusori forniti a questi terminali.</p>

VOLUME, TONE AND OTHER CONTROLS		VOLUMEN, TONO Y OTROS CONTROLES	VOLUME, TONO ED ALTRI COMANDI
Función COMPU PLAY (solo cuando viene utilizada la alimentación a.b.)			
Aun cuando la alimentación esté en STANDBY el presionar el botón mostrado abajo, conecta la alimentación y selecciona la fuente.			
Operador COMPU PLAY (solo cuando viene utilizada la alimentación a.b.)			
Even when the power is set to STANDBY pressing the button shown below switches on the power and selects the source.			
(PC-X106)		CD	
Function mode Modo de función	Operations Operaciones	Operations Operazioni	Operations Operazioni
When this button is pressed with a CD loaded, CD playback begins. Cuando se presiona este botón teniendo un CD colocado, comienza la reproducción del mismo. Se questo tasto viene premuto con un CD caricato, la lettura del CD ha inizio.	When this button is pressed with a tape loaded, tape playback begins. Cuando se presiona este botón teniendo una cinta colocada, comienza la reproducción de la misma. Se questo tasto viene premuto con un nastro caricato, la riproduzione del nastro ha inizio.	When this button is pressed with a Deck A or Deck B, Plataforma A o Plataforma B. Cuando se presiona este botón, se activa el sintonizador. Se questo tasto viene premuto, il sintonizzatore si accende.	When this button is pressed, the tuner is engaged. Cuando se presiona este botón, se activa el sintonizador. Se questo tasto viene premuto, il sintonizzatore si accende.
(PC-X108)		TAPE	
(PC-X106)		TUNER	
Notas:			
1. When switching off the power, be sure to leave the unit on even when the POWER button is pressed. 2. The COMPUI PLAY button has the same function as the PC-X106/X103. 3. When carrying this unit to avoid accidentally pressing the POWER button.	When the CD tray open/close (▲) button is pressed, the source sound does not switch over, the CD tray can open or close.	1. Cuando se activa el temporizador despiertador, la alimentación de esta unidad no se apaga al presionar el botón PLAY► de la plástica. Nota: 1. Cuando se desconecta la alimentación, asegúrese de presionar el botón POWER. (Cuando se desconecta el POWER con el portacd de CD abierto, éste se cierra y a continuación se desconecta la energía). 2. El botón COMPUI PLAY del controlador frontal tiene la misma función como el PC-X106/X103. 3. Coloque el panel frontal alejado de usted cuando transporte la unidad, para evitar presionar accidentalmente el botón POWER.	When wake up timer is engaged, the power of this unit is not switched off even when the POWER button is pressed. 2. The COMPUI PLAY button on the remote control has the same function as the PC-X106/X103. 3. When carrying this unit to avoid accidentally pressing the POWER button.
Notas:			
1. When switching off the power, be sure to leave the unit on even when the POWER button is pressed. 2. The COMPUI PLAY button has the same function as the PC-X106/X103. 3. When carrying this unit to avoid accidentally pressing the POWER button.	When the CD tray open/close (▲) button is pressed, the source sound does not switch over, the CD tray can open or close.	1. Cuando se desconecta la alimentación, asegúrese de presionar el botón POWER. (Cuando se desconecta el POWER con el portacd de CD abierto, éste se cierra y a continuación se desconecta la energía). 2. El botón COMPUI PLAY del controlador frontal tiene la misma función como el PC-X106/X103. 3. Coloque el panel frontal alejado de usted cuando transporte la unidad, para evitar presionar accidentalmente el botón POWER.	When wake up timer is engaged, the power of this unit is not switched off even when the POWER button is pressed. 2. The COMPUI PLAY button on the remote control has the same function as the PC-X106/X103. 3. When carrying this unit to avoid accidentally pressing the POWER button.
VOLUME, TONO Y OTROS CONTROLES	VOLUMEN, TONO Y OTROS CONTROLES	VOLUME, TONO ED ALTRI COMANDI	
Boton VOLUME	Boton VOLUME	Tasti VOLUME	
+ : Utilicelo para aumentar el volumen. - : Utilicelo para reducir el volumen. (Los límites de control van de VOL 0 a VOL 25.)	+ : Utilicelo para aumentar el volumen. - : Utilicelo para reducir el volumen. (Los límites de control van de VOL 0 a VOL 25.)	+ : Per aumentare il volume. - : Per diminuire il volume. (La gamma di controllo va da VOL 0 a VOL 25.)	
Boton ACTIVE HYPER-BASS PRO	Boton ACTIVE HYPER-BASS PRO	Tasto ACTIVE HYPER-BASS PRO ON	
ON : El indicador Active Hyper-Bass Pro se enciende. Colóquelo en esta posición para escuchar el sonido Active Hyper-Bass Pro. OFF : El indicador Active Hyper-Bass Pro se apaga. Colóquelo en esta posición para escuchar el sonido Active Hyper-Bass Pro.	ON : El indicador Active Hyper-Bass Pro se enciende. Colóquelo en esta posición para escuchar el sonido Active Hyper-Bass Pro. OFF : El indicador Active Hyper-Bass Pro se apaga. Colóquelo en esta posición para escuchar el sonido Active Hyper-Bass Pro.	ON : Per attivare Active Hyper-Bass Pro si prega di posizionare l'indicatore Active Hyper-Bass Pro acceso. OFF : Per disattivare Active Hyper-Bass Pro si prega di posizionare l'indicatore Active Hyper-Bass Pro spento.	
Boton de modo de sonido	ACTIVE HYPER-BASS PRO button	Tasto del modo audio	
ON : Esta unidad posee tres modos de sonido preajustados BEAT, POP, CLEAR). Estos modos pueden ser seleccionados para realizar el tipo de música que está siendo reproducida. OFF : Presione el botón SOUND para seleccionar el modo. Cada vez que se presione el botón SOUND, el modo de sonido cambia de la siguiente manera:	ON : The Active Hyper-Bass Pro indicator lights. Set to this position for listening to Active Hyper-Bass Pro sound. OFF : The Active Hyper-Bass Pro indicator lights. Set to this position for listening to Active Hyper-Bass Pro sound.	ON : Esta unità possiede tre modi di sonido preimpostati BEAT, POP, CLEAR). Questi modi possono essere scelti per migliorare il tipo di musica ascoltato. OFF : Per scegliere un modo audio, premere il tasto SOUND. Si noti che ogni volta che si preme questo tasto, il suono viene programmato. Ad esempio, quando si preme questo tasto, il suono cambia nella sequenza seguente.	
Sound mode button	Sound mode button	Flat → Beat → Pop → Clear	
This unit has three preset sound modes (BEAT, POP, CLEAR). These modes can be selected to enhance the type of music being played. • Press the SOUND button to select the sound mode. • Each time the SOUND button is pressed, the sound mode changes as follows:	This unit has three preset sound modes (BEAT, POP, CLEAR). These modes can be selected to enhance the type of music being played. • Press the SOUND button to select the sound mode. • Each time the SOUND button is pressed, the sound mode changes as follows:	Flat → Beat → Pop → Clear	
Selección del modo de sonido	Sound mode selection	Selección del modo de sonido	
Flat : Selección efecto audio (carácterística plana). Colóquelo en esta posición cuando escucha música clásica. Beat : Colóquelo en esta posición para música rock o música molón. Pop : Colóquelo en esta posición para reproducir música ligera compuesta por música popular e instrumental.	Flat (No sound effect (flat characteristic)): Set to this position when listening to classical music. Beat: Set to this position for music with a heavy beat, such as rock or disco music. Pop: Set to this position for light music including pop, rock and vocal music.	Flat : Selección efecto audio (carácteristica plana). Colóquelo en esta posición cuando escucha música clásica. Beat : Colóquelo en esta posición para música rock o música molón. Pop : Colóquelo en esta posición para reproducir música ligera compuesta por música popular e instrumental.	

PLAYING COMPACT DISCS **REPRODUCCION DE DISCOS COMPACTOS**

CONCERNING COMPACT DISCS **EN CUANTO A DISCOS COMPACTOS**



Since dirty, damaged and warped discs may damage the unit, care should be taken when handling them.

- Use compact discs**
- Notes on handling discs**
 - Do not touch the reflective recorded surface.
 - Do not stick anything to or write anything on the label side of the disc.
 - Do not bend compact discs.
- Storage**
 - After removing a disc from the unit, be sure to put it back in its case.
 - Do not expose discs to direct sunlight, high temperatures from a heater, etc.
- Cleaning discs**
 - Before handling a disc, wipe off any dust, dirt or fingerprints with a soft cloth. Discs should be cleaned by wiping radially, from the center to the edge.
 - Never use thinner, benzine, record cleaner or antistatic spray.


Data che i CD sporchi, danneggiati e deformati possono danneggiare l'unità, prestare attenzione quando si maneggiano i CD.

- CD compatti utilizzabili**
- Note sulla manipolazione dei dischi**
 - Non toccare la superficie grabada reflectante.
 - Non incollare etichette o scrivere sul lato dell'etichetta del CD.
 - Non piegare i CD.
- Almacenamiento**
 - Guardar los discos en sus cajas luego de sacarlos del reproductor.
 - No los expusga a la luz solar directa, altas temperaturas de un coche, etc., gran humedad, polvo, etc., al umbral excesivo o a doblever.
- Limpieza de discos**
 - Antes de colocar un disco limpíe la superficie de polvo, suciedad e impresiones digitales con un paño suave. El disco debe limpiarse de forma radial desde el centro hacia el borde.
 - Nunca utilice diluyente, benzina, líquido de pulida para discos o spray antistáticas.

Nota: Non utilizar mai diluente, benzina, líquido de pulida para discos o spray antistáticas.

Lettura di un intero CD ... L'esempio seguente utilizza un CD con 12 tracce con 2 canzoni. Y un tempo di reproducción total de 48 minutos y 57 segundos.

Procedere nel orden indicado.




(PC-X103)

Lettura di un disco completo ... El siguiente ejemplo considera un disco compacto con 12 canciones y un tiempo de reproducción total de 48 minutos y 57 segundos.

Procedere en el orden indicado.

Eseguire le operazioni nell'ordine indicato.



(PC-X106)

Lettura di un intero CD ... L'esempio seguente utilizza un CD con 12 tracce con 2 canzoni. Y un tempo di lettura total de 48 minutos y 57 segundos.

Procedere nel orden indicado.

Eseguire le operazioni nell'ordine indicato.

Lettura di un CD da 8 cm non ricavato

Note:

1. Quando il cassetto del CD viene chiuso premendo il tasto ▶, la lettura del CD inizia. Se si apre il cassetto si chiude. Quando si riapre il cassetto si chiude.
2. Quando si usa il tasto di apertura/chiusura del cassetto del CD (a), la funzione cambia al modo CD.
3. Il tasto POWER per chiudere il cassetto del CD / il cassetto può essere chiuso premendo il tasto ▶.
4. Premere per avviare la lettura.
5. Regolare.

Per interrompere la lettura

1. Premere per aprire il cassetto del CD. (L'alimentazione viene attivata quando viene fornita l'alimentazione c.a.).
2. Quando si utilizzano la batteria, attivare prima il tasto POWER e quindi assicurare l'apertura del cassetto del CD.
3. Premere per chiudere il cassetto del CD / il cassetto può essere chiuso premendo il tasto ▶.
4. Premere per avviare la lettura.

Per interrompere la lettura

1. Premere il tasto di arresto/cancella-
2. Per l'interruzione nel mezzo di un disco premere il tasto □ per interrompere la lettura durante la riproduzione.

* The total number of tracks (tunes) and total playing time are displayed.

* Se visualiza el numero total de pistas (canciones) y el tiempo total de reproducción.


* Vede tempo totale di lettura.



1248:57


Programmed play (using the remote control)

- Puedes programar la reproducción de hasta 20 canciones en cualquier orden deseado.
- Se visualiza el tiempo total de reproducción de las canciones programadas (hasta 99 minutos, 59 segundos).
- (Ejemplo: Cuando programas la reproducción de la 2ª canción, la 6ª canción, la 12ª canción, etc., en dicho orden)



- Para confirmar el contenido de un programa...
Al pulsar el botón PROGRAM, se visualizan las canciones que conforman el programa en el orden programado.

To confirm the details of a program...
Press the PROGRAM button, the tunes making up the program will be displayed in programmed order.



Tune number
Número de canción
Número de brano

PROGRAM


Para cancelar los canciones programadas...
Presiona el botón /CLEAR antes de reproducir un disco. Durante la reproducción programada, presiona este botón dos veces. Al abrirse el portadisco del CD, se cancelan automáticamente las canciones programadas.

Notes:

- Si el tiempo total de reproducción de las canciones programadas asciende a 99 minutos y 59 segundos, el indicador de tiempo de reproducción no se activa.
- Cuando se programa una pista (música) cuyo número sea 21 o superior, el tiempo total de reproducción no será indicado.
- Cuando ejecuta la grabación sincronizada de CD, el paso ③ de arriba no es necesario.

Lectura programada (con el telemando)

- 20 brani possono essere programmati per essere letti in qualsiasi ordinamento.
- Il tempo totale di lettura dei brani programmati viene visualizzato (fino a 99 minuti e 59 secondi). (Esempio: quando si programma per leggere per primo il numero 2, per secondo il brano numero 6, per terzo il brano numero 12, ecc.)



- Para controlare i dettagli di un programma...
Premere il tasto /CLEAR, i brani programmati vengono visualizzati nell'ordine programmato.

- Per cancellare i brani programmatai...
Premere il tasto /CLEAR prima di togliere un CD. Durante la lettura programmata, premere questo tasto due volte. Quando il plateau del CD viene aperto, i brani programmati vengono cancellati automaticamente.

Notes:

- Se il tempo totale di lettura dei brani programmatai è superiore a 99 minuti e 59 secondi, non viene indicato.
- Cuando si programma un numero superiore a 21, non viene visualizzato il tempo di lettura totale.
- Cuando si esegue la registrazione sincronizzata di un CD, la fase ③ sopra non è necessaria.

Lectura repetida (utilizando el controlador remoto)

- Pulse el REPEAT button before or during play. A single tune or all the tunes can be repeated.
- Whether a single tune or all the tunes are to be repeated, each button press changes the repeat mode. Each time the REPEAT button is pressed, the mode will change from single tune (ALL), to the first mode (ALL), to the second mode (ALL), to the third mode, in this order.



- Reproducción repetida de una sola canción (ALL)
La canción reproducida se escuchará repentinamente.

- Reproducción repetida de todas las canciones (ALL)
Cuando se reproduce al disco completo, se escucharán repentinamente todas las canciones.

Lectura repetida (utilizando el controlador remoto)

- Puede especificar la repetición de una canción, o de un solo brano, o de todos los brani. Cada vez que se pulsa el botón REPEAT, cambia el modo de repetición de una sola canción (ALL), a todas las canciones (ALL) y al modo de cancelación, en este orden.

Lectura repetida de un solo brano (ALL)

- Repeat playback is released. La lectura repetida se cancela.

Riproduzione casuale (utilizzando il telecomando)

- Quando il tasto RANDOM viene premuto, ciò significa che un CD viene riprodotto una volta in ordine casuale.

NASTRI A CASSETTA**Nastri a cassetta**

1. Un nastro alla volta può causare problemi.

2. Per prevenire l'accendere accidentale della registrazione, rimuovere la linguetta di protezione con un cacciavite. Chiudere i fori con nastro adesivo per cancellare i rimessi.

Insettrumento della cassetta**Cassette**

1. Una cassetta linda puede causar fallas. Utilizar una cassetta normal con un tapiz, como se muestra en la ilustración.

2. Para prevenir el borado accidental de una grabación, extraiga los lazos (lengüetas) con un desatornillador. Cubra los orificios con cinta adhesiva para borrar y registrar después de haber sacado las lengüetas.

Cassette tape**Cassette**

1. Una cinta linda puede causar fallos. Utilizar una cinta normal con un tapiz, como se muestra en la ilustración.

2. Para prevenir el borado accidental de una grabación, extraiga los lazos (lengüetas) con un desatornillador. Cubra los orificios con cinta adhesiva para borrar y registrar después de haber sacado las lengüetas.

Repeat play (using the remote control)

- Press the REPEAT button before or during play. A single tune or all the tunes can be repeated.
- Whether a single tune or all the tunes are to be repeated, each button press changes the repeat mode. Each time the REPEAT button is pressed, the mode will change from single tune (ALL), to the first mode (ALL), to the second mode (ALL), to the third mode, in this order.



- Repeat playback of a single tune (ALL)
The tune being played back will be hard to hear.

- Repeat playback of all tunes (ALL)
When playing back an entire disc, all tunes will be heard repeatedly.

Random playback (using the remote control)

- When the RANDOM button is pressed, every tune in a disc is played back once, in random order.

CASSETTE**CASSETTE TAPE****Reproducción aleatoria (utilizando el controlador remoto)**

- Cuando se pulsan el botón RANDOM, la unidad reproduce una vez todas las músicas de un disco en orden aleatorio.

Cassette loading

1. Presione el botón ■ STOP/EJECT para abrir el portacasette. 2. Coloque la cinta en la ranura de cinta. 3. Cierre la cubierta del portacasette y presione el botón ■ STOP/EJECT para cerrarla. Esto indica que la cinta ha quedado seguramente.

Colocación de un cassette

1. Turn the ■ STOP/EJECT button to open the cassette holder. 2. Place the cassette as shown. 3. Close the cassette holder and press the ■ STOP/EJECT button again to close it. This indicates that the cassette has been correctly inserted.

Adhesive tape

- Side "A"
Lado "A"
Lengua "A"
Side "B"
Lado "B"
Lengua "B"

Nastro adesivo




- Side "A"
Lado "A"
Lengua "A"
Side "B"
Lado "B"
Lengua "B"

Notes:

1. Se el tiempo total de lettura dei brani programmatai è superiore a 99 minuti e 59 secondi, non viene indicato.

2. Cuando si programma un numero superiore a 21, non viene visualizzato il tempo di lettura totale.

3. Cuando si esegue la registrazione sincronizzata di un CD, la fase ③ sopra non è necessaria.

CASSETTE PLAYBACK REPRODUCCION DE CASSETTES	RIPRODUZIONE DI CASSETTE	REPRODUCCIONE CONTINUADA (SOLO PC-X106)
<p>Operate in the order shown.</p> <p>Eseguire le operazioni nell'ordine indicato.</p> 	<p>Operate in the order indicated.</p> <p>Eseguire le operazioni nell'ordine indicato.</p> 	<p>(From Deck B to Deck A) Operate in the order shown.</p> <p>(Dalla Plastica B alla Plastica A)</p> <p>Eseguire le operazioni nell'ordine indicato.</p> 
<p>RELAY PLAYBACK (PC-X106 ONLY)</p> <p>(From Deck B to Deck A)</p> <p>Operate in the order shown.</p> <p>Eseguire le operazioni nell'ordine indicato.</p>	<p>REPRODUCCION ALTERNADA (PC-X106 EXCLUSIVAMENTE)</p> <p>(De la Plastica B a la plástica A)</p> <p>Proceda en el orden mostrado.</p> <p>Eseguire le operazioni nell'ordine indicato.</p>	<p>RIPRODUZIONE CONTINUATA (SOLO PC-X106)</p> <p>(Dalla Plastica B alla Plastica A)</p> <p>Eseguire le operazioni nell'ordine indicato.</p>


- Load a cassette tape** (PC-X106 only)
Press the **POWER** button. (The power is switched on. TAPe mode is engaged and tape playback starts.) When battery power is used, switch on the **POWER** button first, then perform operations.
- Playback in Deck B (PC-X106 only)**
The previous procedures also apply to Deck B when a cassette is loaded in Deck B. When Decks A and B are simultaneously set to the play mode, only the playback sound of Deck B is heard.
- Notes:**
- When the power is turned off while the tape is still running, cassette operation buttons which are depressed do not return to the original position. Press the **TOP/EJECT** button before turning off the power.
 - Avoid operating the **FF** or **REW** button on the deck during playback of the other deck. (PC-X106)
- Note:**
- Cuando se desconecta la alimentación la cinta sale en rotación. Si se presiona el botón de expulsión del casete, los botones de operación del casete permanecen en su posición original.
 - Premere il tasto ■ STOP/EJECT per interrompere lo scorrimento del nastro prima di disattivare l'alimentazione.
- Evitar de utilizar los tasto ■ FF o ■ REW de la plástica durante la reproducción con la otra plástica. (PC-X106)

- Inserire un nastro a cassetta.**
Premere il tasto **POWER**. Per avviare la riproduzione (l'alimentazione viene attivata automaticamente) inserire una cassetta nella unità nel modo **TAPe** e la riproduzione del nastro inizia.
- Quando si utilizzano le batterie, attivare prima il tasto **POWER** e quindi seguire le operazioni.
- Reproduzione nella Plastica B (solo PC-X106)**
Le procedure precedenti si applicano anche alla Plastica B quando vi è stata inserita una cassetta. Quando la plastica A è inserita regolare contemporaneamente sul modo di riproduzione, è possibile ascoltare solo il suono di riproduzione della Plastica B.

- Set the POWER button to ON.**
Load a cassette. Color the cassette. Color the cassette.
- Press the **PLAY** button on Deck B.**
Press the **PLAY** button on Deck A.
- When Deck B stops, Deck A's pause mode will be released and it will start playback.**
Cuando la plástica B se detenga, el modo de pausa de la plástica A se liberará y se iniciará la reproducción. Cuando la plástica se detenga automáticamente, la reproducción alternada que dará desactivada.

- Positionare il tasto POWER su ON.**
Inserire una cassetta.
- Premere il tasto **PLAY** della Plastica B.**
Inserire una cassetta.
- Positionare il tasto **PLAY** della Plastica A.**
Inserire una cassetta.
- Premere il tasto **PLAY** della Plastica B.**
Inserire una cassetta.
- Positionare il tasto **PLAY** de la plástica A.**
Inserire una cassetta.
- Cuando la plástica B se detenga, el modo de pausa de la plástica A se liberará y se iniciará la reproducción.**
Cuando la plástica se detenga automáticamente, la reproducción alternada que dará desactivada.

Preselezione delle stazioni (utilizzando la unità di controllo remoto)	Premettendo su questa unità 15 pulsanti presintonia, 15 stazioni en- cratificate saranno selezionate dal ricevitore. La selezione può essere fatta sia con la tastiera numerica, sia con la tastiera dei pulsanti di presintonia. I pulsanti di presintonia sono di tipo a pulsazione singola, che si attivano per un tempo di circa 100 ms. Il segnale di selezione viene inviato alla radio via cavo.
Preselezione delle stazioni (con il telecomando)	15 stazioni per ciascuna banda (FM ed AM) possono essere preselezionate nel modo se- guente: Esempio (per preselezionare una stazione FM che trasmite a 105.5 MHz nel testo di presintonia numero 15): FM 105.5



- **Para cambiar las estaciones presintonizadas**
Realice el paso mencionado después

- Per cambiare le situazioni
Eseguire la fase di
iniziazione della stazione o

100

*ra dopo aver simo-
derata.*

10

1

116

transmissione AM si
utili se viene utili-

In option

260

28


zionate verranno un'interruzione di ore o se il cavo di acciaio per più di quattro di nuovo la

open
(PC)

111

100
mississippi

Preset tuning	The stations must be preset before this operation can be performed.	Sintonización de estaciones presintonizadas	Deberán preintonizarse las estaciones para poder realizar esta operación.
Using the controls of the main unit)	Press the TUNER BAND button. Select the band (FM or AM) using the BAND button. Press the PRESET TUNING button to select the required preset station.	Utilizando los controles de la unidad principal)	<ul style="list-style-type: none"> Presione el botón TUNER BAND. Seleccione la banda (FM o AM) utilizando el botón BAND. Presione el botón PRESET TUNING para seleccionar la estación preintonizada deseada.
Using the remote control unit)	Press the TUNERBAND button. Select the band (FM or AM) using the TUNERBAND button. Press the PRESET button. If a required preset station buttons (No. 0, 1, 2, 3, 4, 5, 6, 7, 8, 9) are pressed, the station number and frequency corresponding to the button pressed are shown.	Utilizando el control remoto)	<ul style="list-style-type: none"> Presione el botón TUNERBAND. Seleccione la banda (FM o AM) utilizando el botón TUNERBAND. Presione el botón PRESET. Si se presionan los botones de estación preselecciónadas (Nº. 0, 1, 2, 3, 4, 5, 6, 7, 8, 9), se visualizará el número de estación correspondiente al botón presionado.
Sintonía de las estaciones presintonizadas	Sintonía de las estaciones presintonizadas	Sintonía de las estaciones presintonizadas	Sintonía de las estaciones presintonizadas
	The stations devon essere preselezionate prima di poter eseguire questa operazione.	Le stazioni devono essere preselezionate prima di poter eseguire questa operazione.	Le stazioni devono essere preselezionate prima di poter eseguire questa operazione.
	(Uso de los comandos de la unidad principal)	(Uso del telecomando)	(Uso del telecomando)
	<ol style="list-style-type: none"> Premere il tasto BAND Selezionare la banda (FM o AM) con il tasto BAND. Premere il tasto PRESET TUNING per selezionare la stazione preselezionata desiderata. 	<ol style="list-style-type: none"> Premere il tasto TUNERBAND Selezionare la banda (FM o AM) utilizzando il botón TUNERBAND. Premere il tasto PRESET della stazione preselezionata desiderata (Nº. 0, 1, 2, 3, 4, 5, 6, 7, 8, 9). 	<ol style="list-style-type: none"> Premere il tasto TUNERBAND Selezionare la banda (FM o AM) utilizzando il botón TUNERBAND. Premere il tasto PRESET della stazione preselezionata desiderata (Nº. 0, 1, 2, 3, 4, 5, 6, 7, 8, 9). Il numero della stazione preselezionata e la frequenza corrispondenti al tasto premuto vengono visualizzati.



Note: L'antenna incorporata con un'antenna esterna può essere interamente privata da televisioni nel capitolato che possono disturbare la ricezione di AM.


REGISTRAZIONE	GRABACION	REGISTRACION
<p>In recording, the ALC circuit automatically optimizes the recording level; adjustment of the recording level is unnecessary. Check that the safety tab on the cassette tape is not broken off. To avoid maturation, do not perform operations on deck B when recording.</p>	<p>Al efectuar una grabación, el circuito ALC (control automático de nivel) optimiza automáticamente el nivel de grabación, por lo tanto no es necesario ajustar el nivel de grabación.</p> <ul style="list-style-type: none"> - Verifique que el cassette tenga su lengüeta de seguridad intacta. - Evite las operaciones de lectura y escritura en la placa B durante la grabación. 	<p>Durante la registrazione, il circuito ALC (control automatico di livello) ottimizza automaticamente il livello di registrazione, la regolazione del livello di registrazione non e' perciò necessaria.</p> <ul style="list-style-type: none"> - Controllare che la linguetta di protezione della registrazione della cassetta non sia rotta. - Per evitare la maturazione, non eseguire operazioni sulla piastra B durante la registrazione.

卷之三

10

(No.1986) 19


Synchronized recording with the CD player.
In this system, the CD player starts playback when the cassette deck enters the recording mode.
Operate in the order shown.



- Load a disc and close the CD tray.
- Set CD mode.
- Insert a cassette in the deck with side A facing up.
- Press the REC button.
- Press the PAUSE button.

When automatic switching between tunes is not required ...
Perform the following after finishing the previous operation (① to ②).
① Press the ▶/II button of the CD player twice.
The CD player enters the pause mode.
② Press the ● REC and PLAY▶ buttons simultaneously, the CD player starts playback simultaneously.

Grabación sincronizada con el reproductor de CD.
En este sistema, el reproductor de CD comienza la reproducción cuando el cassete deck entra en modo de grabación.
Proceda en el orden indicado.




- Load a disc and close the cassette deck.
- Set the CD mode.
- Insert a cassette in the deck with side A facing up.
- Press the REC button.
- Press the PAUSE button.

When automatic switching between tunes is not required ...

- Press the REC button.
- Press the PAUSE button again.

Registrazione sincronizzata con il lettore CD.
In questo sistema, il lettore CD inizia la lettura quando la piastra a cassette entra nel modo di registrazione.
Eseguire le operazioni nell'ordine indicato.




- Inserire un CD e chiudere il cassetto del CD.
- Impostare il modo CD.
- Inserire una cassetta nella piastra con il lato A rivolto in alto (faccia attenzione a non rovesciare la cassetta).
- Avviare la guida del nastro prima di iniziare la registrazione.
- Se si desidera registrare la riproduzione programmata, programmare i brani desiderati utilizzando il telecomando. (Vedere pag. 22).
- Selezionare i brani con un tempo di registrazione / treno che non supera la durata del nastro.
- Selezionare il modo di registrazione.
- Premere il tasto ● REC insieme a quello PAUSE.
- La registrazione sincronizzata ha inizio.

- Colocar un disco y cerrar el portadisco del CD.
- Configurar el modo CD.
- Colocar un casete en la placa con la cara A hacia arriba (fijese de no voltear el casete).
- Al iniciar la grabación, presionar la guía del nastro para iniciar la reproducción.
- Si se desea registrar una reproducción programada, programe los cancioness deseadas utilizando el control remoto. (Vea la página 22).
- Seleccione las canciones que posean un tiempo de reproducción que no sea superior al tiempo de duración del nastro.
- Selecione el modo de grabación.
- Presionar el botón ● REC y el botón PAUSE al mismo tiempo que presiona el botón PLAY▶.
- Quedan automáticamente secciones sin grabar de unos segundos entre cada canción.
- Cuando la cinta llega al final durante la reproducción, se detiene automáticamente, cuando el reproductor se detiene por primera vez, la cinta continúa moviéndose. En ese caso presione el botón ■ STOP/EJECT para detener la cinta.

- Tra las canciones que no se registran se crean automáticamente espacios de unos segundos.
- Cuando la cinta llega al final durante la reproducción, se detiene automáticamente, cuando el reproductor se detiene por primera vez, la cinta continúa moviéndose. En ese caso presione el botón ■ STOP/EJECT para detener la cinta.
- Para detener temporalmente la grabación, presionar el botón PAUSE. Para reiniciar la grabación, presionar de nuevo el botón PAUSE.

- Nota: Cuando se registra la cinta en la placa B, ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106 exclusivamente)

Note:
During CD synchronous recording, the ▶/II and SEARCH (◀/▶) buttons do not function. (PC-X106)
During CD synchronous recording, the CD does not effect the operations on Deck B, because the tape in Deck B is played back, that sound would also be recorded. (PC-X106 only)




- Notre que la grabación sincronizada del CD durante la grabación sincronizada del CD, no funciona. (PC-X106)
- Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106 exclusivamente)

Note:
It may be unlawful to record or playback copyrighted material without the consent of the copyright owner.



- Es ilegal grabar o reproducir materiales con derechos registrados sin la autorización del propietario.

Grabación de una radiodifusión
Proceda en el orden indicado.




(PC-X106)

Note:
During the playback recording, the ▶/II and SEARCH (◀/▶) buttons do not function. (PC-X106)
During the playback recording, the CD does not effect the operations on Deck B, because the tape in Deck B is played back, that sound would also be recorded. (PC-X106 only)



- Notre que la grabación de audios sin la autorización del propietario.

Recording from the radio
Operate in the order shown.



(PC-X106)

Note:
During the playback recording, the ▶/II and SEARCH (◀/▶) buttons do not function. (PC-X106)
During the playback recording, the CD does not effect the operations on Deck B, because the tape in Deck B is played back, that sound would also be recorded. (PC-X106 only)



- Notre que la grabación de audios sin la autorización del propietario.

Recording from the radio
Operate in the order shown.

Note:
Durante la grabación sincronizada del CD, no funcionan los botones ▶/II y SEARCH (◀/▶). Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106)

Note:
Durante la grabación sincronizada del CD, no funcionan los botones ▶/II y SEARCH (◀/▶). Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106)

Note:
Durante la grabación sincronizada del CD, no funcionan los botones ▶/II y SEARCH (◀/▶). Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106)




Note:
Durante la grabación sincronizada del CD, no funcionan los botones ▶/II y SEARCH (◀/▶). Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106)

Note:
Durante la grabación sincronizada del CD, no funcionan los botones ▶/II y SEARCH (◀/▶). Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106)


Note:
Durante la grabación sincronizada del CD, no funcionan los botones ▶/II y SEARCH (◀/▶). Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106)

Note:
Durante la grabación sincronizada del CD, no funcionan los botones ▶/II y SEARCH (◀/▶). Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106)

Note:
Durante la grabación sincronizada del CD, no funcionan los botones ▶/II y SEARCH (◀/▶). Durante la grabación sincronizada del CD, no efectúa las operaciones en la placa B ya que si se reproduce la cinta en la placa B, el sonido también será grabado. (PC-X106)



WAKE UP TIMER OPERATIONS	OPERACION DEL TEMPORIZADOR DESPERTADOR	FUNZIONAMENTO DEL TIMER PER LA SVEGLIA
<p>Boton de supresión del bittimento (BEAT CUT)</p> <p>Cuando se registra una transmisión AM, si poseen produce el bittimento que no serán escuchados. En tal caso, set this button after setting the deck to record mode so that the beats are eliminated. Normally set this switch to "CUT-1".</p> 	<p>Tasto di soppressione del battimento (BEAT CUT)</p> <p>Quando si registra una trasmissione AM, si poseono produrre dei battimenti che non verranno uditi quando si ascolta tale trasmissione. In tal caso, registrare questo tasto dopo aver impostato il piastrino nel modo di registrazione o di eliminare dai battimenti. Normalmente questo tasto su "CUT-1".</p>	<p>Come impostare il timer per la sveglia (Esempio: Quando l'ora corrente è 22:00 e si desidera impostare il timer per le 6:00 della mattina successiva (dopo circa 8 ore).)</p> 
<p>Borrado</p> <p>Cuando graba sobre una cinta pregrabada, la grabación previa se borra automáticamente grabado al reproducir la cinta.</p> <p>Para borrar una cinta sin efectuar una nueva grabación</p> <p>Presione el botón "PLAY" de la plática para activar el modo TAPE Y presione conjuntamente los botones REC y PLAY después de presionar el botón STOP/EJECT.</p>	<p>Cancellazione</p> <p>Quando si registra su un nastro pre-registrato, la registrazione precedente viene cancellata automaticamente secca la nuova registrazione riproduttore.</p> <p>Per cancellare un nastro senza eseguire una nuova registrazione</p> <p>Premere il tasto PLAY della piastra per impostare il modo TAPE e quindi premere i tasti REC e PLAY contemporaneamente dopo aver premuto il tasto STOP/EJECT.</p>	<p>Ajuste del temporizador despertador</p> <p>(Ejemplo: Cuando la hora actual es PM 10:00 y usted desea despertarse a las AM 6:00 de la mañana siguiente (8 horas más tarde aproximadamente).)</p> 

DUBBING (SYNCHRO START DUBBING) (PC-X106 ONLY)	COPIA (CON COMIENZO SINCRONIZADO) (PC-X106 EXCLUSIVAMENTE)	DUPPLICACION (DUPLICACION CON AVIVAMIENTO SINCRONIZADO) (SOLO PC-X106)
<p>Erasing</p> <p>When recording on a pre-recorded tape, the previous recording is automatically erased and the new material can be heard when the tape is played.</p> <p>To erase a tape without making a new recording</p> <p>Press the "PLAY" button of the deck to set to the TAPE mode and press the REC and PLAY buttons together after pressing the STOP/EJECT button.</p>	<p>Borrado</p> <p>Cuando graba sobre una cinta pregrabada, la grabación previa se borra automáticamente grabado al reproducir la cinta.</p> <p>Para borrar una cinta sin efectuar una nueva grabación</p> <p>Presione el botón "PLAY" de la plática para activar el modo TAPE Y presione conjuntamente los botones REC y PLAY después de presionar el botón STOP/EJECT.</p>	<p>Normal speed dubbing can be done from Deck B to Deck A.</p> <p>La copia a velocidad normal puede ser efectuada desde la plática B a la A.</p> <p>Operate in the order indicated.</p>



(PC-X106)
Load a cassette. Refer to the note on page 29.
Load a pre-recorded cassette. Press the TAPE mode button to set to TAPE mode. The button should not be locked.
Press the PAUSE button with the PLAY button. The REC button (REC) concomitantly with the button PLAY. (Mode of pause della registrazione). Press the button PLAY. (Synchronized dubbing will start.)

- Load a cassette. (Refer to the note on page 29).
● Insertare una cassetta. (Vedere la nota a pagina 29).
- Load a pre-recorded cassette.
● Posare una cassetta pre-registrata.
- Press the TAPE mode button to set to TAPE mode. (El botón no debe estar bloqueado).
● Premere il tasto PAUSE.
● Premere il tasto REC con il tasto PLAY. (Modo di pausa della registrazione).
- Premere il tasto PLAY. (se inizierà la sincronizzazione iniziale).

MANTENIMENTO	MANTENIMENTO	MANTENIMENTO	TROUBLESHOOTING	DETECCION DE PROBLEMAS	GUIDA ALLA SOLUZIONE DEI PROBLEMI
Cleaning is important! When the tape is running, magnetic powder and dust naturally accumulate on the heads, capstan and pinch roller. When they become too dirty... quality deteriorates. the output sound level drops. the previous sound is not completely erased. Recording is not performed satisfactorily. Because of this, you should clean the heads, etc. after 10 hours of use, so that perfect recording is possible.	Limpieza de cabezas, capstán e rodillo de presión Abra el portacassete. Ponga la cinta, rutin presión e capstán. Ponga la cinta en modo oficial. Utilizar un kit de limpieza disponible en el mercado o en las tiendas de electrónica. Limpie los rodillos de la cinta y el capstán con un paño seco y limpio. Después de la limpieza, asegúrese de que el líquido de limpieza se haya secado completamente antes de colocar un cassette.	Pulizia di testine, capstan e rollini pressori Aprire il vano della cassetta. Ponere la testina, rutini pressori e capstan. Ponere la testina in modo ufficiale. Utilizzare un kit di pulizia disponibile nel mercato oppure specificato per la pulizia dei rodillli e del capstan. Pulire i rodillli e la testina con un panno asciutto e pulito. Dopo la pulizia, assicurarsi che il liquido di pulizia sia completamente asciugato prima di inserire una cassetta.	What appears to be trouble is not always serious. Make sure first... 1. Power can not be turned on? Is the power cord unplugged? 2. No sound from the speakers. Are headphones connected? 3. The disc player does not play. Is the disc upside down? Is the disc dirty? 4. A certain portion of the disc does not play correctly. Is the disc scratched?	Quando il nastro scorre si raccoglie molto spesso su questi componenti. Se non è pulito, il suono non è nello stesso modo. 1. Non si può accendere la unità. * È stata disconnesso il cavo di alimentazione? 2. Non sente sonido por los altavoces. * Los auriculares están conectados? 3. El lector de CD no funciona. * ¿El CD está invertido? * ¿El CD es sucio? 4. No se puede reproducir correctamente una cierta sección del disco. * ¿Está el disco rayado?	Quello che pare essere una falla non sempre è così serio. Assicurarsi prima... 1. Non si può accendere la unità. * È stata disconnesso il cavo di alimentazione? 2. Non sente sonido por los altavoces. * Están conectados los auriculares? 3. El lector de CD no funciona. * ¿El CD è capovolto? * ¿El CD è sporco? 4. Una parte del CD non viene letta correttamente. * ¿Está la sección del disco rotada? * ¿Está el disco graffiato?
Cleaning the heads, capstan and pinch roller Open the cassette holder. Clean the heads, pinch roller and capstan. For this purpose, use a cleaning kit available from electronic stores. After cleaning, be sure that the cleaning fluid has dried completely before loading a cassette.	Record/play head Cabezal de grabación/reproducción Tasma de cancellazione 	Erase head Cabezal de borrado Testina di cancellazione 	7. Reception is noisy. • Try adjusting the antenna. 8. Timer Section • Remote Control 9. Remote control is impossible. • Are the batteries in the remote control exhausted? • Is the REMOTE SENSOR section exposed to bright light (direct sunlight, etc.)?	7. La recepción es ruidosa. • Sintonización de la antena. 8. Sección del temporizador • Control remoto 9. No es posible controlar la unidad. • Las pilas del control remoto están agotadas. • ¿Está la sección REMOTE SENSOR expuesta a la luz solar directa, etc.?	7. La recepción es ruidosa. • Sintonización de la antena. 8. Sección del temporizador • Control remoto 9. No es posible controlar la unidad. • Las pilas del control remoto están agotadas. • ¿Está la sección REMOTE SENSOR expuesta a la luz solar directa, etc.?
Caution: 1. Keep magnets and metallic objects away from the head. If the head becomes magnetized, noise will increase and the tone will change. Demagnetize the head by using a magnet or a soft cloth. It is also possible to use a magnet or a soft cloth to remove static electric charge. (When demagnetizing the head, set the POWER button enough to set to STANDBY). As the erase head of this unit is of magnetic type, do not demagnetize it. 2. Do not use anything other than alcohol for cleaning. Thinner and benzene will damage the rubber pinch roller.	Precauciones: 1. Mantenga imanes y objetos metálicos lejos de la cabeza. Si se magnetiza la cabeza, aumenta el ruido y se deteriora la tono. Desmagnetice la cabeza con un imán o una tela suave. Es también posible deshacerse de la electricidad estática con un imán o una tela suave. (Cuando se desmagnetiza la cabeza, aségúrese que el botón POWER esté en STANDBY). • Como la cabeza de borrado de esta unidad es de tipo magnético, no la desmagnetice. 2. Utilice únicamente alcohol para la limpieza. La benzina y el diluyente dañarán el rodillo de presión de goma.	Precauciones: 1. Tener magneti ed oggetti metallici lontani dalla testina. Se la testina si magnetizza, i dialetti aumentano e il tono si deforma. Desmagnetizzare la testina ogni 20-30 ore con un imán o una toalla suave. Es también posible deshacerse de la electricidad estática con un imán o una toalla suave. (Cuando se desmagnetiza la testina, aségúrese que el botón POWER esté en STANDBY). • Poco la testina di cancellazione di questo apparecchio è del tipo magnetico, non smagnetizzarla. 2. Utilizzare solo alcool per la pulizia. Diluente o benzina danneggeranno la gomma del rollino di presione.			

SPECIFICATIONS	ESPECIFICACIONES	DATI TECNICI
Compact disc player section		
Type	Compact disc player	
Signal detection	Non-contact optical pick-up	
Number of channels	2 channels	
Frequency range	20 Hz - 20,000 Hz	
Signal-to-noise ratio	90 dB	
Wow & flutter	Less than measurable limit	
Radio section		
Frequency ranges	FM: 87.5 - 108 MHz AM: 522 - 1629 kHz LW: 144 - 288 kHz	
Antennas	Telescopic antenna for FM Furite core antenna for AM and LW	
Tape deck section		
Track system	4-track 2-channel stereo	
Motor	Electronic power motor for capstan	
Heads	DC motor for capstan Duct A: Hard permalloy head for recording/playback Magentic head for erasure Duct B: Hard permalloy head for playback Capstan Head capstan Hard permalloy head for recording/playback Magentic head for erasure Duct C: Hard permalloy head for recording/playback Capstan Head capstan	Cabezas Cabezas
Frequency response	63 - 12,500 Hz	
Wow and flutter	0.15% (WRMS)	
Fast wind time	Approx. 120 sec (C-80 cassette)	
General		
Power output	Max. 15.4 W (7.7 W + 8.7 W) at 3 Ω 8 W (4 W + 4 W) at 3 Ω (10% THD)	
Output jacks	Headphones (0-20 mW/ohm, 32 Ω) Matching impedance 16 Ω - 1 KΩ	Jacks de salida
Power supply	AC 220 V "Power DC 12 V" (20 D 13F" cell, 18 Ext. DC 12 V (car battery via optional CA-R120 car adapter) 14 W (with POWER button ON) 4 W (with POWER button STANDBY) 802 (0.6) mm including knobs	Alimentación
Power consumption		
Dimensions	622 (0.6) x 322 (1.1) x 330 (0.9) mm	Dimensiones

PC-X106	: (PC-X106) con batterie 8.0 kg : (PC-X106) senza batterie 7.2 kg	Peso	: (PC-X106) con batterie 8.0 kg : (PC-X106) senza batterie 7.2 kg
PC-X103	: (PC-X103) con batterie 7.7 kg : (PC-X103) senza batterie 6.9 kg	Peso	: (PC-X103) con batterie 7.7 kg : (PC-X103) senza batterie 6.9 kg
Accessories provided	Numero canali 2 canales Gamma di frequenza 20 Hz - 20,000 Hz Rapporto segnale/rumore superiore a 90 dB Peso del limitatore misurabile	Accessori in dotazione	Numero canali 2 canales Gamma di frequenza 20 Hz - 20,000 Hz Rapporto segnale/rumore superiore a 90 dB Peso del limitatore misurabile
Speaker Section (each unit)	F.M.: 87.5 - 108 MHz A.M.: 522 - 1629 kHz L.W.: 144 - 288 kHz Antenna para FM Antena telescópica para AM Antena con antena interna para AM e LW	Speaker Section (each unit)	F.M.: 87.5 - 108 MHz A.M.: 144 - 288 kHz Antenna telescópica para FM Antena con antena interna para AM e LW
Station pista a cassette	Sistema de registrazione Motor	Station pista a cassette	Sistema de registrazione Motor
Station diffusori (classe una unità)	Speaker 10 cm x 1 Impedenza 3 Ω Dimensioni 190 (A) x 242 (An) x 212 (P) mm Peso : Aprox. 1.35 kg	Stazione diffusori (classe una unità)	Speaker 10 cm x 1 Impedenza 3 Ω Dimensioni 190 (A) x 242 (An) x 212 (P) mm Peso : Aprox. 1.35 kg
Design e dati tecnici soggetti a modifiche senza preavviso.	Disco y especificaciones sujetos a cambios sin aviso.		

1 Location of Main Parts

■ Front cabinet inside




Fig. 1 – 1

■ Rear cabinet front view




Fig. 1 – 2

■ CD unit (Top side)




Fig. 1 – 3

■ CD unit (Bottom side)




Fig. 1 – 4

■ Top cabinet unit (Top side)




Fig. 1 – 5

■ Top cabinet unit (Bottom side)




Fig. 1 – 6

■ Top cabinet bottom side




Fig. 1 - 7

■ Main board (Top side)




Fig. 1 - 8

■ Rear cabinet inside view




Fig. 1 - 9

2 Removal of Main Parts

■ Enclosure section

◆ Front cabinet (Fig. 2-1~Fig. 2-2)

1. Remove the six screws ① retaining the front cabinet from the rear and bottom. (Use a screwdriver with a shank length of 22 cm or more.)
2. Remove the two screws ② retaining the front cabinet from both sides.
3. The front cabinet can be removed if pulled towards the front.

◆ CD player unit (Fig. 2-3)

1. Disconnect the three flat wires connected to the CD player from main PC board connectors CN718, CN716, and CN302.
2. The CD player unit can be removed from the rear cabinet if pulled towards the front.

(※ At this time, you can replace the fuse mounted on the power PC board in the back right corner of the rear cabinet.)

◆ Cassette mechanism and main amplifier board assembly unit (Fig. 2-1, Fig. 2-3)

1. Remove the screw ③ securing the speaker terminal from the rear of the rear cabinet. (See Fig. 1.)
2. From the front, disconnect the flat wire to the tuner PC board from main PC board connector CN711.
3. Pull out the cassette mechanism and main PC board ass'y from the rear cabinet, then disconnect the wire connector (W991) on the main PC board from power PC board ass'y connector CN991 located in the back right corner of the rear cabinet.




Fig. 2-1




Fig. 2-2




Fig. 2-3

◆ Power transformer and power supply board assembly

(Fig. 2-4)

1. Install the AC jack of the power PC board assembly onto the rear cabinet, then remove the two screws ④.
2. Disengage the tab on the battery PC board, then remove the PC board together with the power PC board. If necessary, disconnect the connector to the power transformer.
3. Remove the two screws ⑤ retaining the shield plate and power transformer.
4. Remove the two screws ⑥ retaining the power transformer.

◆ Tuner board ass'y (Fig. 2-4)

1. Disconnect the antenna wire from TP1 on the tuner PC board.
2. Remove the screw ⑦ retaining the PC board holder.
3. Pull out the PC board assembly from the rear cabinet.

◆ Internal parts of the front cabinet (Fig. 2-5)

1. Remove the front cabinet.
2. Remove the screw ⑧ retaining the power switch button.
3. Remove the screw ⑨ retaining the function switch button.
4. Remove the two screws ⑩ retaining the holder.
5. Remove the eight screws ⑪ retaining the switch PC board.




Fig. 2 - 4




Fig. 2 - 5

◆ Main board ass'y and cassette mechanism ass'y

(Fig. 2-6~Fig. 2-7)

1. Remove the front cabinet.
2. Remove the cassette mechanism assembly and main board assembly unit from the rear cabinet.
3. Turn the unit upside down so that the top cabinet faces down.
4. Remove the five screws ⑫ retaining the main board ass'y.
5. Slightly lift the main PC board, then disconnect the parallel wires coming from the switch PC board assembly from CN701 on the main PC board assembly.
6. Turn the main PC board assembly upside down (the parts side will face up). Disconnect the wire holder PP11 on the PC board, then disconnect the A mechanism head wire CNA32 (5 pins), the B mechanism head wire CNA31 (3 pins), and the mechanism drive connector CNA33 (15 pins).
7. Remove the three screws ⑬ retaining the switch board ass'y. (When removing the switch PC board holder with the switch PC board mounted on it, remove the two screws ⑭.)
8. Remove the five screws ⑭ retaining the mechanism.
9. Open the cassette door, then remove the cassette mechanism unit from the top cabinet.

◆ Removing the cassette door (Fig. 2-8)

- a. Remove the cassette mechanism ass'y, push the cassette door left arm inward, disengage the door shaft and remove it from the top cabinet. Make sure to hold the edge while performing this step or the door spring may fly out, possibly causing injury.
 - b. When reattaching, start with the door spring side, then push the opposite side in.
 - c. Fit the door spring into the slit.
- (※ Although cassette door removal is possible with the mechanism assembly mounted, removing the mechanism assembly beforehand will make it easier and ensure correctness.)




Fig.2-6




Fig.2-7




Fig.2-8

■ CD unit section

◆ Removing the CD amplifier board (See Fig. 2 – 9)

1. Remove the front panel assembly (See "Removing the front panel assembly").
2. Remove the CD mechanism assembly (See "Removing the CD mechanism assembly").
3. Remove the two screws ⑩ retaining the CD amplifier board.
4. From the loading base assembly, remove the two pawls (Ⓐ and Ⓑ) fixing the CD amplifier board.
5. From the connector CN501 on the CD amplifier board, remove the card wire outgoing from the CD pickup unit. In this case, the card wire should be disconnected after removing the pawls of the connector CN501 in the arrow direction as shown in Fig. 2 – 9.
6. Remove the (CD amplifier board) from the 6PIN connector outgoing from the CD mechanism board.




Fig. 2 – 9

◆ Removing the CD tray (See Fig. 2 – 10, Fig. 2 – 11)

1. Remove the front cover assembly (See "Removing the front cover assembly").
2. Remove the CD mechanism assembly (See "Removing the CD mechanism assembly").
3. Remove the one screw ⑪ provided for the CD tray stopper (See Fig. 2 – 10).
4. After turning over the loading base assembly, insert a plus screw driver into the hole Ⓜ on the loading motor board and turn the driver counterclockwise. Then the CD mechanism will be raised (See Fig. 2 – 11).
5. By pulling out the CD tray manually toward the front side, take it out from the loading base.




Fig. 2 – 10




Fig. 2 – 11

♦ **Removing the clamper base assembly (See Fig. 2 – 12)**

Remove the two screws ②③ retaining the clamper base assembly.




Fig. 2 – 12

♦ **Removing the loading motor (See Fig. 2 – 13, Fig. 2 – 14)**

1. Remove the front cover assembly (See "Removing the front cover assembly").
2. Remove the CD mechanism assembly (See "Removing the CD mechanism assembly").
3. Remove the CD tray (See "Removing the CD tray").
4. Remove the clamper base (See "Removing the clamper base").
5. From the loading base assembly, remove the two screws ④ retaining the loading motor (See Fig. 2 – 13).
6. Remove the belt from the motor pulley (See Fig. 2 – 13).
7. After turning over the loading base assembly, remove the three pawls (⑤, ⑥ and ⑦) by spreading these pawls in the arrow direction (See Fig. 2 – 14).
8. Remove the two soldered parts ⑧ connecting the loading motor (See Fig. 2 – 14).




Fig. 2 – 13





Fig. 2 – 14

♦ **Removing the CD mechanism (See Fig. 2 – 15)**

1. Remove the front cover assembly (See "Removing the front cover assembly").
 2. Remove the cassette mechanism and CD mechanism assembly (See "Removing the cassette mechanism and CD mechanism assembly").
 3. Remove the CD mechanism assembly (See "Removing the CD mechanism assembly, power amplifier assembly and clamper base assembly").
 4. Remove the two screws ②5 retaining the CD mechanism.
 5. To release the engagement between the shaft at the upper part of the CD mechanism and the Part H (slide groove) of the loading base assembly, take out the CD mechanism diagonally upward while pulling out the mechanism toward the front side.
- ★ For re-assembly, move the slide of the loading base assembly in the direction of Arrow ①, and assembly the CD mechanism while inserting the shaft at the upper part of the CD mechanism into the Part A (slide groove).



♦ **Removing the CD pickup unit (See Fig. 2 – 16)**

1. Move the cam gear in the arrow direction ⑨. Then, the CD pickup unit will be moved in the arrow direction ⑩.
2. According to the above step, shift the CD pickup unit to the center position (Fig. 2 – 16).
3. While pressing the stopper retaining the shaft in the arrow direction ⑪, pull out the shaft in the arrow direction ⑫ (See Fig. 2 – 16).
4. After dismounting the shaft from the CD pickup unit, remove the CD pickup unit.





Fig. 2 – 16

Cassette Mechanism Section



■ Removing the Capstan motor

(See Fig.2-17)

1. Remove the Front panel assembly.(Refer to the article "Front panel assembly" appearing on a previous page)
2. Remove the Cassette mechanism assembly.(Refer to the article "Cassette mechanism assembly" appearing on a previous page)
3. Remove the Main board(Refer to the article "Main board" appearing on a previous page.)
4. Remove the Cassette mechanism. (Refer to the article "Cassette mechanism" appearing on a previous page.)
5. Remove two screws ① retaining the capstan motor assembly from the back of the cassette mechanism .
6. Take out the main belt from the flywheel assembly. Then, slide the capstan motor slightly in the direction of the arrow ② while pulling downwards to remove together with the main belt.

■ Removing the Eject slide lever

(See Fig.2-18)

1. Place the cassette mechanism back side frontward and disengage the stopper arm ③ of the Eject slide lever by pressing it inwards through the opening of the chassis with a small screwdriver as shown in Fig. 2-18.
2. Disengage the Eject slide lever in the direction of arrow ④.

Fig.2-17




Fig.2-18




Fig.2-19

■ Removing the Leaf switch


(See Fig.2-19)

Press the leaf switch in the direction of the arrow ① and then remove it in the direction of the arrow ② referring to Fig. 2-19.

■ Removing the Pinch roller assembly

(See Fig.2-20)

1. Full out the stopper protruding from the base assembly in the direction of the arrow ① to remove it from the pinch roller assembly.
2. Then, pull out the pinch roller assembly in the direction of the arrow ②.



■ Removing the Record/Playback head &

Erase head (See Fig.2-21 and 2-22)

1. Remove two screws (②and③) retaining the Record / Playback head.
2. Pull out the stopper of the Erase head in the direction of the arrow ④.
3. Pull out the Erase head in the direction of the arrow ⑤.




Fig.2-21




Fig.2-22

■ Removing the Flywheel assembly

(See Fig.2-23)

1. E. whasher retaining the flywheel assembly in the direction of arrow ①.
2. Pull the flywheel assembly out of the back side of the cassette mechanism in the direction of the arrow ②.




Fig.2-23

3 Main Adjustments

■ Test Instruments required for adjustment

1. Low frequency oscillator
(oscillation frequency: 50Hz to 20kHz)
(Output : 0 dBs with 60 Ω terminator)
2. Attenuator(Impedance : 600 Ω)
3. Test Tapes
 - VTT712 (VT712) For tape speed,wow and flutter measurement
 - VTT724 (VT724) For play back output level
 - VTT739 (VT739) For playback frequency response check
 - VTT703 (VT703) For head azimuth measurement
4. Electronic voltmeter, Distortion meter
5. Resistor...600 Ω for attenuator matching
6. Torque gauge..... Cassette type for CTG - N mechanism adjustment
7. Wow and Flutter meter , Frequency counter
8. Blank tape Normal:UR,Chrome: AC225

■ Measuring conditions (Amplifier section)

- Supply voltage AC230 V (50/60 Hz)
Reference output : Speaker 0 dBs (0.775V) / 3 Ω
(Volume Level: 19)
: Headphone - 10 dBs (0.245V) / 32 Ω

● Standard position of functionswitches

- Function switch TAPE
Mode switch STEREO

● Standard position of volume control

- Sound Flat position
AHB PRO OFF
Main volume adjust 0 dBs Speaker out(Vol.19)
Headphone out(Vol.20)

Beat cut switch Cut1

Standard test frequency 1 kHz
; unless otherwise specified.

Reference input level TP(CN301) : - 20dBs
Input for REC/PB, Check &measuring CN301
: -20 dBs

● Test remarks

1. Negative side of the input and output on the testing set, that ought to be separately to each other, and then bear in mind there connection the testing set with 2 channelles Electronic voltmeter, the negative side never connect commonly.
2. Replaced output load with a dummy and that lead wire to be used as big as possible.
3. Attach top cover when measuring and connect filter shown below Fig. 1 to V. meter.

■ Measuring condition (Radio section)

- Refer to rating source Tuner+B : DC 5.7V
Reference output Speaker : 20mW(0.245 V) / 3 Ω
Headphone : 0.11 mW (0.06 V)/32 Ω
AM frequency 400Hz modulation 30%
FM frequency 400Hz modulation
frequency deviation 22.5kHz

● Standard position of switches and controllers

- Function RADIO
Mode STEREO

● Careful points for adjustment

1. Connect 30 pF capacitor and 33 k Ω resistor to the output side of the IF sweeper in series while 0.082 μ F capacitor and 100k Ω resistor to the input side in series.
2. Set output level of the IF sweeper as minimum as adjustable.
3. RF Alignment order
Procedure of the steps of tracking should be kept.

◎ Test point : CN301(Top view)




Fig. 3 - 1

■ Arrangement of Adjusting Position

(Cassette mechanism)





Fig.3-2

■ Tuner board



■ Main board




Fig.3-4

Fig.3-3

■ Cassette and amplifier section

Item	Conditions	Adjustment & Confirmation Methods	Stand. values	Adjust
Head azimuth adjustment	<ul style="list-style-type: none"> • Test tape : VTT703 (10kHz) • Output terminal for measurement : Headphone • Input terminal for measurement : CN301 	<p>* Adjust the head azimuth screw only when the head is replaced.</p> <p>① Playback test tape VTT703 (10kHz) .</p> <p>② Adjust the head azimuth so that the phase difference is minimum (Within 2dB of the peak level of play output.) After adjustment apply the screw locking adhesive to the head azimuth screw more than a half arund the screw head.</p>	Within 2dB of the peak level Minimum phase difference	Head azimuth adjusting screw
Tape speed adjustment and wow &Flutter checking	<ul style="list-style-type: none"> • Tast tape : VTT712 (3kHz) • Output terminal for measurement : Headphone 	<p>① When playing test tape VTT712 (3kHz).</p> <p>② Check that the frequency counter reading is 2960Hz ~3070Hz . If the reading is out of this range, adjust the variable resistor in the motor hausing .</p> <p>③ Wow &Flutter should be less than 0.35%(JIS UNWTD)</p>	<ul style="list-style-type: none"> • Tape speed : 2960Hz ~3070Hz <p>Wow &Flutter : Less than 0.35%(JIS UNWTD)</p>	Variable resistor in the motor hausing .
Play back output level checking	<ul style="list-style-type: none"> • Tast tape : VTT724 (1kHz) • Output terminal for measurement : Headphone 	<p>① When Playback the test tape VTT724 (1kHz) , the output level at headphone is $-24dB \pm 3dB$ at 1kHz.</p> <p>② Deviation L and R : less than 3dB</p>	$-24dB \pm 3dB$	
Playback frequency response checking	<ul style="list-style-type: none"> • Tast tape : VTT739 • Output terminal for measurement : Headphone 	When playback the test tape VTT739, response should be $-3dB \pm 4dB$ at 63Hz and 1kHz, $\pm 0dB \pm 4dB$ at 10kHz and 1kHz with respect to 1kHz.	<ul style="list-style-type: none"> 63Hz and 1kHz : $-3dB \pm 4dB$ 10kHz and 1kHz $\pm 0dB \pm 4dB$ 	
Record / playback frequency response adjustment	<ul style="list-style-type: none"> • Reference frequency : 1kHz, 10kHz (Ref. $-20dB$) • Test tape : AC224 • Output terminal for measurement :CN301 	<p>① Record and playback the 1kHz reference frequency and 10kHz signal and check at treminal CN301.</p> <p>② Adjust the VRA41 so that record and playback frequency response with 1kHz and 10kHz at CN301 is $\pm 0dB \pm 1dB$</p> <p>③ Comfirm that the frequency counter reading is $86kHz \pm 3kHz$. If the reading is out of this range, adjust LA341.</p>	$+ 1dB \pm 1dB$ $86kHz \pm 1kHz$	VRA41 LA341
Record / playback sensitivity check	• Test tape : VTT724, AC224	While recording / playing back an input signal of the reference level (REC level), confirm that difference between the REC / PB level of the input signal and PB level of the VTT724 test tape is within $0 \pm 3dB$.	$0 \pm 3dB$	

■ Tuner section

- FM,AM IF adjustment : Since a solid IF is being used,no adjustment is required.
 MPX adjustment : Since a ceramic resonator is being used,no adjustment is required.
 FM tracking adjustment : Since a fixed coil is being used,no adjustment is required.

Item	Conditions	Adjustment&Confirmation Methods	Stand.values	Adjust
SW Tracking adjustment	<ul style="list-style-type: none"> • Band:LW • Signal input Dummy antenna • Test point :TP9 • Signal output :CN1 	<ol style="list-style-type: none"> ① Adjust L6 so that the CN1 output is maximum when 144kHz(preset 6)is received from the AM signal generator.Adjust L6 to obtain $1.1 \pm 0.02V$ at TP9. ② Adjust L5 so that the CN1 output is maximum when 144kHz(preset 6)is received from the AM signal generator ③ Adjust TC3 so that the CN1 output is maximum when 288kHz(preset 7)is received from the AM signal generator ④ Repeat the item ②,③,adjust for no further improvement. 	Output level :Maximum $1.1 \pm 0.02V$ at TP9. Output level :Maximum Output level :Maximum	L6 L5 TC3 L5,TC3
AM Tracking adjustment	<ul style="list-style-type: none"> • Band:SW • Signal input Standard loop antenna • Test point :TP9 • Signal output :CN1 	<ol style="list-style-type: none"> ① Confirm so that the CN1 output is maximum when 1629kHz(preset 2)is received from the AM signal generator. ② Incase voltage at TP9 is more than 5.0 V adjust L4 to obtain $5.0 \pm 0.1V$ at TP9. ③ Adjust L3 so that the CN1 output is maximum when 603kHz(preset 3)is received from the AM signal generator. ④ Adjust TC2 so that the CN1 output is maximum when 1404kHz(preset 4)is received from the AM signal generator. ⑤ Repeat the item ④,⑤,adjust for no further improvement. 	Output level :Maximum $5.0 \pm 0.1V$ at TP9 Output level :Maximum Output level :Maximum	L4 L3 TC2 L3,TC2

● Adjusting position of CD amplifier board






Fig. 3 - 5

■ CD player section

Item	Conditions	Adjustment & Confirmation Methods	Stand. values	Adjust
Tracking offset adjustment	<p>Test disc :CTS1000 Oscilloscope</p> <p>Note 1 Adjust VR501 so that the waveform becomes vertically symmetrical to the reference voltage value of servo.</p> <p>Note 2 The oscilloscope input should be DC – coupled.</p> <p>Note 3 VREF: Ground level on the oscilloscope.</p>	<p>① Connect TP503 (TE) and TP501 (VREF) respectively to the hot and ground sides of the oscilloscope.</p> <p>② Replay the test disc CTS1000.</p> <p>③ When TP504 and TP501 have been connected (Shorted) during replay, a tracking error signal will be emitted for about 3 sec. (Since the tracking error signal will be emitted at all times when the model with a test mode function is shifted to TEST mode, the adjustment can be performed more easily).</p> <p>④ Since the waveform of tracking error signal displayed by the oscilloscope goes up and down when VR501 has been adjusted, adjust VR501 so that the center of the waveform amplitude becomes a reference voltage value of servo(VREF).</p> <p>⑤ Repeat the steps ② ~ ④ until the center of the waveform amplitude of tracking error signal becomes the reference voltage value of servo (This step is not necessary in the case of the model with test mode function).</p>	Adjust the center of waveform amplitude to the reference voltage value of servo (VREF).	VR501




4 Wiring Connection



Color codes are shown below.

- 1 Brown
- 2 Red
- 3 Orange
- 4 Yellow
- 5 Green
- 6 Blue
- 7 Violet
- 8 Gray
- 9 White
- 0 Black
- D Pink
- C Light Blue



5 Troubleshooting

■ Pickup maintenance

(1) Checking the service life of laser diode

If a laser diode reaches the end of its service life, the following phenomena will show up. Similar symptoms may also appear when the pickup lens becomes too dirty. In this case, clean the lens.

- 1) The RF output (between TP502(RF) and TP501(VREF))
- 2) The driving current, necessary for the laser diode to emit lights, increases. (Calculate from the voltage level at both ends of the R505 at 10Ω .)

◆ Following the flow chart shown below, check the service life.




Fig. 5 – 1

◆ How to measure laser diode's driving current

After connecting a voltmeter at both ends of the R505(10Ω), measure the voltage during playback. If the voltage level is at 1.0 V or more, the service life of the laser diode has expired.

Laser diode's driving current (A)

= Voltage level at both ends of R505 (V)/ $10 (\Omega)$

When voltage level is at 1.0 V:

$$1.0 \text{ V}/10 \Omega = 0.1 \text{ A} = 100 \text{ mA}$$

Note:

The laser diode easily breaks down. Be sure to turn the power off before connecting a voltmeter.

■ Self - Diagnosis Function of CD

1. Purpose

This function is designed to display an error to readily clarify the cause of such an error should any trouble occur in CD.

2. How to Use the Function

- (1) Turn the microcomputer action of the set to [TEST] mode.
- (2) Press [POWER] + [CLEAR] on the remote control same time. Confirm that all of the LCDs have been turned on when set to the [TEST] mode subsequent to the step in item (2).
- (3) When the CD trouble has occurred after starting CD, an error code will be displayed on the display section of LCD, etc.

3. Error code and location in trouble

(See Figs. 6 – 5~6 – 9)




Fig. 5 – 2




Fig. 5 – 3




Fig. 5 – 4




Fig. 5 – 5




Fig. 5 – 6

General descriptions of TOC (Table of Contents) readings




Fig. 5 – 7

■General section




Fig. 5-8

■ Feed section




Fig. 5 - 9

■ Focus section




Fig. 5 - 10

■ Spindle motor section




Fig. 2 – 11

■ Signal processing section




Fig. 5 – 12

■ Tracking section






Fig. 5 - 13

6 Block Diagram (Integrated circuit)



■ ICA31 (AN7345K) PB/REC EQ. amp.




■ ICA33 (BA3126N) head switch




■ IC301/IC121 (BA15218N) Function/bass boost




■ IC302 (CXA1792S) tone volume




■ IC304 (TA8229K) power amp.




■ IC501 (TA8191F) servo




■ IC502 (BA6398FP) power driver



■ IC601 (TC9284BF) processor



■ IC702 (BA10324A) E. volume




■ IC701 (UPD75336GC) system microprocessor

No.	Signal name	I/O	Explanation for this signal	ACT
1		O	LCD SEGMENT	
2	S18 BUSA(01)	O	LCD SEGMENT	
3	S17 BUSA(02)	O	LCD SEGMENT	
4	S16 BUSA(03)	O	LCD SEGMENT	
5	S15 BUSA(04)	O	LCD SEGMENT	
6	S14 BUSA(05)	O	LCD SEGMENT	
7	S13 BUSA(06)	O	LCD SEGMENT	
8	S12 BUSA(07)	O	LCD SEGMENT	
9	S11 BUSA(08)	O	LCD SEGMENT	
10	S10 BUSA(09)	O	LCD SEGMENT	
11	S9 BUSA(10)	O	LCD SEGMENT	
12	S8 BUSA(11)	O	LCD SEGMENT	
13	S7 BUSA(12)	O	LCD SEGMENT	
14	S6 BUSA(13)	O	LCD SEGMENT	
15	S5 BUSA(14)	O	LCD SEGMENT	
16	S4 BUSA(15)	O	LCD SEGMENT	
17	S3 BUSA(16)	O	LCD SEGMENT	
18	S2 BUSA(17)	O	LCD SEGMENT	
19	S1 BUSA(18)	O	LCD SEGMENT	
20	BUSA(19)	O	LCD SEGMENT	
21	COM 0 BUSA(20)	O	LCD COMMON	
22	COM 1 BUSA(21)	O	LCD COMMON	
23	COM 2 BUSA(22)	O	LCD COMMON	
24	COM 3 BUSA(23)	O	LCD COMMON	
25	LCDB	O	LCD BIAS	
26	VLC 0	-		
27	VLC 1	-		
28	VLC 2	-		
29	MT 0	O	CD TRAY MOTOR CONTROL 0	
30	MT 1	O	CD TRAY MOTOR CONTROL 1	
31	RECB	O	REC BIAS SWITCH	H
32	R/P	O	REC CTL SWITCH	H
33	Vss	-	GND	
34	FTU	O	FUNCTION TUNER SWITCH	L
35	PBM	O	PLAYBACK MUTE	H
36	SMUTE	O	SYSTEM MUTE	L
37	FCD	O	FUNCTION CD SWITCH	L
38	PIN	I	[POWER]KEY INPUT	L
39	SCK	O	SERIAL CLOCK	
40	SDATA	I/O	SERIAL DATA	
41	REC L	I	{REC}SW IN	
42	REM	I	REMOCON IN	
43	WAKE UP	I	WAKW UP SWITCH	L
44	AC/DC	I	AC/DC	L
45	MPX	I	TUNER MPX	L
46	TUST	O	TUNER STROBE	H
47	A/B	O	TAPE A/B CONTROL	H
48	BIAS 1	O	REC BIAS CONTROL 1	H
49	BIAS 2	O	REC BIAS CONTROL 2	H
50	SCD	O	CD SAFETY	H
51	XRST	O	CD LSI RESET	L
52	BUCK	O	CD BUS CLOCK	
53	CCE	O	CD DATA CCE	L
54	BUS 0	I/O	CD DATA BUS 0	
55	BUS 1	I/O	CD DATA BUS 1	
56	BUS 2	I/O	CD DATA BUS 2	
57	BUS 3	I/O	CD DATA BUS 3	
58	BATT	I	BATTERY	
59	SAFETY	I	CD REG SAFETY	
60	DOOR SW	I	CD OPEN / CLOSE / REST SWITCH	
61	KEY 3	I	A PLAY / B PLAY SWITCH	
62	KEY 1	I	TACT KEY 1 / VERSION	
63	KEY 2	I	TACT KEY 2 / VERSION	
64	AVss	-	A GND	
65	AVref	-	A Vdd	
66	Vdd	-	Vdd	
67	XT 1	I	SUB SYSTEM CLOCK	
68	XT 2	O	SUB SYSTEM CLOCK	
69	VDD	-	CONNECT Vdd	
70	OSC 2	I	SYSTEM CLOCK	
71	OSC 1	O	SYSTEM CLOCK	
72	RESET	I	RESET	
73	BEAT	O	MAIN CLOCK SHIFT	L
74	+BCTL	O	A Vref SWITCH	H
75	B.UP	I	BACK UP	
76	TRE	O	PWM	
77	BASS	O	PWM	
78	VOL	O	PWM	
79	MBH	O	BASS SWITCH	H
80	POUT	O	POWER SWITCH	H


■ PC-X103 system diagram

(KEY1) VOL+,-, BAND, ▷▷, ◀◀, SLEEP
P. TUNING, BASS, SOUND

(KEY2) ▷▷, △, □
WAKE UP
POWER




■ CD player diagram



■ PC-X103 signal circuit diagram

1 | 2 | 3 | 4 | 5




6

7

8

9


10



7 Standard Schematic Diagram

1 2 3 4 5

CD amplifier circuit



NOTES
 1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER IN PLAYBACK.
 2. UNLESS OTHERWISE SPECIFIED, RESISTORS ARE 1/8W ±5% CARBON RESISTOR.
 ALL RESISTANCE VALUES ARE IN OHMΩ.
 ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
 ALL CAPACITANCE VALUES ARE IN μF (μF=PF).
 ALL INDUCTANCE VALUES ARE IN H (mH).
 ALL E-CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (μF)/RATED VOLTAGE (V).

(1) UNFLAMMABLE CARBON RESISTOR

(2) METAL FILM RESISTOR

(3) OXIDE METAL FILM RESISTOR

(4) ±20% LOW LEAK CURRENT ELECTROLYTIC CAPACITOR

(5) NON-POLARISED ELECTROLYTIC CAPACITOR

(6) POLYPROPYLENE CAPACITOR

(7) POLYSTYROL CAPACITOR

C501	2SA952(L, K)
C501	2SA1309(R, S) OR 2SA1175IMFEI OR 2SA933S(RS)

Fig.7-1


6

7

8

9

10




L CD Anologe signal line
 R CD Digital signal line
 +B Line

■ System microprocessor circuit

To F-3 on page 61

To G-9 on page 60
(Fig 7-4)



NOTES 1. VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER
OR OSCILLOSCOPE WITHOUT INPUT SIGNAL.
CONDITION — CD MODE, VOL 2, SOUND BEAT

CONDITION — CD MODE, VOL 7, SOUND BEAT
2. UNLESS OTHERWISE SPECIFIED, RESISTORS ARE 1/4W ±5% CARBON RESISTOR.
ALL RESISTANCE VALUES ARE IN OHM(Ω).
ALL CAPACITORS ARE ELECTROLYTIC, CARDED, COIN-LIKE, CAPACITIZED.

ALL RESISTANCE VALUES ARE IN OHM.
ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
ALL CAPACITANCE VALUES ARE IN μ F(P=PF).
ALL INDUCTANCE VALUES ARE IN μ H(MESH).

ALL INDUCTANCE VALUES ARE IN μ H(MH).
ALL E-CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (AF) / RATED VOLTAGE (V).
ALL DIODES ARE 1SS254T OR HSS104TJ

3. BRACKETS INSIDE VOLTS REFERENCE DATA

- (M) METAL FILM RESISTOR
 - (MO) OXIDE METAL FILM RESISTOR
 - (C) ±20% LOW LEAK CURRENT ELECTROLYTIC CAPACITOR
 - (NP) NON-POLARISED ELECTROLYTIC CAPACITOR
 - (PP) POLYPROPYLENE CAPACITOR
 - (PS) POLYSTYRENE CAPACITOR

LOCATION	REF. NO.	VERSION	E/EN/B/G/B1	U/US-9K	U/
* 18-G	PM733	68K		10K	
* 18-B	DM722	SLR-34MCF25		←	
* 18-B	PM722	330		←	

6

7

8

9

10




Fig. 7-2

1 2 3 4 5

Tuner circuit

A

B

C

D

E

F




Fig.7-3

■ Cassette amplifier circuit




Fig.7-4

1 2 3 4 5

■ Power amplifier/power supply circuit

A

B

C


D

E

F

To A-9
on page 58

VDH7070-0058N
TO DECK SECTION



NOTES

- VOLTAGES ARE DC-MEASURED WITH A DIGITAL VOLT METER OR OSCILLOSCOPE WITHOUT INPUT SIGNAL.
- CONDITION --- CD STOP MODE AT AC SUPPLY.
- 1 IS MODE VOL+15 SOUND MODE FLAT AHB PRO:ON TO +COM SECTION VDH7071-0058V
2. UNLESS OTHERWISE SPECIFIED, RESISTORS ARE 1/8W ±5% CARBON RESISTOR.
ALL RESISTANCE VALUES ARE IN OHMS.
- ALL CAPACITORS ARE CERAMIC CAPACITOR OR MYLAR CAPACITOR.
ALL CAPACITANCE VALUES ARE IN FIFTH OF A MICROFARAD.
- ALL E CAPACITORS ARE SHOWN IN THE FORM OF CAPACITANCE (MF) RATED VOLTAGE (V).
- ALL DIODES ARE 1SS254T OR HSS104TJ.
- ALL NPN TRANSISTORS ARE 2SC2785(P-E) OR 2SC3330(S-T).

To A-2
on page 59

	AC IN	J991	POWER CORD	T991	F992	F5
J/C	120V 60Hz	QMCB251-V01	QMP1F00-183E	VTP57A2-12C	QMF51N2-3R0J1 3A/250V	
E/EN/B/G/G1	230V 50Hz	QMC0263-004	QMP39F0-183E	VTP57J2-12B	QMF51E2-2R5J1 12.5A	
B		↑	↑	QMP5520-183E	↑	


6

7

8

9

10



 Psrts are safety assurance parts.
When replacing those parts make
sure to use the specified one.


	L	Recording signal line
	R	
	L	CD Signal line
	R	
	L	Playback signal line
	R	
	L	Radio signal line
	R	
	+B Line	

Fig. 7-5

8 Location of P.C. Board Parts and Parts List

■ Main board

1 2 3 4 5



6

7

8

9

10




Fig. 8-1

Main board parts list

BLOCK NO. 01111111						BLOCK NO. 01111111					
A REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX		A REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	
C 101	QET41AM-107	E.CAPACITOR	100MF 20% 10V			C 391	QET1HM-104ZN	E.CAPACITOR	.10MF 20% 50V		
C 102	QCBBIHK-12ZY	C.CAPACITOR	120PF 10% 50V			C 392	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V		
C 103	QET41AM-22Z	E.CAPACITOR	220MF 20% 10V			C 701	QET11AM-22Z	E.CAPACITOR	220MF 20% 10V		
C 104	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 702	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V		
C 105	QETN1CM-108Z	E.CAPACITOR	OUT CUP			C 703	QEIM0JM-228	E.CAPACITOR	2200MF 20% 6.3V		
C 122	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 704	QFLC1HM-107ZM	M.CAPACITOR	.10MF 5% 50V		
C 123	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 705	QCS11HM-240	C.CAPACITOR	CLOCK		
C 124	QET41AM-476	E.CAPACITOR	OPAMP			C 706	QCS11HM-220	C.CAPACITOR	CLOCK		
C 141	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			C 707	QCS11HM-360	C.CAPACITOR	CLOCK		
C 142	QCS11HM-470	C.CAPACITOR	4.7PF 5% 50V			C 708	QCS11HM-202Y	C.CAPACITOR	CLOCK		
C 143	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			C 709	QCBBIHK-102Y	C.CAPACITOR	CLOCK		
C 144	QET41HM-152ZM	M.CAPACITOR	.015MF 5% 50V			C 710	QETC1HM-222ZN	E.CAPACITOR	2.2MF 20% 50V		
C 151	QCBBIHK-68ZY	C.CAPACITOR	680PF 10% 50V			C 712	QCVB1CM-103Y	C.CAPACITOR	XT2		
C 152	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V			C 715	QCVB1CM-103Y	C.CAPACITOR			
C 161	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V			C 716	QETC1HM-225ZN	E.CAPACITOR	RESET		
C 163	QFLB1HK-821	M.CAPACITOR	820PF 5% 50V			C 717	QCVB1CM-103Y	C.CAPACITOR			
C 192	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V			C 721	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 194	QET41AM-476	E.CAPACITOR	4.7MF 20% 10V			C 722	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 195	QFLC1HM-822ZM	M.CAPACITOR	8200PF 5% 50V			C 723	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 201	QET41AM-107	E.CAPACITOR	100MF 20% 10V			C 724	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 202	QCBBIHK-12ZY	C.CAPACITOR	120PF 10% 50V			C 725	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 203	QET41AM-22Z	E.CAPACITOR	220MF 20% 10V			C 726	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 204	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 727	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V		
C 205	QETN1CM-108Z	E.CAPACITOR	OUT CUP			C 734	QCBBIHK-151Y	C.CAPACITOR	150PF 10% 50V		
C 222	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 901	QET41AM-476	E.CAPACITOR	4.7MF 20% 10V		
C 223	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 902	QETC1AM-331ZN	E.CAPACITOR	330MF 20% 10V		
C 224	QET41AM-476	E.CAPACITOR	OPAMP			C 906	QET41EM-106	E.CAPACITOR	10MF 20% 25V		
C 241	QET41AM-475	E.CAPACITOR	4.7MF 20% 50V			C 911	QET41AM-476	E.CAPACITOR	4.7MF 20% 10V		
C 242	QCS11HM-470	C.CAPACITOR	4.7PF 5% 50V			C 912	QET41EM-106	E.CAPACITOR	DECAP		
C 243	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			C 914	QC20205-115	ML.C.CAPACITOR	PULSE		
C 251	QCBBIHK-152ZM	M.CAPACITOR	.015MF 5% 50V			C 915	QET41AM-227	E.CAPACITOR	P SW		
C 252	QER41EM-475VM	E.CAPACITOR	680PF 10% 50V			C 916	QCBBI1CM-103Y	C.CAPACITOR	.010MF 20% 16V		
C 263	QFLB1HK-821	M.CAPACITOR	4.7MF 20% 25V			C 917	QET11AM-476	E.CAPACITOR	4.7MF 20% 10V		
C 292	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V			C 918	QCBBI1CM-103Y	C.CAPACITOR	4.7MF 20% 10V		
C 294	QET41AM-476	E.CAPACITOR	4.7MF 20% 50V			C 919	QET11AM-477	E.CAPACITOR	4.7MF 20% 10V		
C 295	QFLC1HM-68ZY	M.CAPACITOR	8200PF 5% 50V			C 920	QCBBI1CM-103Y	C.CAPACITOR	4.7MF 20% 10V		
C 302	QET41EM-475VM	E.CAPACITOR	RF			C 921	QET11AM-476	E.CAPACITOR	4.7MF 20% 10V		
C 303	QET11EM-227	E.CAPACITOR	SW			C 922	QCBBI205-155	ML.C.CAPACITOR	1.5MF		
C 304	QET11HM-104ZN	E.CAPACITOR	.10MF 20% 50V			C 931	QET41AM-107	E.CAPACITOR	100MF 20% 10V		
C 321	QET41AM-476	E.CAPACITOR	3.3MF 20% 10V			C 932	QET11AM-337ZN	E.CAPACITOR	330MF 20% 10V		
C 322	QET11AM-336ZN	E.CAPACITOR	4.7MF 20% 10V			C 933	QET11AM-337ZN	E.CAPACITOR	330MF 20% 10V		
C 341	QET11AM-476	E.CAPACITOR	3.3MF 20% 10V			C 934	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 342	QET41AM-107	E.CAPACITOR	100MF 20% 10V			C 935	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 351	QETC1EM-226ZM	E.CAPACITOR	22MF 20% 25V			C 936	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 363	QET11EM-538	E.CAPACITOR	4.7MF 20% 10V			C 937	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 364	QET11AM-476	E.CAPACITOR	4.7MF 20% 10V			C 938	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 365	QET21HM-475	E.CAPACITOR	4.7MF 20% 50V			C 939	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 366	QET11AM-107	E.CAPACITOR	VCC			C 940	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 367	QET11AM-476	E.CAPACITOR	VG			C 941	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 368	QET11AM-476	E.CAPACITOR	VOL			C 942	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 369	QET11AM-475	E.CAPACITOR	4.7MF 20% 50V			C 943	QET11AM-477	E.CAPACITOR	330MF 20% 10V		
C 370	QET11AM-476	E.CAPACITOR	100HZ			C 944	QET11AM-477	E.CAPACITOR	330MF 20% 10V		

BLOCK NO. 01111111						BLOCK NO. 01111111					
A REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX		A REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	
C 101	QET41AM-107	E.CAPACITOR	100MF 20% 10V			C 391	QET1HM-104Z	E.CAPACITOR	.10MF 20% 50V		
C 102	QCBBIHK-12ZY	C.CAPACITOR	120PF 10% 50V			C 392	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V		
C 103	QET41AM-22Z	E.CAPACITOR	220MF 20% 10V			C 701	QET11AM-22Z	E.CAPACITOR	220MF 20% 10V		
C 104	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 702	QCVB1CM-103Y	C.CAPACITOR	.010MF 20% 16V		
C 105	QETN1CM-108Z	E.CAPACITOR	OUT CUP			C 703	QEIM0JM-228	E.CAPACITOR	2200MF 20% 6.3V		
C 122	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 704	QFLC1HM-107ZM	M.CAPACITOR	.10MF 5% 50V		
C 123	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 705	QCS11HM-240	C.CAPACITOR	CLOCK		
C 124	QET41AM-476	E.CAPACITOR	OPAMP			C 706	QCS11HM-220	C.CAPACITOR	CLOCK		
C 141	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			C 707	QCS11HM-360	C.CAPACITOR	CLOCK		
C 142	QCS11HM-470	C.CAPACITOR	4.7PF 5% 50V			C 708	QCS11HM-202Y	C.CAPACITOR	CLOCK		
C 143	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			C 709	QCBBIHK-102Y	C.CAPACITOR	CLOCK		
C 144	QET41HM-152ZM	M.CAPACITOR	.015MF 5% 50V			C 710	QETC1HM-102Y	E.CAPACITOR	2.2MF 20% 50V		
C 151	QCBBIHK-68ZY	C.CAPACITOR	680PF 10% 50V			C 712	QETC1HM-222ZN	E.CAPACITOR	2.2MF 20% 50V		
C 152	QER41EM-475VM	E.CAPACITOR	680PF 10% 50V			C 715	QCVB1CM-103Y	C.CAPACITOR	XT2		
C 161	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V			C 716	QETC1HM-225ZN	E.CAPACITOR			
C 163	QFLB1HK-821	M.CAPACITOR	820PF 5% 50V			C 717	QCVB1CM-103Y	C.CAPACITOR			
C 192	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V			C 721	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 194	QET41AM-476	E.CAPACITOR	4.7MF 20% 10V			C 722	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 195	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 723	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 201	QET41AM-107	E.CAPACITOR	100MF 20% 10V			C 724	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 202	QCBBIHK-12ZY	C.CAPACITOR	120PF 10% 50V			C 725	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 203	QET41AM-22Z	E.CAPACITOR	220MF 20% 10V			C 726	QCBBIHK-471Y	C.CAPACITOR	4.70PF 10% 50V		
C 204	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 727	QCVB1CM-103Y	C.CAPACITOR	4.70PF 10% 50V		
C 205	QETN1CM-108Z	E.CAPACITOR	OUT CUP			C 734	QCBBIHK-151Y	C.CAPACITOR	150PF 10% 50V		
C 222	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 901	QET41AM-476	E.CAPACITOR	4.7MF 20% 10V		
C 223	QFLC1HM-102ZM	M.CAPACITOR	.10MF 5% 50V			C 902	QETC1AM-331ZN	E.CAPACITOR	P SW		
C 224	QET41AM-476	E.CAPACITOR	OPAMP			C 916	QCBBI1CM-103Y	C.CAPACITOR	.010MF 20% 16V		
C 241	QET41AM-475	E.CAPACITOR	4.7MF 20% 50V			C 917	QET11AM-476	E.CAPACITOR	4.7MF 20% 10V		
C 242	QCS11HM-470	C.CAPACITOR	4.7PF 5% 50V			C 918	QET11AM-476	E.CAPACITOR	4.7MF 20% 10V		
C 243	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			C 919	QET11AM-477	E.CAPACITOR	4.7MF 20% 10V		
C 251	QCBBIHK-152ZM	M.CAPACITOR	.015MF 5% 50V			C 920	QCBBI1CM-103Y	C.CAPACITOR	100MF 20% 10V		
C 252	QER41EM-475VM	E.CAPACITOR	680PF 10% 50V			C 921	QET11AM-476	E.CAPACITOR	4.7MF 20% 10V		
C 263	QFLB1HK-821	M.CAPACITOR	4.7MF 20% 25V			C 922	QCBBI1CM-103Y	C.CAPACITOR	4.7MF 20% 10V		
C 292	QER41EM-475VM	E.CAPACITOR	4.7MF 20% 25V			C 923	QET11AM-475	E.CAPACITOR	1.0MF 20% 50V		
C 294	QET41AM-476	E.CAPACITOR	4.7MF 20% 50V			C 924	QCBBI1CM-221Y	C.CAPACITOR	220PF 10% 50V		

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
CA206	QCB81HK-151Y	C.CAPACITOR	150PF 10% 50V			DI701	VGL196-001	LCD			
CA209	QCB81HK-221Y	C.CAPACITOR	220PF 10% 50V			ICA31	AN345K	IC	PB/REC AMP		
CA221	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			ICA33	BA3126N	IC	HEAD SW		
CA226	QCY1HK-352	C.CAPACITOR	3300PF 10% 50V			IC121	BA15218N	IC	BASS BOOST		
CA227	QETC1EM-226ZN	E.CAPACITOR	22MF 20% 25V			IC301	CA172S	IC			
CA230	QFLC1HK-832M	M.CAPACITOR	.082MF 5% 50V			IC302	TA180SD08BP	IC	TONE VOL		
CA232	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			IC304	TA8229K	IC	POWER AMP		
CA233	QCB81HK-221Y	C.CAPACITOR	220PF 10% 50V			IC305	TA80SD06BP	IC			
CA234	QFLC1HK-2232M	M.CAPACITOR	.022MF 5% 50V			IC701	UPD53366C-169	IC			
CA241	QCS11HJ-351J	C.CAPACITOR	330PF 5% 50V			IC702	BA10324	IC			
CA301	QETC1AM-476	E.CAPACITOR	.47MF 20% 10V			J 301	VM14024-001	JACK	HP JACK		
CA302	QETC1EM-226ZN	E.CAPACITOR	22MF 20% 25V			J 303	FMMJ4001-001	SPK TERMINAL	SPK TERM.		
CA303	QETC1EM-226ZN	E.CAPACITOR	22MF 20% 25V			K 701	VQ20048-009	INDUCTOR	INDUCTOR		
CA304	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			K 702	VQ20048-009	INDUCTOR	INDUCTOR		
CA305	QETC1EM-352ZN	E.CAPACITOR	3.3MF 20% 50V			L 701	VQPD033-100Z	INDUCTOR			
CA315	QETC1CM-107	E.CAPACITOR	100MF 20% 16V			L 703	VQPD033-100Z	INDUCTOR			
CA322	QFLC1HK-3932M	M.CAPACITOR	.039MF 5% 50V			LA341	VQH1009-026	OSC COIL			
CA323	QET41AM-227	E.CAPACITOR	220MF 20% 10V			LA371	VAP0028-002	INDUCTOR			
CA341	QETC1AM-106	E.CAPACITOR	10MF 20% 25V			PP 11	VM20015-005	POST PIN			
CA342	QFLC1HK-2232M	M.CAPACITOR	.022MF 5% 50V			Q 153	KTC3203(CY)-T	TRANSISTOR			
CA345	QFPB1HJ-562	PP CAPACITOR	.018MF 5% 50V			Q 191	ZSC2285	TRANSISTOR			
CA349	QCUB1CM-103Y	C.CAPACITOR	.010MF 20% 16V			Q 253	KTC3203(CY)-T	TRANSISTOR			
CA350	QCUB1CM-103Y	C.CAPACITOR	.010MF 20% 16V			Q 291	KRA102M-T	D.TRANSISTOR			
CA351	QCS11HJ-561	C.CAPACITOR	BIAS1			Q 391	DTC115ES	TRANSISTOR			
CA352	QFPB1HJ-592	PP CAPACITOR	BIAS2			Q 701	ZSC2289	TRANSISTER			
CM701	QCB81CM-103Y	C.CAPACITOR	.010MF 20% 16V			Q 702	ZSC2289	TRANSISTER			
CM702	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V			Q 703	KTA1267(G)-T	TRANSISTOR			
CM703	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V			Q 704	ZSC2285	TRANSISTOR			
CM704	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V			Q 705	KRC111M-T	TRANSISTOR			
CNA32	VMCO00-005Z	CONNECTOR	TO R/P HEAD			Q 901	ZSC22785	TRANSISTOR			
CNA33	VMCO00-009Z	CONNECTOR	TO MECHA SW			Q 902	KRA107M-T	D.TRANSISTOR			
CN301	VMCO041-004	CONNECTOR	TEST POINT			Q 911	ZSD082(P-Q)	TRANSISTOR			
CN302	VMCO163-R07	CONNECTOR	CD			Q 914	ZSC22785	TRANSISTOR			
CN701	VMCO163-011	CONNECTOR	MICOM-CONT			Q 915	ZSA052(L-K)	TRANSISTOR			
CN703	VMCO192-S06	CONNECTOR	MICOM-CNT			Q 916	ZSC2785	TRANSISTOR	POWER SW		
CN711	VMCO163-R09	CONNECTOR	TO TUNER			Q 931	ZSD0882(P-Q)	TRANSISTOR	CD REG		
CN716	VMCO163-R09	CONNECTOR	TO CD			Q 932	KRA107M-T	D.TRANSISTOR	REC MUTE		
CN718	VMCO163-R07	CONNECTOR	TO CDRAY(103,6			Q 934	ZSC2785	TRANSISTOR	R MUTE DRIVE		
D 321	MT24.3JB	ZENER DIODE	ZENER DIODE			QA344	ZSC2785	TRANSISTOR			
D 361	MT25.1JC	ZENER DIODE	SI DIODE			QA345	ZSC2785	TRANSISTOR			
D 392	ISS133	SI DIODE	ZENER DIODE			QA346	ZSC2785	TRANSISTOR			
D 393	ISS133	SI DIODE	SI DIODE			R 101	QR161J-271	CARBON RESISTOR	270 5% 1/6W		
D 701	ISS133	SI DIODE	SI DIODE			R 102	QR161J-2R2	FUSI.RESISTOR	2.2 10% 1/6W		
D 702	MT25.1JAT-77	Z-DIODE	ZENER DIODE			R 103	QR161J-221	CARBON RESISTOR	HP LEVEL		
D 703	ISS133	SI DIODE	SI DIODE			R 121	GRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W		
D 711	ISS133	SI DIODE	ZENER DIODE			R 122	GRD161J-224	CARBON RESISTOR	220K 5% 1/6W		
D 913	ISS133	SI DIODE	SI DIODE			R 123	GRD161J-183	CARBON RESISTOR	OPAMP		
D 914	ISSR5-100	SI DIODE	SI DIODE			R 141	GRD167J-682	CARBON RESISTOR	6.8K 5% 1/6W		
D 915	MT26.2JAT-77	Z-DIODE									
D 931	MT26.8JB	ZENER DIODE									
DA301	ISS133	SI DIODE									
DA302	ISS133	SI DIODE									
DA303	ISS133	SI DIODE									

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
CA206	QCB81HK-151Y	C.CAPACITOR	150PF 10% 50V			DI701	VGL196-001	LCD			
CA209	QCB81HK-221Y	C.CAPACITOR	220PF 10% 50V			ICA31	AN345K	IC	PB/REC AMP		
CA221	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			ICA33	BA3126N	IC	HEAD SW		
CA226	QCY1HK-352	C.CAPACITOR	3300PF 10% 50V			IC121	BA15218N	IC	BASS BOOST		
CA227	QETC1EM-226ZN	E.CAPACITOR	22MF 20% 25V			IC301	CA172S	IC			
CA230	QFLC1HK-832M	M.CAPACITOR	.082MF 5% 50V			IC302	TA180SD08BP	IC	TONE VOL		
CA232	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			IC304	TA8229K	IC	POWER AMP		
CA233	QCB81HK-221Y	C.CAPACITOR	220PF 10% 50V			IC305	TA80SD06BP	IC			
CA234	QFLC1HK-2232M	M.CAPACITOR	.022MF 5% 50V			IC701	UPD53366C-169	IC			
CA241	QCS11HJ-351J	C.CAPACITOR	330PF 5% 50V			IC702	BA10324	IC			
CA301	QETC1AM-476	E.CAPACITOR	.47MF 20% 10V			J 301	VM14024-001	JACK	HP JACK		
CA302	QETC1EM-226ZN	E.CAPACITOR	22MF 20% 25V			J 303	FMMJ4001-001	SPK TERMINAL	SPK TERM.		
CA303	QETC1EM-226ZN	E.CAPACITOR	22MF 20% 25V			K 701	VQ20048-009	INDUCTOR	INDUCTOR		
CA304	QET41HM-475	E.CAPACITOR	4.7MF 20% 50V			K 702	VQ20048-009	INDUCTOR	INDUCTOR		
CA305	QETC1EM-352ZN	E.CAPACITOR	3.3MF 20% 50V			PP 11	VM20015-005	POST PIN			
CA315	QETC1CM-107	E.CAPACITOR	100MF 20% 16V			Q 153	KTC3203(CY)-T	TRANSISTOR			
CA322	QFLC1HK-3932M	M.CAPACITOR	.039MF 5% 50V			Q 191	ZSC2285	TRANSISTOR			
CA323	QET41AM-227	E.CAPACITOR	220MF 20% 10V			Q 253	KTC3203(CY)-T	TRANSISTOR			
CA341	QETC1AM-106	E.CAPACITOR	10MF 20% 25V			Q 291	KRA102M-T	D.TRANSISTOR			
CA342	QFLC1HK-2232M	M.CAPACITOR	.022MF 5% 50V			Q 391	DTC115ES	TRANSISTOR			
CA345	QFPB1HJ-562	PP CAPACITOR	BIAS0			Q 701	ZSC2289	TRANSISTER			
CA349	QCUB1CM-103Y	C.CAPACITOR	BIAS0			Q 702	ZSC2289	TRANSISTER			
CA350	QCUB1CM-103Y	C.CAPACITOR	BIAS0			Q 703	KTA1267(G)-T	TRANSISTOR			
CA351	QCS11HJ-561	C.CAPACITOR	BIAS1			Q 704	ZSC2285	TRANSISTOR			
CA352	QFPB1HJ-592	PP CAPACITOR	BIAS2			Q 705	KRC111M-T	TRANSISTOR			
CM701	QCB81CM-103Y	C.CAPACITOR	.010MF 20% 16V			Q 901	ZSC22785	TRANSISTOR			
CM702	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V			Q 902	KRA107M-T	D.TRANSISTOR			
CM703	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V			Q 911	ZSD082(P-Q)	TRANSISTOR			
CM704	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V			Q 914	ZSC22785	TRANSISTOR			
CNA32	VMCO00-005Z	CONNECTOR	TO R/P HEAD			Q 915	ZSA052(L-K)	TRANSISTOR			
CNA33	VMCO00-009Z	CONNECTOR	TO MECHA SW			Q 916	ZSC2785	TRANSISTOR	POWER SW		
CN301	VMCO041-004	CONNECTOR	TEST POINT			A 931	ZSD0882(P-Q)	TRANSISTOR	CD REG		
CN302	VMCO163-R07	CONNECTOR	CD			A 932	KRA107M-T	D.TRANSISTOR	REC MUTE		
CN701	VMCO163-011	CONNECTOR	MICOM-CONT			QA222	ZSC2785	TRANSISTOR	REC MUTE		
CN703	VMCO192-S06	CONNECTOR	MICOM-CNT			QA344	ZSC2785	TRANSISTOR	R MUTE DRIVE		
CN711	VMCO163-R09	CONNECTOR	TO TUNER			QA345	ZSC2785	TRANSISTOR			
CN716	VMCO163-R09	CONNECTOR	TO CD			QA346	ZSC2785	TRANSISTOR			
CN718	VMCO163-R07	CONNECTOR	TO CDRAY(103,6			QA347	ZSC2001(L,K)	TRANSISTOR			
D 321	MT24.3JB	ZENER DIODE	ZENER DIODE			QA348	ZSC2785	TRANSISTOR			
D 361	MT25.1JC	ZENER DIODE	SI DIODE			QA349	ZSC2785	TRANSISTOR			
D 392	ISS133	SI DIODE	ZENER DIODE			QA350	ZSC2785	TRANSISTOR			
D 393	ISS133	SI DIODE	SI DIODE			QA351	ZSC2785	TRANSISTOR			
D 701	ISS133	SI DIODE	SI DIODE			QA352	ZSC2785	TRANSISTOR			
D 702	MT25.1JAT-77	Z-DIODE	ZENER DIODE			QA353	ZSC2785	TRANSISTOR			
D 703	ISS133	SI DIODE	SI DIODE								
D 711	ISS133	SI DIODE	ZENER DIODE								
D 911	MT26.8JB	ZENER DIODE	SI DIODE								
D 913	ISS133	SI DIODE	SI DIODE								
D 914	ISSR5-100	SI DIODE	SI DIODE								
D 915	MT26.2JAT-77	Z-DIODE	Z-DIODE								
D 931	MT26.8JB	ZENER DIODE	SI DIODE								
DA301	ISS133	SI DIODE	ZENER DIODE								
DA302	ISS133	SI DIODE	SI DIODE								
DA303	ISS133	SI DIODE	SI DIODE								

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. 01111111	BLOCK NO. 01111111	SUFFIX	BLOCK NO. 01111111
R 142	QRD161J-363	CARBON RESISTOR 36K	5% 1/6W			R 370 QRD161J-102	CARBON RESISTOR 1.0K	5%	1/6W
R 143	QRD161J-393	CARBON RESISTOR 39K	5% 1/6W			R 371 QRD161J-164Y	CARBON RESISTOR 1.6K	5%	1/6W
R 152	QRD161J-753	CARBON RESISTOR 75K	5% 1/6W			R 391 QRD161J-224	CARBON RESISTOR 220K	5%	1/6W
R 154	QRD161J-562	CARBON RESISTOR 5.6K	5% 1/6W			R 392 QRD161J-105	CARBON RESISTOR 1.0M	5%	1/6W
R 155	QRD161J-183	CARBON RESISTOR 18K	5% 1/6W			R 393 QRD161J-103	CARBON RESISTOR 10K	5%	1/6W
R 158	QRD161J-183	CARBON RESISTOR 18K	5% 1/6W			R 701 QRD161J-681	CARBON RESISTOR CLOCK		
R 160	QRD161J-152	CARBON RESISTOR 1.5K	5% 1/6W			R 702 QRD161J-681	CARBON RESISTOR CLOCK		
R 161	QRD161J-123	CARBON RESISTOR 12K	5% 1/6W			R 703 QRD161J-331	CARBON RESISTOR BUP		
R 162	QRD161J-472	CARBON RESISTOR 4.7K	5% 1/6W			R 711 QRD161J-103	CARBON RESISTOR RESET		
R 163	QRD161J-332	CARBON RESISTOR 3.3K	5% 1/6W			R 712 QRD161J-103	CARBON RESISTOR RESET		
R 190	QRD161J-333	CARBON RESISTOR 33K	5% 1/6W			R 713 QRD161J-473	CARBON RESISTOR BUP		
R 191	QRD161J-273	CARBON RESISTOR 27K	5% 1/6W			R 714 QRD161J-333	CARBON RESISTOR BUP		
R 192	QRD161J-472	CARBON RESISTOR 4.7K	5% 1/6W			R 715 QRD161J-104	CARBON RESISTOR BUP		
R 193	QRD161J-393	CARBON RESISTOR 39K	5% 1/6W			R 716 QRD161J-103	CARBON RESISTOR 10K	5%	1/6W
R 194	QRD161J-224	CARBON RESISTOR 220K	5% 1/6W			R 719 QRD161J-103	CARBON RESISTOR 10K	5%	1/6W
R 197	QRD161J-102	CARBON RESISTOR 1.0K	5% 1/6W			R 720 QRD161J-102	CARBON RESISTOR BEAT		
R 198	QRD161J-562	CARBON RESISTOR 5.6K	5% 1/6W			R 721 QRD161J-103	CARBON RESISTOR MBH		
R 199	QRD161J-223	CARBON RESISTOR 22K	5% 1/6W			R 722 QRD161J-104	CARBON RESISTOR VOL		
R 201	QRD161J-271	CARBON RESISTOR 270	5% 1/6W			R 723 QRD161J-104	CARBON RESISTOR BASS		
A R 202	QRH161K-2R2	FUSI.RESISTOR	2.2 10%	1/6W		R 724 QRD161J-104	CARBON RESISTOR TRE		
R 203	QRD161J-121	CARBON RESISTOR HP LEVEL				R 725 QRD161J-222	CARBON RESISTOR BUP		
R 221	QRD161J-122	CARBON RESISTOR 1.2K	5% 1/6W			R 726 QRD161J-103	CARBON RESISTOR +BCTL		
R 222	QRD161J-224	CARBON RESISTOR 220K	5% 1/6W			R 727 QRD161J-222	CARBON RESISTOR BEAT		
R 223	QRD161J-183	CARBON RESISTOR OPAMP				R 728 QRD161J-222	CARBON RESISTOR KEY2		
R 241	QRD161J-682	CARBON RESISTOR 6.8K	5% 1/6W			R 729 QRD161J-222	CARBON RESISTOR KEY1		
R 242	QRD161J-363	CARBON RESISTOR 36K	5% 1/6W			R 730 QRD161J-222	CARBON RESISTOR KEY3(AP/BP)		
R 243	QRD161J-393	CARBON RESISTOR 39K	5% 1/6W			R 731 QRD161J-222	CARBON RESISTOR MICJ		
R 252	QRD161J-753	CARBON RESISTOR 75K	5% 1/6W			R 732 QRD161J-222	CARBON RESISTOR BATT		
R 254	QRD161J-562	CARBON RESISTOR 5.6K	5% 1/6W			R 733 QRD161J-103	CARBON RESISTOR KEY2		
R 255	QRD161J-183	CARBON RESISTOR 18K	5% 1/6W			R 734 QRD161J-103	CARBON RESISTOR KEY1		
R 258	QRD161J-183	CARBON RESISTOR 18K	5% 1/6W			R 735 QRD161J-103	CARBON RESISTOR KEY3(AP/BP)		
R 260	QRD161J-152	CARBON RESISTOR 1.5K	5% 1/6W			R 738 QRD161J-222	CARBON RESISTOR DOOR SW		
R 261	QRD161J-123	CARBON RESISTOR 12K	5% 1/6W			R 739 QRD161J-103	CARBON RESISTOR DOOR SW		
R 262	QRD161J-472	CARBON RESISTOR 4.7K	5% 1/6W			R 740 QRD161J-102	CARBON RESISTOR BUS3		
R 263	QRD161J-332	CARBON RESISTOR 3.3K	5% 1/6W			R 741 QRD161J-102	CARBON RESISTOR BUS2		
R 290	QRD161J-333	CARBON RESISTOR 33K	5% 1/6W			R 742 QRD161J-102	CARBON RESISTOR BUS1		
R 291	QRD161J-273	CARBON RESISTOR 27K	5% 1/6W			R 743 QRD161J-102	CARBON RESISTOR CCE		
R 292	QRD161J-472	CARBON RESISTOR 4.7K	5% 1/6W			R 744 QRD161J-102	CARBON RESISTOR BUCK		
R 293	QRD161J-393	CARBON RESISTOR 39K	5% 1/6W			R 745 QRD161J-102	CARBON RESISTOR XRST		
R 294	QRD161J-224	CARBON RESISTOR 220K	5% 1/6W			R 746 QRD161J-683	CARBON RESISTOR S CD		
R 298	QRD161J-562	CARBON RESISTOR 5.6K	5% 1/6W			R 747 QRD161J-473	CARBON RESISTOR REST		
R 299	QRD161J-223	CARBON RESISTOR 22K	5% 1/6W			R 750 QRD161J-102	CARBON RESISTOR BUS1		
R 321	QRD161J-101	CARBON RESISTOR OPAMP				R 752 QRD161J-102	CARBON RESISTOR BUS2		
R 341	QRD161J-103	CARBON RESISTOR 10K	5% 1/6W			R 753 QRD161J-102	CARBON RESISTOR BUS0		
R 342	QRD161J-103	CARBON RESISTOR 10K	5% 1/6W			R 754 QRD161J-102	CARBON RESISTOR CCE		
R 343	QRD161J-221	CARBON RESISTOR 220	5% 1/6W			R 755 QRD161J-102	CARBON RESISTOR BUCK		
R 363	QRD161J-274	CARBON RESISTOR 270K	5% 1/6W			R 756 QRD161J-102	CARBON RESISTOR XRST		
R 364	QRD161J-182	CARBON RESISTOR 1.8K	5% 1/6W			R 757 QRD161J-102	CARBON RESISTOR S CD		
R 365	QRD161J-223	CARBON RESISTOR 22K	5% 1/6W			R 758 QRD161J-222	CARBON RESISTOR BIAS2		
R 366	QRD161J-223	CARBON RESISTOR 1.2K	5% 1/6W			R 759 QRD161J-222	CARBON RESISTOR BIAS1		
R 367	QRD161J-122	CARBON RESISTOR 1.8K	5% 1/6W			R 760 QRD161J-103	CARBON RESISTOR F TUNER		
R 368	QRD161J-182	CARBON RESISTOR 100	5% 1/6W			R 761 QRD161J-103	CARBON RESISTOR TUST		
R 369	QRD161J-101	CARBON RESISTOR				R 762 QRD161J-103	CARBON RESISTOR MPX		

BLOCK NO. 01111111				BLOCK NO. 01111111			
REF.	PARTS NO.	PARTS NAME	REMARKS	REF.	PARTS NO.	PARTS NAME	REMARKS
			SUFFIX				SUFFIX
R 763	GRD161J-473	CARBON RESISTOR AC/DC		RA130	GRD161J-272	CARBON RESISTOR	2.7K 5% 1/6W
R 764	GRD161J-103	CARBON RESISTOR WAKEUP		RA131	GRD161J-332	CARBON RESISTOR	3.3K 5% 1/6W
R 765	GRD161J-222	CARBON RESISTOR REMCON		RA132	GRD161J-273	CARBON RESISTOR	27K 5% 1/6W
R 766	GRD161J-222	CARBON RESISTOR RECL		RA133	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R 767	GRD161J-223	CARBON RESISTOR SDATA		RA141	GRD161J-272	CARBON RESISTOR	2.7K 5% 1/6W
R 769	GRD161J-102	CARBON RESISTOR SDATA2		RA203	GRD161J-220	CARBON RESISTOR	22.5% 1/6W
R 770	GRD161J-102	CARBON RESISTOR SCK		RA204	GRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W
R 772	GRD161J-222	CARBON RESISTOR PIN		RA206	GRD161J-223	CARBON RESISTOR	22K 5% 1/6W
R 773	GRD161J-222	CARBON RESISTOR A/B		RA207	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W
R 776	GRD167J-562	CARBON RESISTOR RECH		RA221	GRD161J-183	CARBON RESISTOR	18K 5% 1/6W
R 777	GRD161J-103	CARBON RESISTOR REC8		RA225	GRD161J-560	CARBON RESISTOR	5.6% 1/6W
R 778	GRD161J-103	CARBON RESISTOR MT1		RA226	GRD161J-681	CARBON RESISTOR	680 5% 1/6W
R 779	GRD161J-103	CARBON RESISTOR MTO		RA228	GRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W
R 780	GRD161J-222	CARBON RESISTOR F CD		RA230	GRD161J-272	CARBON RESISTOR	2.7K 5% 1/6W
R 781	GRD161J-223	CARBON RESISTOR SMUTE		RA231	GRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W
R 782	GRD161J-222	CARBON RESISTOR PBM		RA232	GRD161J-273	CARBON RESISTOR	27K 5% 1/6W
R 783	GRD161J-222	CARBON RESISTOR A/B		RA241	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R 784	GRD161J-222	CARBON RESISTOR REC H		RA241	GRD161J-272	CARBON RESISTOR	2.7K 5% 1/6W
R 785	GRD161J-222	CARBON RESISTOR REC B		RA301	GRD161J-101	CARBON RESISTOR	100 5% 1/6W
R 786	GRD161J-222	CARBON RESISTOR MT11C1CD1BIS2(3C)		RA305	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R 787	GRD161J-222	CARBON RESISTOR MTO		RA315	GRD161J-221	CARBON RESISTOR	220 5% 1/6W
R 789	GRD161J-104	CARBON RESISTOR REC L		RA316	GRD161J-163	CARBON RESISTOR	16K 5% 1/6W
R 790	GRD161J-104	CARBON RESISTOR WAKEUP		RA321	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W
R 791	GRD161J-393	CARBON RESISTOR LCDB		RA322	GRD161J-393	CARBON RESISTOR	39K 5% 1/6W
R 792	GRD161J-104	CARBON RESISTOR VLC0		RA324	GRD161J-272	CARBON RESISTOR	2.7K 5% 1/6W
R 793	GRD161J-104	CARBON RESISTOR VLC1		RA327	GRD161J-273	CARBON RESISTOR	27K 5% 1/6W
R 794	GRD161J-104	CARBON RESISTOR VLC2		RA341	GRD14CJ-220S	CARBON RESISTOR	22 5% 1/4W
R 795	GRD161J-222	CARBON RESISTOR PBM		RA342	GRD161J-151	CARBON RESISTOR	150 5% 1/6W
R 796	GRD161J-183	CARBON RESISTOR OPN11CD1BIS2(3C)		RA343	GRD141J-2R2	CARBON RESISTOR	2.2 5% 1/6W
R 797	GRD161J-913	CARBON RESISTOR CLS11CD1BIS1(3C)		RA344	GRD161J-682	CARBON RESISTOR	39K 5% 1/6W
R 798	GRD161J-104	CARBON RESISTOR 100K 5% 1/6W		RA346	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W
R 901	GRD161J-152	CARBON RESISTOR 1.5K 5% 1/6W		RA349	GRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W
R 902	GRD161J-101	CARBON RESISTOR XC7(121)		RA350	GRD161J-182	CARBON RESISTOR	1.8K 5% 1/6W
R 903	GRD161J-151	CARBON RESISTOR XC7(121)		RA351	GRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W
R 911	GRD161J-101	CARBON RESISTOR 100 5% 1/6W		RA352	GRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W
R 912	GRD161J-564	CARBON RESISTOR XC7(392)		RA354	GRD161J-123	CARBON RESISTOR	12K 5% 1/6W
R 914	GRD161J-103	CARBON RESISTOR 100K 5% 1/6W		RA355	GRD161J-123	CARBON RESISTOR	12K 5% 1/6W
R 915	GRD167J-562	CARBON RESISTOR 5.6K 5% 1/6W		RA361	GRD161J-474	CARBON RESISTOR	4.7K 5% 1/6W
R 922	GRD161J-222	CARBON RESISTOR 2.1K 5% 1/6W		RA362	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 923	GRD167J-332	CARBON RESISTOR 3.3K 5% 1/6W		RA371	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 924	GRD161J-220	CARBON RESISTOR 22.5% 1/6W		RM701	GRD161J-103	CARBON RESISTOR	100 5% 1/6W
R 929	GR20077-4R7X	FUSE RESISTOR 4.7 1/0W		RM702	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 931	GRD161J-1R0	CARBON RESISTOR 1.0 5% 1/6W		RM703	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 932	GRD161J-101	CARBON RESISTOR 100 5% 1/6W		RM704	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W
R 933	GRD161J-122	CARBON RESISTOR 1.2K 5% 1/6W		RM705	GRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W
R 934	GRD161J-473	CARBON RESISTOR (-P908)		RM706	GRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W
RA103	GRD161J-220	CARBON RESISTOR 22.5% 1/6W		RM707	GRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W
RA104	GRD161J-392	CARBON RESISTOR 3.3K 5% 1/6W		RM751	GRD161J-273	CARBON RESISTOR	BATT-KKC7=303
RA105	GRD161J-223	CARBON RESISTOR 22K 5% 1/6W		RM752	GRD161J-183	CARBON RESISTOR	BATT+KKC7=563
RA107	GRD161J-104	CARBON RESISTOR 100K 5% 1/6W		RM791	GRD161J-102	CARBON RESISTOR	SCK2
RA121	GRD161J-183	CARBON RESISTOR 18K 5% 1/6W		RM792	GRD161J-102	CARBON RESISTOR	SDATA2
RA126	GRD161J-681	CARBON RESISTOR 56 5% 1/6W		VRA41	QVPA603-202M	SEMI-V. RESISTOR	BIAS ADJ
RA128	GRD167J-562	CARBON RESISTOR 680 5% 1/6W		M224.19		CERA LOCK	
					X 701		

BLOCK NO. 01111111			
REF.	PARTS NO.	PARTS NAME	REMARKS
R 763	GRD161J-473	CARBON RESISTOR AC/DC	
R 764	GRD161J-103	CARBON RESISTOR WAKEUP	
R 765	GRD161J-222	CARBON RESISTOR REMCON	
R 766	GRD161J-222	CARBON RESISTOR RECL	
R 767	GRD161J-223	CARBON RESISTOR SDATA	
R 769	GRD161J-102	CARBON RESISTOR SCK	
R 770	GRD161J-102	CARBON RESISTOR PIN	
R 772	GRD161J-222	CARBON RESISTOR A/B	
R 773	GRD161J-222	CARBON RESISTOR RECH	
R 776	GRD167J-562	CARBON RESISTOR RECB	
R 777	GRD161J-103	CARBON RESISTOR MT1	
R 778	GRD161J-103	CARBON RESISTOR MTO	
R 781	GRD161J-223	CARBON RESISTOR SMUTE	
R 782	GRD161J-222	CARBON RESISTOR PBM	
R 783	GRD161J-222	CARBON RESISTOR A/B	
R 784	GRD161J-222	CARBON RESISTOR REC H	
R 785	GRD161J-222	CARBON RESISTOR REC B	
R 786	GRD161J-222	CARBON RESISTOR MT11C1CD1BIS2(3C)	
R 787	GRD161J-222	CARBON RESISTOR MTO	
R 789	GRD161J-104	CARBON RESISTOR REC L	
R 790	GRD161J-104	CARBON RESISTOR WAKEUP	
R 791	GRD161J-393	CARBON RESISTOR LCDB	
R 792	GRD161J-104	CARBON RESISTOR VLC0	
R 793	GRD161J-104	CARBON RESISTOR VLC1	
R 794	GRD161J-104	CARBON RESISTOR VLC2	
R 795	GRD161J-222	CARBON RESISTOR PBM	
R 796	GRD161J-183	CARBON RESISTOR OPN11CD1BIS2(3C)	
R 797	GRD161J-913	CARBON RESISTOR CLS11CD1BIS1(3C)	
R 798	GRD161J-104	CARBON RESISTOR 100K 5% 1/6W	
R 901	GRD161J-152	CARBON RESISTOR 1.5K 5% 1/6W	
R 902	GRD161J-101	CARBON RESISTOR XC7(121)	
R 903	GRD161J-151	CARBON RESISTOR XC7(121)	
R 911	GRD161J-101	CARBON RESISTOR 100 5% 1/6W	
R 912	GRD161J-564	CARBON RESISTOR XC7(392)	
R 914	GRD161J-103	CARBON RESISTOR 100K 5% 1/6W	
R 915	GRD167J-562	CARBON RESISTOR 5.6K 5% 1/6W	
R 922	GRD161J-222	CARBON RESISTOR 2.1K 5% 1/6W	
R 923	GRD167J-332	CARBON RESISTOR 3.3K 5% 1/6W	
R 924	GRD161J-220	CARBON RESISTOR 22.5% 1/6W	
R 929	GR20077-4R7X	FUSE RESISTOR 4.7 1/0W	
R 931	GRD161J-1R0	CARBON RESISTOR 1.0 5% 1/6W	
R 932	GRD161J-101	CARBON RESISTOR 100 5% 1/6W	
R 933	GRD161J-122	CARBON RESISTOR 1.2K 5% 1/6W	
R 934	GRD161J-473	CARBON RESISTOR (-P908)	
RA103	GRD161J-220	CARBON RESISTOR 22.5% 1/6W	
RA104	GRD161J-392	CARBON RESISTOR 3.3K 5% 1/6W	
RA105	GRD161J-223	CARBON RESISTOR 22K 5% 1/6W	
RA107	GRD161J-104	CARBON RESISTOR 100K 5% 1/6W	
RA121	GRD161J-183	CARBON RESISTOR 18K 5% 1/6W	
RA126	GRD161J-681	CARBON RESISTOR 56 5% 1/6W	
RA128	GRD167J-562	CARBON RESISTOR 680 5% 1/6W	

■ Switch board


1

2

3

4

5

**◆ Power supply**

6

7

8

9

10




Fig. 8 - 2

● Switch board parts list

A REF.	PARTS NO.	PARTS NAME	REMARKS	BLOCK NO. [021111]	SUFFIX
C 718	QET41CM-476	E.CAPACITOR	4.7MF, 20% 16V		
C 991	QCF11HP-223	C.CAPACITOR	.022MF +100:-0%		
C 992	QCF11HP-223	C.CAPACITOR	.022MF +100:-0%		
C 993	QCF11HP-223	C.CAPACITOR	.022MF +100:-0%		
C 994	QCF11HP-223	C.CAPACITOR	.022MF +100:-0%		
CN702	VMCO163-011	CONNECTOR	MICOM-CONT		
CN704	VMCO192-P06	CONNECTOR	MICOM-CONT		
CN991	VMCO41-004	CONNECTOR	SUPPLY-MAIN		
CN994	EMV5137-002	CONNECTOR	PRI SEC		
CN995	VMZ0049-A02	CONNECTOR			
A D 991	1N5401TM	SI DIODE			
A D 992	1N5401TM	SI DIODE			
A D 993	1N5401TM	SI DIODE			
A D 994	1N5401TM	SI DIODE			
A D 995	1N5401TM	SI DIODE			
DM721	SLR-3AVCF25	LED	MBH(RED)		
DM722	SLR-34MCF25	LED	POWER(RED)		
DM723	SLR-3AVCF25	LED	STANDBY(RED)		
IC711	GP1U271X	RM RECEIVER			
J 991	QMC063-004BS	AC SOCKET			
J 992	QMA431B-V01	FILM CAPACITOR			
PP 1	VMZ0015-005	POST PIN			
PP 2	VMZ0015-005	POST PIN			
Q 706	KRA113M-T	TRANSISTOR	IND.-CONT		
R 991	QRD161J-103	CARBON RESISTOR	AC IN		
RM721	QRD161J-221	CARBON RESISTOR	MBH		
RM722	QRD161J-331	CARBON RESISTOR	POWER		
RM723	QRD161J-331	CARBON RESISTOR	POWER		
RM725	QRD161J-102	CARBON RESISTOR	MICOM-CONT		
RM726	QRD161J-102	CARBON RESISTOR	AC IN		
RM727	QRD161J-122	CARBON RESISTOR	1.2K 5% 1/6W		
RM728	QRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W		
RM729	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W		
RM730	QRD161J-272	CARBON RESISTOR	330 5% 1/6W		
RM731	QRD161J-392	CARBON RESISTOR	1.2K 5% 1/6W		
RM732	QRD167J-562	CARBON RESISTOR	68K 5% 1/6W		
RM733	QRD167J-683	CARBON RESISTOR	68K 5% 1/6W		
RM771	QRD167J-332	CARBON RESISTOR	EJECT(1CD)		
RM772	QRD167J-682	CARBON RESISTOR	PLAY(1CD)		
RM773	QRD161J-392	CARBON RESISTOR	STOP(1CD)		
S 701	QSQ4H11-V10Z	TACT SWITCH	POWER		
S 702	QSQ4H11-V10Z	TACT SWITCH	SLEEP		
S 703	QSQ4H11-V10Z	TACT SWITCH	VOL+		
S 704	QSQ4H11-V10Z	TACT SWITCH	VOL-		
S 705	QSQ4H11-V10Z	TACT SWITCH	BAND		
S 706	QSQ4H11-V10Z	TACT SWITCH	REV SKIP		
S 707	QSQ4H11-V10Z	TACT SWITCH	FOR SKIP		
S 708	QSQ4H11-V10Z	TACT SWITCH	SLEEP		
S 709	QSQ4H11-V10Z	TACT SWITCH	WAKE UP		
S 710	QSQ4H11-V10Z	TACT SWITCH	RESET		
S 711	QSQ4H11-V10Z	TACT SWITCH	MBH		
S 718	QSQ4H11-V10Z	TACT SWITCH	SOUND		
S 721	QSQ4H11-V10Z	TACT SWITCH	EJECT(1CD)PLAY(3C)		
S 722	QSQ4H11-V10Z	TACT SWITCH	RANDOM REPEAT		

■ Tuner board




Fig. 8-3

● Tuner board parts list

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	BLOCK NO. ③ ④ ⑤ ⑥ ⑦	BLOCK NO. ③ ④ ⑤ ⑥ ⑦	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
BP 1	VBP4M3B-007Z	P FILTER	BPF		L 3	VQB008B-503	BAR ANTENA	MW/LW RF			
C 3	GCSB1HK-5R6Y	C.CAPACITOR	5-6PF 10% 50V		L 4	VQM7U02-404	OSC COIL(MW)	MW OSC			
C 6	GCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		L 5	VQM7U02-502	OSC COIL(LW)	LW OSC			
C 7	GCS11HJ-200	C.CAPACITOR	2QPF 5% 50V		L 6	VQP0018-221	INDUCTOR				
C 9	GCS11HJ-120	C.CAPACITOR	12PF 5% 50V		L 12	VQ3047-16	RF COIL				
C 13	GCC11EH-223V	C.CAPACITOR	.022MF 20% 25V		Q 2	ZSC1923	TRANSISTOR	LW			
C 16	GCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		Q 3	ZSC1923	TRANSISTOR				
C 21	QET41EM-73V	C.CAPACITOR	.047MF 20% 25V		Q 4	ZSA1175	TRANSISTOR				
C 22	QFP41HJ-431	PP.CAPACITOR	4.30PF 5% 50V		Q 5	ZSC1923	TRANSISTOR				
C 23	QCT30CH-120Y	C.CAPACITOR	12PF 5% 50V		Q 6	ZSC1923	TRANSISTOR				
C 24	GCSB1HJ-620Y	E.CAPACITOR	62PF 5% 50V		Q 14	DTA114S	TRANSISTOR				
C 25	GET41HM-104Z	E.CAPACITOR	.10MF 20% 50V		R 1	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W			
C 26	GP31HJ-1812M	PP.CAPACITOR	180PF 5% 50V		R 2	GRD161J-473	CARBON RESISTOR	47K 5% 1/6W			
C 27	QCS11HJ-101	C.CAPACITOR	100PF 5% 50V		R 3	GRD161J-4R7	CARBON RESISTOR	4.7 5% 1/6W			
C 28	QCS11HJ-150	C.CAPACITOR	15PF 5% 50V		R 7	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W			
C 31	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		R 9	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W			
C 32	GCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		R 12	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W			
C 33	QET41AN-107	E.CAPACITOR	.10MF 20% 10V		R 13	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W			
C 35	GCVB1CN-103Y	C.CAPACITOR	100MF 30% 16V		R 14	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W			
C 36	QET41HM-475	E.CAPACITOR	=R19		R 15	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W			
C 37	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		R 16	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W			
C 40	QET41HM-105	E.CAPACITOR	1.0MF 20% 50V		R 17	GRD161J-104	CARBON RESISTOR	1.0K 5% 1/6W			
C 41	QET41CM-106	E.CAPACITOR	10MF 20% 10V		R 18	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W			
C 42	QCC11EM-473V	C.CAPACITOR	.010MF 30% 16V		R 19	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W			
C 43	GCVB1CN-103Y	C.CAPACITOR	.010MF 30% 16V		R 20	GRD161J-103	CARBON RESISTOR	1.0K 5% 1/6W			
C 44	QET41HM-473V	E.CAPACITOR	.010MF 20% 50V		R 21	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W			
C 45	QET41HM-474	E.CAPACITOR	.47MF 20% 50V		R 28	GRD161J-512	CARBON RESISTOR	5.1K 5% 1/6W			
C 47	QET41EM-123V	C.CAPACITOR	.012MF 20% 25V		R 30	GRD161J-104	CARBON RESISTOR	1.0K 5% 1/6W			
C 48	QCC11EM-123V	C.CAPACITOR	.012MF 20% 25V		R 31	GRD161J-123	CARBON RESISTOR	12K 5% 1/6W			
C 49	QET41HM-104N	E.CAPACITOR	.10MF 20% 50V		R 32	GRD161J-223	CARBON RESISTOR	=B121.			
C 50	QET41HM-104N	E.CAPACITOR	.010MF 20% 50V		R 33	GRD161J-101	CARBON RESISTOR	100 5% 1/6W			
C 51	QCBB1HK-681Y	C.CAPACITOR	680PF 10% 50V		R 34	GRD161J-101	CARBON RESISTOR	100 5% 1/6W			
C 52	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		R 35	GRD161J-183	CARBON RESISTOR	18K 5% 1/6W			
C 56	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		R 36	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W			
C 60	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		R 37	GRD161J-560	CARBON RESISTOR	56 5% 1/6W			
C 61	QET41AM-107	E.CAPACITOR	100MF 20% 10V		R 40	GRD161J-222	CARBON RESISTOR	E/U			
C 62	QCT30CH-120Y	C.CAPACITOR	12PF 5% 50V		R 41	GRD161J-222	CARBON RESISTOR	E/U			
C 63	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		R 44	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W			
C 64	QCT30CH-120Y	C.CAPACITOR	12PF 5% 50V		R 45	GRD161J-102	CARBON RESISTOR	E/U			
C 65	QCBB1HK-102Y	C.CAPACITOR	1000PF 10% 50V		R 46	GRD161J-103	CARBON RESISTOR	E/U			
CF 1	VCF2M3B-106	C FILTER	150PF 10% 50V		R 47	GRD161J-471	CARBON RESISTOR	470 5% 1/6W			
C 68	QCBB1HK-151Y	C.CAPACITOR	2200PF 20% 16V		R 48	GRD161J-332	CARBON RESISTOR	1.0K 5% 1/6W			
C 69	GCVB1CN-222Y	C.CAPACITOR	2.2MF 20% 50V		R 51	GRD161J-102	CARBON RESISTOR	E/U			
C 70	QET41HM-225ZN	E.CAPACITOR	3.3MF 20% 50V		R 52	GRD161J-772	CARBON RESISTOR	4.7K 5% 1/6W			
C 71	QET41HM-335Z	E.CAPACITOR	1000PF 10% 50V		R 54	GRD161J-222	CARBON RESISTOR	=B114			
D 1	SVC20SSPA-AB-AL	VARI CAP	TO MAIN		R 55	GRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W			
D 2	SVC20SSPA-AB-AL	VARI CAP			R 61	GRD161J-102	CARBON RESISTOR	=B108			
D 5	ISS153	SI DIODE			R 64	GRD161J-102	CARBON RESISTOR	I.FT			
D 6	ISS153	SI DIODE			T 2	VQT7A21-112	CARBON RESISTOR	3.3K 5% 1/6W			
CF 4	CMU2-456A05	CERA LOCK			TC 2	QAT3722-200ZM	T-CAPACITOR	MW RF			
CN 1	VMC0163-009	CONNECTOR			R 59	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W			
D 10	SVC20SSPA-AB-AL	VARI CAP			R 60	GRD161J-102	CARBON RESISTOR	B113			
D 12	DSK10C-E	DIODE			R 61	GRD161J-102	CARBON RESISTOR	TO ROD ANT			
IC 2	TA2008N	IC			TP 1	VM720015-002	POST PIN	GND			
IC 3	LC72136	OSC COIL			TP 2	VMZ0015-002	POST PIN	CRYSTAL			
L 2	VQF1820-019	RF COIL			X 1	VCX5044-001					
L 2	VQC1505-002T	FM OSC									
L 2	VQC1505-002T	FM RF									

■ CD amplifier board




Fig.8-4

● CD amplifier board parts list

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX		BLOCK NO. ④ ④ ④ ④ ④	BLOCK NO. ④ ④ ④ ④ ④
A	IC501	7A8191F	IC	SERVO LSI				
A	IC502	BA897FP	IC	POWER DRIVER				
	IC601	TC724BF	IC	1 CHIP PROCESE				
	IC604	BA15218N	IC	L.P.F				
Q	501	2SA952 (L.K)	TRANSISTOR	LASER APC				
△	Q 581	2SA1309 (RS)	TRANSISTOR	SV REGULATOR				
R	591	GRD161J-12K	TRANSISTOR	2VREF				
R	501	GRD161J-124	CARBON RESISTOR	120K 5% 1/6W				
R	502	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W				
R	504	GRD161J-202	CARBON RESISTOR	2.0K 5% 1/6W				
R	505	GRD161J-300	CARBON RESISTOR	10 5% 1/6W				
R	506	GRD161J-101	CARBON RESISTOR	100 5% 1/6W				
R	507	GRD161J-120	CARBON RESISTOR	12 5% 1/6W				
R	511	GRD161J-183	CARBON RESISTOR	18K 5% 1/6W				
R	512	GRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W				
R	513	GRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W				
R	514	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W				
R	515	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W				
R	516	GRD161J-15	CARBON RESISTOR	2.0K 5% 1/6W				
R	517	GRD161J-202	CARBON RESISTOR	2.0K 5% 1/6W				
R	518	GRD161J-335YT	CARBON RESISTOR	3.3M 5% 1/6W				
R	521	GRD161J-152	CARBON RESISTOR	150K 5% 1/6W				
R	522	GRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W				
R	523	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W				
R	524	GRD161J-331	CARBON RESISTOR	330 5% 1/6W				
R	525	GRD161J-472	CARBON RESISTOR	4.7K 5% 1/6W				
R	529	GRD167J-56	CARBON RESISTOR	5.6K 5% 1/6W				
R	531	GRD161J-73	CARBON RESISTOR	6.7K 5% 1/6W				
R	532	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W				
R	533	GRD161J-153	CARBON RESISTOR	15K 5% 1/6W				
R	541	GRD161J-123	CARBON RESISTOR	12K 5% 1/6W				
R	542	GRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W				
R	543	GRD161J-473	CARBON RESISTOR	4.7K 5% 1/6W				
R	544	GRD161J-223	CARBON RESISTOR	22K 5% 1/6W				
R	545	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W				
R	548	GRD161J-153	CARBON RESISTOR	15K 5% 1/6W				
R	549	GRD161J-821	CARBON RESISTOR	820 5% 1/6W				
R	550	GRD161J-104	CARBON RESISTOR	100K 5% 1/6W				
R	551	GRD161J-223	CARBON RESISTOR	22K 5% 1/6W				
R	562	GRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W				
R	553	GRD161J-821	CARBON RESISTOR	820 5% 1/6W				
R	555	GRD161J-392	CARBON RESISTOR	3.9K 5% 1/6W				
R	559	GRD161J-104	CARBON RESISTOR	1.2M 5% 1/6W				
R	561	GRD167J-562	CARBON RESISTOR	5.6K 5% 1/6W				
R	562	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W				
R	563	GRD161J-152	CARBON RESISTOR	1.5K 5% 1/6W				
R	564	GRD167J-332	CARBON RESISTOR	3.3K 5% 1/6W				
R	565	GRD161J-683	CARBON RESISTOR	6.8K 5% 1/6W				
R	566	GRD161J-273	CARBON RESISTOR	27K 5% 1/6W				
R	583	GRD161J-101	CARBON RESISTOR	100 5% 1/6W				
R	584	GRD161J-351	CARBON RESISTOR	330 5% 1/6W				
R	591	GRD161J-73	CARBON RESISTOR	4.7K 5% 1/6W				
R	611	GRD161J-102	CARBON RESISTOR	1.0K 5% 1/6W				
R	612	GRD161J-103	CARBON RESISTOR	10K 5% 1/6W				
R	613	GRD161J-224	CARBON RESISTOR	220K 5% 1/6W				
A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX			
C	501	QCBB1HK-821Y	C.CAPACITOR	820PF 10% 50V				
C	503	QCVCB1CN-103Y	C.CAPACITOR	1010MF 30% 16V				
C	504	QET41CM-106	E.CAPACITOR	10MF 20% 16V				
C	511	QCSB1HJ-3R9	C.CAPACITOR	3.9PF 10% 50V				
C	512	QCS31HJ-270Z	C.CAPACITOR	270F 5% 50V				
C	513	QFLC1HJ-104M	M.CAPACITOR	10NF 5% 50V				
C	514	QFLC1HJ-4722M	M.CAPACITOR	4700PF 5% 50V				
C	521	QCBB1HK-331Y	C.CAPACITOR	3301F 10% 50V				
C	522	QFLC1HJ-4732M	M.CAPACITOR	4.7MF 5% 50V				
C	523	QFVB1HJ-154	FILM CAPACITOR	1.1MF 5% 50V				
C	524	QEPC11M-4752M	N.P.E.CAPACITOR	4.7MF 20% 25V				
C	529	QETCL1AM-3337N	E.CAPACITOR	33MF 20% 10V				
C	531	QCVB11M-822Y	C.CAPACITOR	8200PF 20% 16V				
C	541	QCBB1HK-101X	C.CAPACITOR	1001F 10% 50V				
C	542	QFLC1HJ-1032M	M.CAPACITOR	1.01MF 5% 50V				
C	543	QFLC1HJ-3933M	M.CAPACITOR	0.99MF 5% 50V				
C	545	QEN61HM-1052	N.P.E.CAPACITOR	1.0MF 20% 10V				
C	546	QFLC1HJ-2232M	M.CAPACITOR	0.92MF 5% 50V				
C	561	QET41AM-476	E.CAPACITOR	4.7MF 20% 10V				
C	562	QET41HM-475	E.CAPACITOR	4.7MF 20% 10V				
C	581	QET41AM-477	E.CAPACITOR	4.7MF 20% 10V				
C	582	QEK41CM-476	E.CAPACITOR	4.7MF 20% 10V				
C	591	VCP0012-1052	C.CAPACITOR	4.7MF 20% 10V				
C	592	QCC11E-0102	C.CAPACITOR	4.7MF 20% 10V				
C	593	QCC11EM-104Y	C.CAPACITOR	4.7MF 20% 10V				
C	599	QEKG61AM-1077M	C.CAPACITOR	100MF 20% 10V				
C	601	QCS11HJ-220	C.CAPACITOR	FOR CERA LOCK				
C	602	QCS11HJ-220	C.CAPACITOR	FOR CERA LOCK				
C	603	QFV41HJ-104ZM	FILM CAPACITOR	1.0MF 5% 50V				
C	604	QCC11EM-104Y	C.CAPACITOR	1.0MF 20% 25V				
C	605	QCVCB1CN-103Y	C.CAPACITOR	100MF 30% 16V				
C	606	QCC11EM-473Y	C.CAPACITOR	0.47MF 20% 25V				
C	607	QFV41HJ-104ZM	FILM CAPACITOR	1.0MF 5% 50V				
C	608	QCC11EM-473Y	C.CAPACITOR	0.47MF 20% 25V				
C	609	QFV41HJ-104ZM	FILM CAPACITOR	0.47MF 5% 50V				
C	611	QCS11HJ-101	C.CAPACITOR	100MF 5% 50V				
C	612	QFLC1HJ-103M	M.CAPACITOR	0.10MF 5% 50V				
C	613	QFLC1HJ-103M	M.CAPACITOR	0.10MF 5% 50V				
C	614	QFLC1HJ-332M	M.CAPACITOR	3300PF 5% 50V				
C	615	QEK41CM-226	E.CAPACITOR	22MF 20% 16V				
C	616	QCC11EM-103V	C.CAPACITOR	FOR EMC				
C	617	QCS11HJ-107	E.CAPACITOR	100MF 20% 10V				
C	618	QFLC1HJ-107ZM	E.CAPACITOR	100MF 20% 10V				
C	619	QEKG61AM-1077M	E.CAPACITOR	100MF 20% 10V				
C	620	QCS11HJ-332M	E.CAPACITOR	3300PF 5% 50V				
C	621	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	622	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V				
C	623	QCBB1HK-101Y	C.CAPACITOR	27PF 5% 50V				
C	624	QCS31HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	625	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V				
C	626	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V				
C	627	QCBB1HK-101Y	C.CAPACITOR	100PF 10% 50V				
C	628	QCS31HJ-270Z	C.CAPACITOR	27PF 5% 50V				
C	629	QCS31HJ-270Z	C.CAPACITOR	27PF 5% 50V				
C	630	EMV711-115R	15F FC CONNECTOR	TO PICK UP				
CN501	EMV711-115R							
CN502	VMCO075-006							
CN503	VMCO063-R07							
CN601	VMCO163-R09							

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX		BLOCK NO. ④ ④ ④ ④ ④	BLOCK NO. ④ ④ ④ ④ ④
C	501	QCBB1HK-821Y	C.CAPACITOR	820PF 10% 50V				
C	503	QCVCB1CN-103Y	C.CAPACITOR	1010MF 30% 16V				
C	504	QET41CM-106	E.CAPACITOR	10MF 20% 16V				
C	511	QCSB1HJ-3R9	C.CAPACITOR	3.9PF 10% 50V				
C	512	QFLC1HJ-3R9	C.CAPACITOR	3.9PF 10% 50V				
C	513	QFLC1HJ-270Z	C.CAPACITOR	270F 5% 50V				
C	514	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	515	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	516	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	517	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	518	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	519	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	520	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	521	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	522	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	523	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	524	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	525	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	526	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	527	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	528	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	529	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	530	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	531	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	532	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	533	QFLC1HJ-101Y	C.CAPACITOR	100PF 10% 50V				
C	534	QFLC1HJ-101Y						

A REF.	PARTS NO.	PARTS NAME	REMARKS	BLOCK NO. 04
R 614	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 615	QRD161J-225	CARBON RESISTOR 2.2M 5% 1/6W		
R 616	QRD161J-333	CARBON RESISTOR 33K 5% 1/6W		
R 651	QRD161J-820	CARBON RESISTOR 82.5% 1/6W		
R 652	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 653	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 661	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 662	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 663	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 664	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 665	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W		
R 666	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W		
R 671	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 672	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 673	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 674	QRD161J-473	CARBON RESISTOR 47K 5% 1/6W		
R 675	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W		
R 676	QRD161J-223	CARBON RESISTOR 22K 5% 1/6W		
R 691	QRD161J-561	CARBON RESISTOR FTZ		
R 692	QRD161J-561	CARBON RESISTOR FTZ		
R 693	QRD161J-561	CARBON RESISTOR FTZ		
R 694	QRD161J-561	CARBON RESISTOR FTZ		
R 695	QRD161J-561	CARBON RESISTOR FTZ		
R 696	QRD161J-561	CARBON RESISTOR FTZ		
R 697	QRD161J-561	CARBON RESISTOR FTZ		
VR501	QV15523-154A7	V-RESTSTOR	TE OFFSET ADJ	
X 501	CSA16-93NXX0401	CERA LOCK	16.93MHZ	

A REF.	PARTS NO.	PARTS NAME	REMARKS	BLOCK NO. 05
CA371	QET41AM-227	E.CAPACITOR	220MF 20% 10V	

● Cassette mechanism electrical parts

■ CD loading (tray) motor board




Fig.8-5


● CD loading (tray) motor board parts list

BLOCK NO. 05

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 831	QEK61CM-107ZN	E.CAPACITOR	100MF 20% 16V		
CN505	VMC0163-R07	CONNECTOR	MICOM/TRAY SW		
D 812	1SR35-100	SI DIODE			
IC802	BA6208A	IC			
S 851	ESS1200-002	SWITCH			

9 Exploded View of Enclosure Assembly

1 2 3 4 5




6

7

8

9

10



● Enclosure assembly parts list

BLOCK NO. M1MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	A	ZCPRX103K-CB	C.DOR ASS'Y	NO.22,23	1		
	1	VJG1384-002	FRONT CABINET		1		
	2	PQ45130-1-1	JVC MARK		1		
	3	VXP3771-001	PUSH BUTTON(A)	POWER	1		
	4	SBSF2610Z	SCREW	F.CAB+BUTTON(A)	1		
	5	VXP3772-001	PUSH BUTTON(B)	BAND SEARCH	1		
	6	SBSF2610Z	SCREW	F.CAB+BUTTON(B)	1		
	7	VXP3757-001	PUSH BUTTON(C)	VOLUME	1		
	8	SBSF2610Z	SCREW	F.CAB+BUTTON(C)	2		
	9	VXP3770-001	PUSH BUTTON(E)	CD PLAY STOP	1		
	10	SBSF2610Z	SCREW	F.CAB+BUTTON(E)	2		
	11	VJD3991-001	LCD LENS		1		
	12	VJD2468-002	FRONT COVER		1		
	13	SBSF2610Z	SCREW	F.CAB+F.COVER	2		
	14	SBSF2610Z	SCREW	F.CAB+SW PWB	4		
	15	VYH3916-001	HOLDER		1		
	16	SBSF3010Z	SCREW	F.CAB+HOLDER	2		
	17	VJD5483-002	FOOT PLATE		2		
	21	VJG1395-102	TOP COVER		1		
	22	VJT2365-001	CASSETTE DOOR		1		
	23	VJT4230-002	DOOR LENS		1		
	24	VKW5218-001	DOOR SPRING		1		
	29	VYH7366-001MM	GEAR		1		
	31	VXP2116-001	MECHA BUTTON	REC	1		
	32	VXP2116-002	MECHA BUTTON	PLAY	1		
	33	VXP2116-003	MECHA BUTTON	REW	1		
	34	VXP2116-004	MECHA BUTTON	FF	1		
	35	VXP2116-005	MECHA BUTTON	STOP/EJECT	1		
	36	VXP2116-006	MECHA BUTTON	PAUSE	1		
	37	VYH7877-002	SHAFT		1		
	38	VYH7883-002	BUTTON LEVER		6		
	39	E65923-001	TAPPING SCREW		2		
	40	VYH2316-001	CHASSIS		1		
	41	SBSF3010Z	SCREW	TOP+CHASSIS	2		
	42	SBSF3010Z	SCREW	CHASSIS+SW PWB	3		
	51	-----	CASSETTE MECHA		1		
	52	SBSF3010Z	SCREW	TOP+MECHA	5		
	53	VJD5458-004	PLATE	MOTOP AJAST	1		
	55	SBSF3010Z	SCREW	TOP+ MAIN PWB	3		
	56	SBSF3010Z	SCREW	CHASSIS+MAIN PW	2		
	57	VKZ4001-110	WIRE CLAMP		1		
	61	VJG1385-002	REAR CABINET		1		
	62	VJH2016-001	HANDLE		1		
	63	VJC2555-001	BATTERY COVER		1		
	64	VYH5657-002	BATTERY SPRING		1		
A	65	E65923-004	TAPPING SCREW	BATT SPRING	1		
	66	VYH8075-001	PROTECTOR SHEET	FOR BATTERY	1		
	67	FMJA3001-00A(D)	ROD ANT ASS'Y	JSC VJA3001-A(C	1		
	68	SDSP3016N	SCREW	FOR ANT	1		
	69	VYSA1R4-056	SPACER		1		
	70	VYH5012-005SS	TERMINAL LUG		1		
	71	VYH8095-001	PROTECTOR SHEET	FOR BATTERY	1		
	72	SBSF3010Z	SCREW	TRANS	4		
	73	VYH3933-001	SHIELD		1		
	74	VMA4685-001	BARRIER		1		

BLOCK NO. M1MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	76	SDSF3065Z	SCREW	FRONT+REAR	6		
	77	SSSF3010M	SCREW	FRONT+HANDLE	2		
	78	SBSF3010Z	SCREW	REAR+AC SOKET	2		
	79	SBSF3010Z	SCREW	SP TERMINAL	1		
	80	VYH2303-001	CD SUPPORT	CD MECHA+REAR	1		
	81	SBSF3010Z	SCREW	CD SUPPO+REAR	3		
	82	VYH8050-001	TUNER HOLDER		1		
A	83	SBSF3014Z	SCREW	FOR T.HOLDER	2		
	84	VYN7072-M009T	NAME PLATE		1		
	86	E70891-001	CLASS 1 LABEL		1		
	87	VYH5483-001	BATTERY SPRING		1		
	88	VMZ0125-001Z	FUSE CLIP	FOR F992,F993	4		
	91	VYH3919-001	HEAT SINK		1		
	92	DPSP3010Z	SCREW	IC	2		
	93	SBSF3010Z	SCREW	POWER TRANSISTA	1		
	94	VYH8066-001	AC BRACKET		1		
	95	VMA4695-001	SHIELD	FOR POWER SUPPL	1		
	96	E406709-001	LASER CAUTION		1		
	102	VYH1238-001	LODING BASE		1		
	103	MMN-6F1LB8K	MOTOR		1		
	104	SPSK2640Z	MINI SCREW		2		
	105	E75984-221	MOTOR PULLEY		1		
	106	E75950-002	BELT		1		
	107	E75985-221SS	GEAR(1)		1		
	108	E75986-221SS	GEAR(2)		1		
	109	E75987-221SS	GEAR(3)		1		
	110	E307162-331	LEVER		1		
	111	E307252-331	CAM-PLATE		1		
	112	E65923-003	TAPPING SCREW		3		
	113	VYH7787-001	SPRING		1		
	114	SBSF3008Z	SCREW		1		
	115	E307179-332	E.BASE ASS'Y		1		
	116	E406871-001	SPRING		2		
	117	E406294-002	INSULATOR		4		
	118	E60912-005SS	SPEED NUT		1		
	119	E406293-001	SPECIAL SCREW		1		
	120	-----	CD MECHA ASS'Y		1		
	122	VYH3680-001	CLAMPER		1		
	123	VYH7315-005	PAD		1		
	124	E74897-002	MAGNET		1		
	125	GBSF2606Z	SCREW	FOR CLAMPER	1		
	126	VYH2302-001	CLAMPER BASE		1		
	127	VYH3764-401	CLAMPER PLATE		1		
	128	SBSF3010Z	SCREW	FOR CLAMPER BAS	2		
	129	VJD3995-001	TRAY FITTING		1		
	130	VYH1222-101	TRAY		1		
	131	SBSF3010Z	SCREW	FOR TRAY STOPPE	1		
	132	VMA4619-002	SHIELD CASE		1		
	133	SDSR2606Z	SCREW	FOR SHIELD CASE	2		
	134	SBSF3010Z	SCREW	FOR CD PWB	2		
A	140	VYH3911-001	LCD HOLDER		1		
A	F 992	QMF51E2-2R5J1	FUSE	2ND	1		
A	F 993	QMF51E2-2R5J1	FUSE	FOR DC	1		
A	T 991	VTP57J2-12B	POWER TRANS		1		

■ Speaker section




Fig. 9-2

● Speaker section parts list

BLOCK NO. M2MM

▲	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
S	1	VJC2556-00D	SP FRONT ASSY	RIGHT SIDE	1		
S	2	VJC2556-00C	SP FRONT ASSY	LEFT SIDE	1		
S	3	VJG1387-001	SP R.CABINET(L)	LEFT SIDE	1		
S	4	VJG1388-001	SP.R.CABINET(R)	RIGHT SIDE	1		
S	5	SBSF3050Z	SCREW	FRONT+REAR	5		
S	6	VYSH201-013	SPACER	SP.F.CABNET	1		
S	7	VGS1001-020	SPEAKER	SP01	1		
S	8	SBSF3010Z	SCREW	SPEAKER	2		
S	9	VYH8069-001	WASHER	SPEAKER	2		
S	10	VMP0132-001	SPEAKER CORD		1		
S	11	VJD5470-001	CORD HOLDER		1		
S	12	SBSF3010Z	SCREW	CORD HOLDER	1		

10 Exploded View of Mechanism Assembly

■ Cassette mechanism section

1 2 3 4 5

Block No. M1




Fig.10-1

● Cassette mechanism parts list

BLOCK NO. M3MM 1111

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
A	1921123026T	DC MOTOR ASS'Y	NO.54,64	1		
1	192114316T	BASE ASS'Y		1		
2	19211409T	SWITCH ACTUATOR		1		
3	19211438T	PUSH B.ACTUATOR		1		
4	19211422T	BUTTON LEVER	REC.	1		
5	19211484T	BUTTON LEVER	PLAY	1		
6	19211424T	BUTTON LEVER	REW	1		
7	19211425T	BUTTON LEVER	FF	1		
8	19211466T	BUTTON LEVER	STOP	1		
9	19211461T	BUTTON LEVER	PAUSE	1		
10	19211413T	P CONT. SPRING		1		
11	19211455T	PAUSE LEVER (E)		1		
12	19211412T	SPRING		1		
13	19211411T	PAUSE STOPPER		1		
14	19211414T	TORSION SPRING		1		
15	192101501ZT	CHASSIS ASS'Y		1		
16	19211416T	TORSION SPRING		1		
17	19211417T	TORSION SPRING		1		
19	19211464T	E KICK LEVER		1		
20	19211420T	STOPPER		1		
21	19211421T	TORSION SPRING		1		
22	19211415T	TORSION SPRING		1		
23	MSW-1541T	LEAF SWITCH	MSW-1541T	1		
24	18210150T	PLAY BUTTON LEV		1		
25	19210313T	HEAD PANEL		1		
26	19210304AT	HEAD BASE		1		
27	19210309T	PANEL P SPRING		1		
28	19210305T	MAGNET HEAD ARM		1		
29	18210307T	AZIMUTH SPRING		1		
30	19211418T	TORSION SPRING		1		
31	19210310T	MG ARM SPRING		1		
32	192104309T	P.ROLL. ARM ASY		1		
35	19212604TT	SENSING LEVER		1		
36	19212605T	TORSION SPRING		1		
37	192126502ZT	GEAR PLATE ASSY		1		
38	19212602T	CAM GEAR		1		
40	192107308T	RF CLUTCH ASS'Y		1		
41	18210711T	RF BELT		1		
43	192109303ZT	FLYWHEEL ASS'Y		1		
45	18211070T	F.FORWARD GEAR		1		
46	18211099T	B.T.SPRING		1		
47	192105304T	S. REEL ASS'Y		1		
48	192105303T	T. REEL ASS'Y		1		
49	19210506T	SENSOR		1		
51	19211208T	MOTOR BRACKET		1		
53	19211202T	COLLAR SCREW		2		
54	19211201T	MOTOR PULLEY		1		
55	19210924T	MAIN BELT		1		
56	19211203T	MB SCREW		1		
58	19211301T	EJ. SLIDE LEVER		1		
59	18291001T	PACK SPRING		1		
60	18211069T	REC.SAF.LEVER		1		
62	MS15R-AA2N1	R/P HEAD	MS15R-AA2N1	1		
63	PHK-MSI-6A	E HEAD	PH-K380-MS16A	1		

BLOCK NO. M3MM | | | |

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
64	60020218T	MOTOR	EG530AD-9F	1		
66	91790000T	TAPPING SCREW	M2 X 3	1		
68	96790000T	TAPPING SCREW	M2 X 5	2		
69	99991809T	SPECIAL SCREW	M2 X 4.5	3		
70	91150000T	SCREW(M2 X 3)	M2 X 3	1		
71	90040000T	SCREW(M2 X 6)	M2 X 6	1		
72	99220000T	SCREW(M2 X 7)	M2 X 7	1		
75	94220000T	P.WASHER	1.2X3.8X0.3	1		
76	99990313T	POLY.CUT WASHER	1.45X3.8X0.5	1		
77	98820000T	POLY.WASHER	2 X 3.5 X 0.4	1		
78	99990003T	POLY.WASHER	2.1 X 7 X 0.13	1		
80	19210201T	REC ARM		1		
81	19211437T	P ARM COLLAR		2		
82	64010138T	LEAF SWITCH	MSW-1275	1		
83	91800000T	SCREW	M2 X 4	1		
84	91810000T	SCREW	M2 X 5	1		
86	19211434T	P.ROLLER ARM		1		
87	640101161T	LEAF SWITCH	MSW-17820MVDO	1		
88	99992041T	SPECIAL SCREW	M2 X 3	1		

■ CD mechanism section




Fig. 10-2

● CD mechanism section parts list

BLOCK NO. M4MM

△	REF.	PARTS NO.	PARTS NAME	REMARKS	Q.TY	SUFFIX	CLR
	1	EPB-002A	MECHA BASE ASSY		1		
	2	OPTIMA-6S	OPTICAL PICK-UP		1		
	3	E406777-001	GUIDE SHAFT		1		
	4	E307746-001	CD RACK		1		
	5	SDSF2006Z	SCREW		1		
	6	EPB-003A	MECHA GEAR		1		
	7	E75807-301	TURN TABLE		1		
	9	SDSP2003N	SCREW		4		
	10	E406783-001	DC MOTOR		1		
	11	E406784-001SA	DC MOTOR ASSY		1		
	12	E75832-001	SPECIAL SCREW		1		
	13	EMW10190-001	PRINTED BOARD		1		
	14	EMV5109-006B	CONN. TERMINAL		1		
	15	ESB1100-005	LEAF SWITCH		1		
	16	E407212-001	DAMPER		1		

11 Illustration of Packing and Parts List




Fig. 11-1

● Packing parts list

BLOCK NO. M5MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
P	1	VPC7072-M001	CARTON		1		
P	2	VPH1684-001	CUSHION(U.L)		1		
P	3	VPH1684-002	CUSHION(U.C)		1		
P	4	VPH1684-003	CUSHION(U.R)		1		
P	5	VPH1684-004	CUSHION(BOTTOM)		1		
P	6	VPH1691-001	CUSHION(SP.BOT)		1		
P	7	VPK4325-001	PAD		1		
P	8	VPE3026-005	POLY BAG	SET	1		
P	9	VPK4002-025	SHEET	SET	1		
P	10	VPE3005-007	POLY BAG	INST	1		
P	11	-----	CARTON LABEL	046838061295	1		
P	12	VPE3026-006	POLY BAG	SPEAKER	2		

● Accessories

BLOCK NO. M6MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
A	1	VNN7071-261M	INSTRUCTIONS		1		
A		VNN7071-271M	INSTRUCTIONS		1		
A	6	QMP39F0-183E	POWER CORD		1		
A	7	R6PRPA-2STS	BATTERY		2		
A	8	VGR0042-301	REMO-CON UNIT	RM-RX1060	1		

PC-X103BK E/EN

JVC

VICTOR COMPANY OF JAPAN LIMITED

AUDIO PRODUCTS DIVISION 10-1, 1-chome, Ohwatari-machi, Maebashi-city, Japan

(No.1986)

 Printed in Japan
H0806-V-