

Service Manual

Multi-Scan Color CRT Display


TX-D1732 Series

Chassis No. 17HV3

Chassis Family No. HV3

MODEL No.

TX-D1732-U	TX-D1732-G
TX-D1732-SW	TX-D1732B
TX-D1732-K	TX-D1732-A
TX-D1732N	TX-D1732-J
TX-D1732NM	TX-D1732NE



CONTENTS

SAFETY PRECAUTIONS.....	1
SERVICE WARNING	2
GENERAL INFORMATION	2
SPECIFICATIONS.....	2
DIMENSIONS.....	12
DISASSEMBLY INSTRUCTIONS	14
CONTROL LOCATION.....	17
CAUTION FOR ADJUSTMENT AND REPAIR.....	18
CAUTION FOR SERVICING	18
ADJUSTMENT AND CHECK PROCEDURE	19
ADJUSTMENT PROCEDURE WITH COMPUTER.....	23
BLOCK DIAGRAM.....	39
CONDUCTOR VIEW	46
SCHEMATIC DIAGRAM.....	49
TROUBLE SHOOTING HINTS.....	60
EXPLODED VIEW.....	63
REPLACEMENT PARTS LIST	64

Panasonic

Matsushita Electric Industrial Co., Ltd.

Central P.O. Box 288, Osaka 530-91, Japan

SERVICE WARNING

TO PREVENT RISK OF ELECTRIC HAZARD, TEST BEFORE TOUCHING. Where, after operation of the fuse in the live side of the mains supply, some components of the equipment that remain under voltage might represent a hazard during servicing.

GENERAL INFORMATION

1. OUTLINE

This is a 17 inch (16"V) color FS (flat square) CRT display with cabinet which has good focus using sophisticated gun and 0.28 mm dot pitch CRT, and suitable for graphic display terminals.

Digital Control System is employed in this model, which automatically synchronizes with multi-modes.

2. FEATURES

2-1 Digital adjustment by On-Screen Display

- Adjustment is easy and speedy using four buttons on the front panel and screen menus.
- Even subtle adjustments can be easily made referring to numeric values and bars on the screen.

2-2 Power management function

- A power management circuit conforming to the VESA standard is employed so that the power consumption of the display unit can be lowered by using it in combination with a computer that meets the DPMS standard.

2-3 Low-leak flux (Static prevention)

- The display unit meets the Swedish standard MPRII on low-frequency field and low-frequency field static so it is safe to use.

2-4 Color temperature adjusting function

- The white of the image can be adjusted as desired

by individual adjustment of the red, blue signals (except for the green which is fixed).

This produces images in colors closer to the real colors in color print, etc.

- The white reference color temperature of 9300K/6550K/user color can be selected.

2-5 Digital multi-scan (11 kinds of timing stored)

- Horizontal frequencies of 30 to 64 kHz and vertical frequencies of 50 to 160 Hz can be automatically tracked. The display unit is suited to VGA, SVGA, VESA, and high-resolution video boards of 1280 (H) x 1024 (V).

- The three kinds of timing specified in the manual have already been set for image size and position in the factory.


The other eight kinds of timing can be registered by the user as desired.

2-6 DBF electron gun with hyperbolic focus compensation circuit

- The exclusive DBF electron gun with hyperbolic focus compensation circuit that controls the electron beams is combined with an invar mask to display fine images over the entire area of the 17-inch, 0.28-dot pitch, flat and square screen.

SPECIFICATION

1. DIAGRAM



3.1 POWER SW, LED, [1]-key (MENU), ▽-key (DOWN), △-key (UP), and [2]-key (ENTER) are located on the front panel.

3.2 Signal connector and AC inlet are located on the back side of the cabinet.

3.3 OSD menu includes the following function.
BRIGHTNESS, H/V SIZE, H/V POSITION, PIN-CUSHION, TRAPEZOID, DEGAUSS, PARALLELO-

GRAM, COLOR SELECT, USER COLOR, VIDEO INPUT LEVEL, DISPLAY FREQUENCY.

3.4 CONTRAST can be directly controlled with ▽/△-key.

3.5 With sync signal, OSD menu appears by pushing [1]-key.

Without sync signal, self test menu appears by pushing [1]-key.

2. MECHANICAL SPECIFICATIONS

..... refer to the attached drawing

- 2.1 Dimension Height : 422 mm (16.6") typ.
 Width : 410 mm (16.1") typ.
 Depth : 438 mm (17.2") typ.


- 2.2 Net Weight : 17.1 kg (37.6 lbs) typ.

3. CONNECTORS

- 3.1 Signal connector: 15P Mini D-Sub X 1

- 3.2 AC inlet: CEE 22 typed connector

15P Mini D-Sub Pin assignment



- | | | |
|----------------|----------------|-----------------|
| 1 ... RED | 6 ... GROUND | 11 ... GROUND |
| 2 ... GREEN | 7 ... GROUND | 12 ... - (OPEN) |
| 3 ... BLUE | 8 ... GROUND | 13 ... H.SYNC. |
| 4 ... GROUND | 9 ... - (OPEN) | 14 ... V.SYNC. |
| 5 ... - (OPEN) | 10 ... GROUND | 15 ... - (OPEN) |

4. CRT SPECIFICATIONS

Part No.	M41KXH900X
Type	17", 90°, 29ø, in-line gun
Dot Pitch	0.28 mm
Phosphor	R, G, B Short Persistence
Bulb	TINT
Face	Anti-Glare, Anti-Static Coating (AR COAT)
Total Transmission	52%

5. ELECTRICAL SPECIFICATIONS

5.1 Standard conditions ... Except special items

Display image	Green, full "H" characters with a border line. (7 x 9 dots) Video Signal: 100% duty Display area: 300 mm x 225 mm
Ambient Temperature	20±5°C (68±9°F)
Input voltage	AC120V, 60 Hz
Terrestrial magnetism	Vertical field: northern hemisphere field (40μT) Horizontal field: no field
Viewing direction	Parallel to the CRT axis
Measurements	After an initial warming up time of more than 30 minutes.
Ambient light	200 ± 50 lux


5.2 Power supply ... Commercial power source

Input voltage	AC90 - 264V
Power frequency	50/60 Hz
Input current	1.5A (Max.) at AC 100V
Inrush current (at 20°C)	40 Aop (Max.) at AC 240V
Power consumption	120W max./<30W stand-by

5.3 Standard timing

- Following total 3 modes are preset in the memory as standard timing at the factory.
- Refer to Fig. 2 as a definition of timing and signal level.
- This SPECIFICATION is specified at STD (1024 x 768) mode unless otherwise mentioned.

TIMING CHART



FOR PRESET

DOT CLOCK		MODE-3	MODE-9	MODE-12
		25.1745 MHz	40.0000 MHz	65.0000 MHz
H O R I Z	fH	31.4681 kHz	37.8788 kHz	48.3631 kHz
	A-Period	31.778 us (800 Dots)	26.400 us (1,056 Dots)	20.677 us (1,344 Dots)
	B-Blanking time	6.356 us (160 Dots)	6.400 us (256 Dots)	4.923 us (320 Dots)
	C-Sync width	3.813 us (96 Dots)	3.200 us (128 Dots)	2.092 us (136 Dots)
	D-Back porch	1.907 us (48 Dots)	2.200 us (88 Dots)	2.462 us (160 Dots)
	E-Active time	25.423 us (640 Dots)	20.000 us (800 Dots)	15.754 us (1,024 Dots)
	F-Front porch	0.636 us (16 Dots)	1.000 us (40 Dots)	0.369 us (24 Dots)
V E R T	fV	59.9393 Hz	60.3165 Hz	60.0038 Hz
	A-Period	16.684 ms (525 lines)	16.579 ms (628 lines)	16.666 ms (806 lines)
	B-Blanking time	1.431 ms (45 lines)	0.739 ms (28 lines)	0.786 ms (38 lines)
	C-Sync width	0.064 ms (2 lines)	0.106 ms (4 lines)	0.124 ms (6 lines)
	D-Back porch	1.049 ms (33 lines)	0.607 ms (23 lines)	0.600 ms (29 lines)
	E-Active time	15.254 ms (480 lines)	15.840 ms (600 lines)	15.880 ms (768 lines)
	F-Front porch	0.318 ms (10 lines)	0.026 ms (1 lines)	0.062 ms (3 lines)
Sync polarity (H/V)		Negative/Negative	Positive/Positive	Negative/Negative

DOT CLOCK				
H O R I Z	fH			
	A-Period			
	B-Blanking time			
	C-Sync width			
	D-Back porch			
	E-Active time			
	F-Front porch			
V E R T	fV			
	A-Period			
	B-Blanking time			
	C-Sync width			
	D-Back porch			
	E-Active time			
	F-Front porch			
Sync polarity (H/V)				




FOR ADJUSTMENT

DOT CLOCK		HV3-1	HV3-2	HV3-3
		22.60 MHz	40.25 MHz	64.04 MHz
H O R I Z	fH	29.50 kHz	39.00 kHz	54.00 kHz
	A-Period	33.90 us (766 Dots)	25.64 us (1,032 Dots)	18.52 us (1,186 Dots)
	B-Blanking time	6.02 us (136 Dots)	5.74 us (231 Dots)	4.51 us (288 Dots)
	C-Sync width	4.12 us (93 Dots)	2.83 us (114 Dots)	1.72 us (110 Dots)
	D-Back porch	1.28 us (29 Dots)	2.31 us (93 Dots)	2.19 us (140 Dots)
	E-Active time	27.88 us (630 Dots)	19.90 us (801 Dots)	14.01 us (897 Dots)
	F-Front porch	0.62 us (14 Dots)	0.60 us (24 Dots)	0.60 us (38 Dots)
V E R T	fV	48.00 Hz	77.10 Hz	105.00 Hz
	A-Period	20.815 ms (614 lines)	12.974 ms (506 lines)	9.519 ms (514 lines)
	B-Blanking time	0.916 ms (27 lines)	0.744 ms (29 lines)	0.482 ms (26 lines)
	C-Sync width	0.102 ms (3 lines)	0.103 ms (4 lines)	0.037 ms (2 lines)
	D-Back porch	0.712 ms (21 lines)	0.513 ms (20 lines)	0.352 ms (19 lines)
	E-Active time	19.899 ms (587 lines)	12.230 ms (477 lines)	9.038 ms (488 lines)
	F-Front porch	0.102 ms (3 lines)	0.128 ms (5 lines)	0.093 ms (5 lines)
Sync polarity (H/V)		Negative/Negative	Negative/Negative	Negative/Negative

DOT CLOCK		HV3-4	HV3-2A	HV3-4A
		86.06 MHz	40.25 MHz	86.06 MHz
H O R I Z	fH	64.52 kHz	39.00 kHz	64.52 kHz
	A-Period	15.50 us (1,334 Dots)	25.64 us (1,032 Dots)	15.50 us (1,334 Dots)
	B-Blanking time	3.60 us (309 Dots)	5.74 us (231 Dots)	3.60 us (309 Dots)
	C-Sync width	1.19 us (102 Dots)	2.83 us (114 Dots)	1.19 us (102 Dots)
	D-Back porch	1.98 us (170 Dots)	2.31 us (93 Dots)	1.98 us (170 Dots)
	E-Active time	11.90 us (1,024 Dots)	19.90 us (801 Dots)	11.90 us (1,024 Dots)
	F-Front porch	0.43 us (37 Dots)	0.60 us (24 Dots)	0.43 us (37 Dots)
V E R T	fV	165.00 Hz	77.10 Hz	165.00 Hz
	A-Period	6.060 ms (391 lines)	12.974 ms (506 lines)	6.060 ms (391 lines)
	B-Blanking time	0.465 ms (30 lines)	12.846 ms (501 lines)	5.998 ms (387 lines)
	C-Sync width	0.046 ms (3 lines)	0.103 ms (4 lines)	0.046 ms (3 lines)
	D-Back porch	0.341 ms (22 lines)	6.359 ms (248 lines)	2.976 ms (192 lines)
	E-Active time	5.596 ms (361 lines)	0.128 ms (5 lines)	0.062 ms (4 lines)
	F-Front porch	0.078 ms (5 lines)	6.384 ms (249 lines)	2.976 ms (192 lines)
Sync polarity (H/V)		Negative/Negative	Negative/Negative	Negative/Negative




DOT CLOCK				
H O R I Z	fH			
	A-Period			
	B-Blanking time			
	C-Sync width			
	D-Back porch			
	E-Active time			
	F-Front porch			
V E R T	fV			
	A-Period			
	B-Blanking time			
	C-Sync width			
	D-Back porch			
	E-Active time			
	F-Front porch			
Sync polarity (H/V)				

- 4) Remove the connector ④ of the CRT ground connected to the left and right of the shield case.
- 5) Loosen the screws ⑤ securing the CRT neck and the shield case.
- 6) Remove the PWB block from the CRT.
- 7) Remove the N382 connector ⑥.
- 8) Remove two focus leads ⑦ after pulling up the focus lead securing lever.
- 9) Remove two ground connectors ⑧ (N105 and N106) connected to the PWB.
- 10) Remove two flexible PWBs ⑨.
- 11) Remove the PWB from the shield case.



3. Main PWB Removal

- 1) Remove the ground wire ⑩ from the AC inlet.
- 2) Remove the connector ⑪ (N802) of the degauss coil.
- 3) Remove the DY connector ⑫.
- 4) Remove the anode cap.
- 5) Move the CRT face down and remove two screws ⑬ securing the bottom fitting metal.
- 6) Remove the fitting metal and the PWB from the cabinet.
- 7) Remove three screws ⑭ securing the fitting metal and the PWB.
- 8) Remove the FBT securing fitting metal ⑮.
- 9) Remove the holder ⑯ from the fitting metal with the figure referenced.
- 10) Remove the PWB from the holder with the figure referenced.




CONTROL LOCATION

Basic operation of parts

Control panel

Names of control

Functions




* For a detailed description of the functions of the [1] key, down key, up key, and [2] key, refer to the next section onward.

Examples of on-screen operation

A. Contrast adjustment


Display changes



Steps of operation


1. Press ↓ key or ↑ key to call contrast adjustment menu on the screen.
2. Set the desired state using cursor buttons ↓ and ↑. When the [2] key is pressed, the setting is stored in the memory. If the [1] key is pressed, the screen returns to the main menu without storing it.

On-screen display changes



B. H. size adjustment



Display changes




Steps of operation

1. Press [1] key to call main menu on the screen.
2. Move cursor to H. SIZE using ↓ and ↑ keys, and press [2] key to select it.

On-screen display changes




3. Adjust H. SIZE as desired using ↓ and ↑ keys. The set H. SIZE is registered in memory when [2] key is pressed. When [1] key is pressed, the screen returns to memory.




4. Press [1] key to quit main menu. The screen is now blank.

< Page 1 >



< Page 2 >



Main menu

CAUTION FOR ADJUSTMENT AND REPAIR

1. Degaussing is inevitably required at purity adjustment or convergence adjustment.
2. If you check or adjust electrical specification or function, more than 20 minutes burn-in is required.
3. Reforming of the leadwire is required after your repair work.
4. Prior to starting work, be sure check that the input signal is at the specified timing and that the polarity is as specified in all modes.
5. Brightness control: brightness tends to decrease about 5 cd/m² at the white window and about 1 cm/m² in the white raster after mounting the rear cover in position. This should be taken into consideration.
6. Brightness stabilizing time: It takes about 20 to 50 seconds for the brightness to stabilize after turning the power off for 5 seconds (AC). Therefore, care should be taken to this.
7. Aging should be made in white raster of 30 ~ 50 cd/m² and raster size, 373 x 289 mm before adjusting the ITC.
8. Contrast: When both of CONTRAST switches (UP and DOWN SW) are simultaneously pressed, the contrast increases to a maximum.
9. Brightness: When both of BRIGHT switches (UP and DOWN SW) are simultaneously pressed, the brightness lights at the center point.

CAUTION FOR SERVICING

When servicing or replacing the CRT, high voltage sometimes remains on the anode. So, completely discharge high voltage before servicing or replacing the CRT so as to prevent a shock to the serviceman.


This model has a section that does not share a common ground with the power supply section. The different sections are referred to as the HOT section and the COLD section in the precautions below.

CRT Anode Discharge

1. When you check the CRT anode or replace the CRT, discharge the CRT anode to the external conductive coating (aquadag) of CRT, especially when checked right after power turn-off.
2. Ground one end of a jumper wire which has a resistor (30kV < resisting pressure 100M Ω) and connect the other point to the CRT anode.

Note: Grounding must be done first.

1. Do not touch the HOT section and the COLD section at the same time. You may receive an electric shock.
2. Do not short the HOT section to the COLD section. This could blow the fuse or damage parts.
3. Never measure the HOT section and the COLD section at the same time when using tools such as oscilloscopes or multimeters.
4. Always unplug the unit before beginning any operation such as removing the chassis.



ADJUSTMENT AND CHECK PROCEDURE

INTRODUCTION

- This monitor is controlled by microcomputer. With the exception of a part of purity/convergence/tilt direction/focus, all is digitally adjusted. Therefore, the computer/dedicated control software/interface/12V power supply/signal generator are required for servicing.

TOOL REQUIRED

- Computer**
Control software is compatible with IBM PC. Therefore, it is suggested to use a computer which has compatibility with IBM PC.
- Control Software**
The control software uses a 3.5" floppy disk. Therefore, the HV3 chassis can only use "HV3 control program disk" and no other disk can be used on this chassis.

Interface

Just as in the case of the control software, this interface is not commercially available on the market. You are requested to obtain this interface by writing or cabling directly to our Monitor Production Sales Division.


Power Supply

A DC 9~12V (+9~12V/-9~12V) power supply is required for operating the interface.


Signal Generator

It is necessary for you to use a signal generator which operates on fh 64 KHz, fv 160 Hz, and fc 86 MHz bands.

INTERFACE CONNECTION



INTERFACE SCHEMATIC DIAGRAM



Parts No.	No. green label	with green label
IC1*	M5223	M5238P
D1*	MA162	MA27TA
D2*	MA162	MA27TA


OTHER TOOLS

- Oscilloscope (dual trace)
- Scope probe – Attenuation: 100:1
Attenuation: 10:1
- Digital Voltmeter – Range: 0 to 1000V DC
Accuracy: 0.1%
- TV color Analyzer II – that reads luminance and chromaticity X and Y coordinates.
- Digital High Voltmeter
- AC power supply – Output voltage : 0 to 300V
- Degaussing coil
- Convergence meter
- Scale
- Double-faced scale
- Microscope – Scale factor: 50
- Screwdriver – Tip width: 1/10" (2.5 mm)
One with extremely narrow tip-end
Length: 6" (15 cm)
- Screwdriver – Cross recessed head
Length: 14" (35 cm)
- Tool-for hexagon socket set screw of Deflection Yoke
- White racquer (Paint)


STANDARD CONDITION OF ADJUSTMENT PROCEDURE

- Signal timing : Standard timing 1024 x 768
(See page 5)
- Display pattern : White, full "H" character
- Signal level : V/H: TTL level video: 700mV
- Input source : AC 120V, 60 Hz
- Ambient temperature : Room temperature
- Warm-up time : More than 30 minutes
- Brightness control : Center
- Contrast control : Max.
- Magnetic field : Vertical: 40 μ T
Horizontal: 0 μ T
- Signal cable : Attached

Video input signal from PC.



- Use a Helmholtz device to adjust an unit with no horizontal magnetic field and a vertical field of 40 μ T. Inspect the unit under the same conditions.
- The ambient illuminance must be 200 lux.
- Use an external degaussing coil any time the DEGAUSS switch does not remove color shading.
- To check the image width, height, linearity and distortion, proceed as below.



Measure level with respect to tube axis.

HV3 Chassis Adjusting Program Description

- Use the PC (IBM AT or compatible) and a communications cable in combination with the control program to make communications between PC and the monitor possible. Adjustment is possible with operations from the keyboard.
- The HV dedicated program is required for control of this monitor.

Never attempt to use those for other chassis.

As an important control program, there is the

address control of memory in the monitor set.

This much varies depending upon the chassis. Therefore, if a program of other chassis is used, the operation may be rendered erratic, and parts destruction may result in an extreme case.

- Also, to operate the HV3 control program properly and correctly, use in **ENGLISH** MS-DOS environment is absolutely necessary.

Be sure to check the following points before starting the control.

1. The computer operates in **ENGLISH** MS-DOS.
2. Display is made by the program main menu <HV3 ADJUST>.

Main Menu of Control Program

<<HV3 ADJUST PROGRAM MAIN MENU>> (e: exit) <Ver *.*>	
1) Load data from FILE	6) Clear User preset
2) Adjust H.OSC freerun	7) Save data to FILE
3) Adjust VSR setting	8) Special ADJUST
4) Adjust OTHER setting	9) Information Service
5) Adjust Factory preset	10) Show Version & Error

Description of Function of Each Menu (Read the image description manual on 29~32 page also.)

1) Load Data from File

Transfer the contents of the data file of the disc to the monitor and update the contents of EEPROM forcibly.

When the data of the EEPROM is damaged for some reason or other, a return to the initial state can be made easily by using the function from the original data.

2) Adjust H. OSC Freerun

To guarantee the operation in the follow-up possible horizontal frequencies, the reference oscillation frequency can be automatically set by making the microcomputer reference it.

3) Adjust VSR Setting

To guarantee the operation in the follow-up possible horizontal frequency, the reference voltage to be referenced by the microcomputer and the distortion offset reference data should be set.

4) Adjust Other Setting

This is used to control the brightness and color.

5) Adjust Factory Preset

Makes the control at the time of preset mode, and

the microcomputer is referenced when operating the partial data in modes other than the preset mode.

6) Clear User Preset

Clear the data written in the user preset domain. Nothing is written in this domain when shipping the product from factory.

7) Save Data to File

Transfer the data of the EEPROM of the monitor set to prepare a data file in a desired file name.

8) Information Service

Displays the H/V frequencies of the signal fed to the monitor set and the operation status on the monitor set of the PC side.

10) Show Version and Error

① Return the microcomputer version to the PC model.

② If there is an error in monitor operation and the microcomputer sensing is in error, the contents of that error are returned to the PC.

Required Adjustment Items after Repair

Applicable Repair Parts	Adjustment item
CRT, DY (ITC)	Items B-R and Purity/Convergence
MAIN PCB	Items B-R
Video PCB	Items N/P/Q/R
FBT	Items C/D/E/G/H/I/J/K/L/M/N (N4/N5/N10)/P
IC902 (EEPROM)*	Items A-R
IC1302 (Video Out)	Items N/P/Q
IC1301 (Video Amp)	Items N/P/Q
IC501 (H/V Process)	Items B/F
IC301 (DAF Control)	Items G/H
IC850, Q853 (Chopper)	Items C/D
Q550 (H.Out)	Items C/D/E/I/J/K/L/M/N (N4/N5/N10)/P
IC762, Q761 (V.PCC)	Items J/K/L/M
Q586, Q587 (H.Center)	Items I
Q650 (EHT)	Items E/J (J3)/L/M/N (N4/N5/N10)
IC901 (Micro Computer)	Check Only

Note: When the EEPROM is replaced, or when a trouble leading to the destruction of the ROM data is suspected, report the serial number to the factory.*

If the data is saved at the time of shipment from factory, send the contents by facsimile.

After receiving the facsimile, write the data by the procedure given below.

The data can be returned to the state at the time of shipment from factory.

1. Load the "VER8 2.DAT" written in the program floppy disc by the editor.
2. Update the data to the facsimile contents by using the editor.
3. Save the file in the serial number name. (EXAMPLE : FF4111732 = "4111732.DAT")
4. Start the control program.
5. Select 1) Load data from file from the main menu.
6. Feed the file prepared in 3 and transfer the data to the monitor set.
7. Turn the power of the monitor set off and turn it on once again. (Reset)

FAX NUMBER

81-466-35-5922 Display Monitor Division
Sales Engineering Section

ADJUSTMENT PROCEDURE WITH COMPUTER

1. Description of Adjustment Method

























Item Program Menu	◇ Test Meter ▼ Test Point □ Pattern	JOB CODE	Input Signal	Operation	Adjusting Value
A DATA SETTING 1) Load data from FILE		A1	OFF	Turn the power on, but do not connect the signal cable.	
		A2		Press by setting the cell to the menu at left.	
		A3		A message FILE -> EEPROM FILE NAME (G or Q escape) [] is displayed. So, key in the VER8.2.DAT (when using the standard data) and press .	
		A4		Note: To make the transferred data effective, turn the power of the monitor set off once and turn it on once again.	
B H. FREE RUN 2) Adjust H. OSC freerun	□ Crosshatch	B1		Press by setting the cell to the menu shown at left.	 ↓ (Automatic adjustment)
		B2		Set the cell to the adjusting mode <u>INTP[0]</u> and press the .	
		B3	HV3-1	Check to be sure that the input signal to the monitor set is [fH 29.5kHz] and [fV 48.0Hz] and press the .	
		B4		When the screen image has stabilized, press and return the image to the screen image of B2. <The same as B2, B3, and B4 except for the adjusting mode/signal >	
		B5	HV3-2	Adjusting mode <u>INTP[1]</u> : Input signal [fH 39.0kHz] [fV 77.1Hz]	
		B6	HV3-3	Adjusting mode <u>INTP[2]</u> : Input signal [fH 54.0kHz] [fV 105.0Hz]	
		B7	HV3-4	Adjusting mode <u>INTP[3]</u> : Input signal [fH 64.5kHz] [fV 165.0Hz]	
		BE		Press to return to the main menu.	
C H. DRIVE 3) Adjust VSR setting	◇ Digital voltmeter ▼ TP503 - GND □ Crosshatch	C1		Set the cell to the menu at left and press the .	18.9 ±0.3V 17.8 ±0.3V 18.2 ±0.3V 14.0 ±0.3V
		C2		Set the cell to the adjusting mode <u>INTP[0]</u> and press the .	
		C3	HV3-1	Check to be sure that the input signal to the monitor set is at given at left [fH 29.5Hz] and [fV 48.0Hz] and press the .	
		C4		Set the cell to <u>H.DRIVE+B</u> and press the . Then, move the cell to the data side.	
		C5		Make adjustment to as shown at right using the and . Register with the after adjustment and return to the menu if C2 using the .	
				<The same as C2, C3 C4, and C5 except for the adjusting mode/signal/Adjusting value.>	
		C6	HV3-2	Adjusting mode <u>INTP[1]</u> : Input signal [fH 39.0kHz] [fV 77.1Hz]	
		C7	HV3-3	Adjusting mode <u>INTP[2]</u> : Input signal [fH 54.0kHz] [fV 105.0Hz]	
		C8	HV3-4	Adjusting mode <u>INTP[3]</u> : Input signal [fH 64.5kHz] [fV 165.0Hz]	
		CE		Press the to return to the main menu.	




















Note 1: Check to be sure that the program disc name is TXD1732 before making necessary adjustment.

Note 2: Unless otherwise specified, the monitor set state is as given at right.

Note 3: The underlined places indicate the adjustment items on the screen of the PC.

Item Program Menu		◇ Test Meter ▼ Test Point □ Pattern	JOB CODE	Input Signal	Operation	Adjusting Value
D	H. +B 3) Adjust VSR setting	◇ Digital voltmeter ▼ TP502 (H-OUT) - GND □ Crosshatch	D1	HV3-1	Set the cell to the menu at left and press the	62.2 ±0.5V
			D2		Set the cell to the adjusting mode <u>INTP[0]</u> and press the	
			D3		Check to be sure that the input signal to the monitor set is [fH 29.5Hz] and [fV 48.0Hz] and press the	
			D4		Set the cell to <u>H. OUT B</u> and press the . Then, move the cell to the data side.	
			D5		Make adjustment to as shown at right using and . Make registration using the after adjustment and press the to return to the menu of D2. <The same as D2, D3, D4, and D5 after setting the adjusting mode/signal and adjustment.	
			D6	HV3-2	Adjusting mode <u>INTP[1]</u> : Input signal [fH 39.0kHz] [fV 77.1Hz]	86.2 ±0.5V
			D7	HV3-3	Adjusting mode <u>INTP[2]</u> : Input signal [fH 54.0kHz] [fV 105.0Hz]	122.3 ±0.5V
			D8	HV3-4	Adjusting mode <u>INTP[3]</u> : Input signal [fH 64.5kHz] [fV 165.0Hz]	145.5 ±0.5V
			DE		Return to the main menu by pressing the .	
E	EHT 4) Adjust OTHER setting	◇ Oscilloscope ▼ TP3 - GND □ Sync signal only (RGB OFF)	E1	HV3-1	Check to be sure that the input signal is as shown at left and set the cell to the menu at left. Then, press the .	
			E2		Move the cell to <u>EHT</u> and press the .	
			E3		Make adjustment to as shown at right using the and . (390Vp-p ±20V)	
			EE		Press the to return to the main menu.	
F	V. OSC 8) Special ADJUST	◇ Oscilloscope ◇ 10:1 probe x 2 ▼ TP401 (V. OSC) - GND ▼ N101 ③ (G. IN) - GND □ White flat field pattern	F1	HV3-2A	Set the cell to the menu at left and press the .	 The bottom of the M waveform coincides with the video phase.
			F2		Select <u>4.V. OSC</u> using 4 .	
			F3		Set the cell to the adjusting mode <u>VSR2</u> and press the .	
			F4		Check to be sure that the signal is as shown at left and press the .	
			F5		Make adjustment to as shown at right using the and . After adjustment, press the to return to the menu of F3.	
			F6	HV3-4A	Set the cell to the adjusting mode <u>VSR4</u> and press the .	
			F7		Check to be sure that the signal is as shown at left, press the ENTER key, and make same adjustment as F4.	
			FE		Return to the menu of F3 using and F4 using and return to the main menu using and .	
G	DAF 8) Special ADJUST	◇ Oscilloscope ◇ 100:1 probe ◇ 10:1 probe ▼ TP301 - GND (100:1) ▼ N101 ③ (G. IN) - GND □ White flat field pattern	G1	HV3-4	Set the cell to the menu at left and press the .	Waveform of G4 (H. DAF)
			G2		Select the <u>2.DAF ADJUST</u> using 2 .	
			G3		Check to be sure that the signal is as shown at left.	Waveform of G6 (V. DAF)
			G4		Adjust the time axis of the oscilloscope so that the DAF waveform becomes as shown at right.	
			G5		Move the cell to <u>H. DAF GAIN</u> , <u>H. DAF POS</u> and adjust as shown at right using and . (220Vp-p ±10V)	
			G6		Adjust the time axis of the oscilloscope so that the DAF waveform becomes as shown at right.	
			G7		Move the cell to the <u>V. DAF GAIN</u> , <u>V. DAF POS</u> and adjust as shown at right using and . (100Vp-p ±10V)	
			GE		Return to the menu of G2 using and return to the main menu using the and .	

Item Program Menu		<input type="checkbox"/> Test Meter <input checked="" type="checkbox"/> Test Point <input type="checkbox"/> Pattern	JOB CODE	Input Signal	Operation	Adjusting Value
H	FOCUS	<input type="checkbox"/> Crosshatch <input type="checkbox"/> Character pattern	H1	HV3-4	Turn the FOCUS H VR of the FBT to make the focus of the peripheral section optimum.	
			H2		Turn the FOCUS V VR of the FBT to make the focus of the center section optimum. (Repeat H1 and H2 to make it optimum.)	
			H3		Switch to the character pattern and check to be sure that the focus is at its best. (Note: This adjustment should be done by turning the VR using a screwdriver.)	
I	H. CENTER 3) Adjust VSR setting	<input type="checkbox"/> RGB OFF (Sync signal only)	I1	HV3-1	Set the cell to the menu at left and press the  .	<div style="text-align: center;">  </div> Set the RASTER to the center with respect to the bezel.
			I2		Set the cell to the adjusting mode <u>INTP[0]</u> and press the  .	
			I3		Check to be sure that the input signal to the monitor set is as shown at left [fH 29.5kHz] and [fV 48.0Hz] and press the  .	
			I4		Set the cell to the <u>H_CENTER</u> and press the  , and move the cell to the data side.	
			I5		Make adjustment as shown at right using  and  . Register using the  after adjustment, press the  , and return to the menu of 12. <The same as 12, 13, 14, and 15 except for the adjusting mode and signal.>	
			I6		Adjusting mode <u>INTP[1]</u> : Input signal [fH 39.0kHz] [fV 77.1Hz]	
			I7		Adjusting mode <u>INTP[2]</u> : Input signal [fH 54.0kHz] [fV 105.0Hz]	
			I8		Adjusting mode <u>INTP[3]</u> : Input signal [fH 64.5kHz] [fV 165.0Hz]	
			IE		Return to the main menu by pressing the  .	
J	HV. SIZE/HV. POSI/ V. PCC (1) 5) Adjust Factory preset	<input type="checkbox"/> Crosshatch	J1	MODE-12	Set the cell to the menu at left and press the  .	H. SIZE 300mm ±5mm V. SIZE 225mm ±5mm HV. POSI CENTER
			J2		Check to be sure that the input signal is as shown at left and press the  .	
			J3		<Set the cell to the following items, press the  , and make J3 and J4.>	
			J4		Adjust the <u>H_SIZE</u> , <u>V_SIZE</u> , <u>H_POSI</u> and <u>V_POSI</u> to the left using  and  .	
			JE		Set the <u>V_PCC</u> , <u>V_PCC TRAPEZOID</u> and <u>V_PCC PARAL-LEL</u> to the best using  and  . Press the  and  to return to the main menu.	
K	V. PCC 3 Adjust OTHER setting	<input type="checkbox"/> Crosshatch	K1	MODE-12	Check to be sure that the input signal is as shown at left. Set the cell to the menu at left and press the  .	
			K2		<Set the cell to the following items, press the  , and make necessary adjustment.>	
			KE		Set the <u>V_PCC CORNER</u> , <u>V_PCC CENTER</u> and <u>V_PCC BALANCE</u> to the best using the  and  . Press the  to return to the main menu.	

Item Program Menu		<input type="checkbox"/> Test Meter <input checked="" type="checkbox"/> Test Point <input type="checkbox"/> Pattern	JOB CODE	Input Signal	Operation	Adjusting Value
L	HV. SIZE, HV. POSI, V. PCC (2) 3) Adjust VSR setting	<input type="checkbox"/> Crosshatch	L1		Set the cell to the menu at left and press the  .	H. SIZE 300mm ±5mm V. SIZE 225mm ±5mm HV. POSI CENTER V. PCC best point
			L2		Set the cell to the adjusting mode <u>INTP[0]</u> and press the  .	
			L3	HV3-1	Check to be sure that the input signal to the monitor set is as shown at left [fH 29.5kHz] and [fV 48.0Hz] and press the  .	
			L4		Set the cell to the following items, press the  , and make necessary adjustment using the  and  .	
					① <u>H. SIZE</u> , ② <u>V. SIZE</u> , ③ <u>H. POSI</u> , ④ <u>V. POSI</u> , and ⑤ <u>V. PCC</u>	
			L5		After adjusting ① - ⑤, press the  and return to the menu of L2. <Same as L2, L3, L4, and L5 except for the adjusting mode/signal.>	
			L6	HV3-2	Adjusting mode <u>INTP[1]</u> : Input signal [fH 39.0kHz] [fV 77.1Hz]	
			L7	HV3-3	Adjusting mode <u>INTP[2]</u> : Input signal [fH 54.0kHz] [fV 105.0Hz]	
			L8	HV3-4	Adjusting mode <u>INTP[3]</u> : Input signal [fH 64.5kHz] [fV 165.0Hz]	
			LE		Press the  to return to the main menu.	
M	HV. SIZE, HV. POSI, V. PCC (3) 5) Adjust Factory preset	<input type="checkbox"/> Crosshatch	M1		Set the cell to the menu at left and press the  .	H. SIZE 300mm ±5mm V. SIZE 225mm ±5mm HV. POSI CENTER V. PCC best point
			M2	MODE-3	Check to be sure that the input signal to the monitor set is as shown at left [fH 31.5kHz] and [fV 60Hz] and press the  .	
			M3		Set the cell to the following items, press the  , and make adjustment as shown at right using the  and  .	
					① <u>H. SIZE</u> , ② <u>V. SIZE</u> , ③ <u>H. POSI</u> , ④ <u>V. POSI</u> , ⑤ <u>V. PCC</u> , ⑥ <u>PARALLEL</u> and ⑦ <u>TRAPEZOID</u> Note: H. POSI and V. SIZE should use both modes, MSB and LSB. For details, refer to the description of adjusting screen image.	
			M4		After adjusting ① - ⑦, go to M5 using the  and  .	
					<Same as M2, M3, and M4 except for the input signal below.>	
			M5	MODE-9	Input signal [fH 37.8kHz] and [fV 60Hz]	
			M6		After adjustment, go to M7 using the  and  .	
			M7	MODE-12	Input signal [fH 48.3kHz] and [fV 60Hz]	
			ME		Return to the main menu after adjustment using the  and  .	

Item Program Menu		<input type="checkbox"/> Test Meter <input checked="" type="checkbox"/> Test Point <input type="checkbox"/> Pattern	JOB CODE	Input Signal	Operation	Adjusting Value
Q	INPUT 1.0V SETTING	<input type="checkbox"/> Totally white pattern	Q1	MODE-12	Set the cell to the menu at left and press the <input type="button" value="F1"/> . Select <u>1: VIDEO 1.0V ADJUST</u> from the menu. Set the <u>CONTRAST MAX</u> and <u>VIDEO INPUT 1.0V</u> using the OSD of the monitor set. Press the <input type="button" value="F1"/> against the message of "hit return key". Press the <input type="button" value="F1"/> as other message is displayed. Press the <input type="button" value="F1"/> to return to the menu of Q2 and return to the main menu using the <input type="button" value="F1"/> .	
	8) Special ADJUST		Q2			
			Q3			
			Q4			
			Q5			
			QE			
R	FINAL SETTING		R1	MODE-12	Set the cell to the menu at left and press the <input type="button" value="F1"/> . Select the <u>9: FINAL TUNE</u> from the menu. Press either Y or N when the message of "CANCEL USER PRESET DATA (y/n) ->" has been output after a while. Key in 1 against the message of SELECT FLAG ->. Press the <input type="button" value="F1"/> to return to the menu of R2 and then return to the main menu using the <input type="button" value="F1"/> .	
	8) Special ADJUST		R2			
			R3			
			R4			
			RE			
T	DATA SAVING		T1		Set the cell to the menu at left and press the <input type="button" value="F1"/> . Key in the file name after []: Use SERIAL No. as a file name. (EXAMPLE : FF4111732 = "4111732. DAT")	
	7) Save data to FILE		T2			

2. Control Program Screen Image Description

①	②	④
③		JOB CODE
		⑤

- ① Screen image No. (S-1 - S-19) on this manual
 ② Screen image name
 ③ Screen image of control-side PC
 ④ Description of method of use
 (: indicate key operation)
 (⇒S-□ : indicates that an advance is made to the S-□ screen.)
 ⑤ JOB CODE given on the control description corresponding to this manual.

S-1	Main Menu	Move the cell with the cursor key. => MS-DOS																																			
<< HV3 ADJUST PROGRAM MAIN MENU >> (e:exit) <Ver8.2> 1) Load data from FILE 6) Clear User preset 2) Adjust H. OSC freerun 7) save data to FILE 3) Adjust VSR setting 8) Special ADJUST 4) Adjust OTHER setting 9) Information Service 5) Adjust Factory preset 10) Show Version & Error		<table border="1"> <tr> <th colspan="7">JOB CODE</th> </tr> <tr> <td>A2</td> <td>B1</td> <td>C1</td> <td>D1</td> <td>E1</td> <td>F1</td> <td>G1</td> </tr> <tr> <td>I1</td> <td>J1</td> <td>K1</td> <td>L1</td> <td>M1</td> <td>N2</td> <td>P2</td> </tr> <tr> <td>Q1</td> <td>R1</td> <td>T1</td> <td></td> <td></td> <td></td> <td></td> </tr> </table>	JOB CODE							A2	B1	C1	D1	E1	F1	G1	I1	J1	K1	L1	M1	N2	P2	Q1	R1	T1											
JOB CODE																																					
A2	B1	C1	D1	E1	F1	G1																															
I1	J1	K1	L1	M1	N2	P2																															
Q1	R1	T1																																			
S-2	Operation screen of 1) Load data from FILE	File name DATA is displayed. => S-1 When the fed file does not exist. => S-1 => S-1 <<Note: Be careful as the data in the monitor tends to vary!>>																																			
FILE -> EEPROM FILE NAME (q or Q escape) [] : _		<table border="1"> <tr> <th colspan="7">JOB CODE</th> </tr> <tr> <td></td> <td>A3</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table>	JOB CODE								A3																										
JOB CODE																																					
	A3																																				
S-3	Adjusting mode setting screen of 2)/3) Adjust H. OSC/VSR	Move the cell with the cursor key. => S-4 or S-5 => S-1																																			
<< HV3 ADJUST PROGRAM H. OSC/VSR MENU >> (E:exit) <Ver8.2> INTP [0] INTP [2] INTP [1] INTP [3]		<table border="1"> <tr> <th colspan="7">JOB CODE</th> </tr> <tr> <td></td> <td>B2</td> <td>B5</td> <td>B6</td> <td>B7</td> <td>BE</td> <td></td> </tr> <tr> <td>C2</td> <td>C6</td> <td>C7</td> <td>C8</td> <td>CE</td> <td>D2</td> <td>D6</td> </tr> <tr> <td>D7</td> <td>D8</td> <td>DE</td> <td>I2</td> <td>I6</td> <td>I7</td> <td>I8</td> </tr> <tr> <td>IE</td> <td>L2</td> <td>L6</td> <td>L7</td> <td>L8</td> <td>LE</td> <td></td> </tr> </table>	JOB CODE								B2	B5	B6	B7	BE		C2	C6	C7	C8	CE	D2	D6	D7	D8	DE	I2	I6	I7	I8	IE	L2	L6	L7	L8	LE	
JOB CODE																																					
	B2	B5	B6	B7	BE																																
C2	C6	C7	C8	CE	D2	D6																															
D7	D8	DE	I2	I6	I7	I8																															
IE	L2	L6	L7	L8	LE																																
S-4	Operation screen of 2) Adjust H. OSC freerun	If the input signal is as displayed, When not HV3-* is not TIMING: Error display => S-3 When the screen movement stops, adjustment (automatic adjustment) is completed. => S-3																																			
1 fH = (29.50 kHz) fV (48.0 Hz) In case of INTP[0] Please Input 'this' timing . Then HIT RETURN key !! If picture was stopped . HIT RETURN key !! Adjustment is completed. <<WARNING !!>> NO sync Error display		<table border="1"> <tr> <th colspan="7">JOB CODE</th> </tr> <tr> <td>B3</td> <td>B4</td> <td>B5</td> <td>B6</td> <td>B7</td> <td></td> <td></td> </tr> </table>	JOB CODE							B3	B4	B5	B6	B7																							
JOB CODE																																					
B3	B4	B5	B6	B7																																	
S-5	Input signal confirmation screen after selection of INTP[0] - INTP[4].	If the input signal is as displayed, => S-3. If HV3 -* is not TIMING: Error display => S-3																																			
1 fH (29.50kHz) fV (48.0Hz) In case of INTP[0] 2 fH (39.00kHz) fV (77.1Hz) In case of INTP[1] 3 fH (54.00kHz) fV (105.0Hz) In case of INTP[2] 4 fH (64.50kHz) fV (165.0Hz) In case of INTP[3] Please Input "this" timing . Then HIT RETURN key !! <<WARNING !!>> NO sync Error display		<table border="1"> <tr> <th colspan="7">JOB CODE</th> </tr> <tr> <td>C3</td> <td>C6</td> <td>C7</td> <td>C8</td> <td>D3</td> <td>D6</td> <td>D7</td> </tr> <tr> <td>D8</td> <td>I3</td> <td>I6</td> <td>I7</td> <td>I8</td> <td>L3</td> <td>L6</td> </tr> <tr> <td>L7</td> <td>L8</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table>	JOB CODE							C3	C6	C7	C8	D3	D6	D7	D8	I3	I6	I7	I8	L3	L6	L7	L8												
JOB CODE																																					
C3	C6	C7	C8	D3	D6	D7																															
D8	I3	I6	I7	I8	L3	L6																															
L7	L8																																				

Note 1: Control items underlined are not needed.

Note 2: Refer to the control description for the method of adjustment and adjusting values.

S-6	Main Menu	Select mode: ① The cell moves items with the cursor key. ② Adjusting mode of that item is selected by <input type="button" value="F4"/> . Adjusting mode: ③ Adjust with <input type="button" value="←"/> and <input type="button" value="→"/> . ④ Return to ① by <input type="button" value="F4"/> . Adjusting completed: <input type="button" value="E"/> => S-3 <input type="button" value="Q"/> => S-3 (Data is not registered.)																																																																																				
<< HV3 ADJUST PROGRAM INTP MENU >> (e:exit . q:quit) <Ve.r8.2> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;">H. OSC</td> <td style="width: 33%; text-align: center;">□□</td> <td style="width: 33%;">V. OSC</td> <td style="width: 33%; text-align: center;">□□</td> </tr> <tr> <td>H. DRIVE +B</td> <td style="text-align: center;">□□</td> <td>V. SIZE</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. OUT +B</td> <td style="text-align: center;">□□</td> <td>V. POSI</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. CENTER</td> <td style="text-align: center;">□□</td> <td>V. PCC</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. SIZE</td> <td style="text-align: center;">□□</td> <td>V. LIN (S)</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. POSI</td> <td style="text-align: center;">□□</td> <td>V. DAF GAIN</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. DAF GAIN</td> <td style="text-align: center;">□□</td> <td></td> <td></td> </tr> </table> All data will be written in EEPROM when you hit 'e' key !		H. OSC	□□	V. OSC	□□	H. DRIVE +B	□□	V. SIZE	□□	H. OUT +B	□□	V. POSI	□□	H. CENTER	□□	V. PCC	□□	H. SIZE	□□	V. LIN (S)	□□	H. POSI	□□	V. DAF GAIN	□□	H. DAF GAIN	□□			<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="7">JOB CODE</th></tr> <tr><td>C4</td><td>C5</td><td>C6</td><td>C7</td><td>C8</td><td>D4</td><td>D5</td></tr> <tr><td>D6</td><td>D7</td><td>D8</td><td>I4</td><td>I5</td><td>I6</td><td>I7</td></tr> <tr><td>I8</td><td>L4</td><td>L5</td><td>L6</td><td>L7</td><td>L8</td><td></td></tr> </table>	JOB CODE							C4	C5	C6	C7	C8	D4	D5	D6	D7	D8	I4	I5	I6	I7	I8	L4	L5	L6	L7	L8																													
H. OSC	□□	V. OSC	□□																																																																																			
H. DRIVE +B	□□	V. SIZE	□□																																																																																			
H. OUT +B	□□	V. POSI	□□																																																																																			
H. CENTER	□□	V. PCC	□□																																																																																			
H. SIZE	□□	V. LIN (S)	□□																																																																																			
H. POSI	□□	V. DAF GAIN	□□																																																																																			
H. DAF GAIN	□□																																																																																					
JOB CODE																																																																																						
C4	C5	C6	C7	C8	D4	D5																																																																																
D6	D7	D8	I4	I5	I6	I7																																																																																
I8	L4	L5	L6	L7	L8																																																																																	
S-7	Adjusting screen of 4) Adjust OTHER setting	Selection mode: ① The cell moves the item with the cursor key. ② The adjusting mode of the item is selected by <input type="button" value="F4"/> . Adjusting mode: ③ Adjust with <input type="button" value="←"/> and <input type="button" value="→"/> . ④ Return to ① with <input type="button" value="F4"/> . Adjustment is completed: <input type="button" value="E"/> => S-1 <input type="button" value="Q"/> => S-1 (Adjusting data is not registered.) Note: Data of *1A - *8A, *1B - *8B With the job code N11 of the adjusting manual operated, make as follows: <table style="width: 100%; border: none;"> <tr> <td>*1A=*1B</td> <td>*2A=*2B</td> <td>*3A=*3B</td> <td>*4A=*4B</td> </tr> <tr> <td>*5A=*5B</td> <td>*6A=*6B</td> <td>*7A=*7B</td> <td>*8A=*8B</td> </tr> </table>	*1A=*1B	*2A=*2B	*3A=*3B	*4A=*4B	*5A=*5B	*6A=*6B	*7A=*7B	*8A=*8B																																																																												
*1A=*1B	*2A=*2B	*3A=*3B	*4A=*4B																																																																																			
*5A=*5B	*6A=*6B	*7A=*7B	*8A=*8B																																																																																			
<< HV3 ADJUST PROGRAM OTHER MENU >> (e:exit . q:quit) <Ve.r8.2> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;">G2 9300K</td> <td style="width: 33%; text-align: center;">*1A</td> <td style="width: 33%;">G2 6500K</td> <td style="width: 33%; text-align: center;">*1B</td> </tr> <tr> <td>ABL 9300K</td> <td style="text-align: center;">*2A</td> <td>ABL 6500K</td> <td style="text-align: center;">*2B</td> </tr> <tr> <td>R SUBCONT 9300K</td> <td style="text-align: center;">*3A</td> <td>R SUBCONT 6500K</td> <td style="text-align: center;">*3B</td> </tr> <tr> <td>G SUBCONT 9300K</td> <td style="text-align: center;">*4A</td> <td>G SUBCONT 6500K</td> <td style="text-align: center;">*4B</td> </tr> <tr> <td>B SUBCONT 9300K</td> <td style="text-align: center;">*5A</td> <td>B SUBCONT 6500K</td> <td style="text-align: center;">*5B</td> </tr> <tr> <td>R LOW LIGHT 9300K</td> <td style="text-align: center;">*6A</td> <td>R LOW LIGHT 6500K</td> <td style="text-align: center;">*6B</td> </tr> <tr> <td>G LOW LIGHT 9300K</td> <td style="text-align: center;">*7A</td> <td>G LOW LIGHT 6500K</td> <td style="text-align: center;">*7B</td> </tr> <tr> <td>CONTRAST</td> <td style="text-align: center;">□□</td> <td>V. CPCC</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>BRIGHTNESS</td> <td style="text-align: center;">□□</td> <td>V. PCC CENTER</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>G1</td> <td style="text-align: center;">□□</td> <td>V. PCC TRAPEZOID</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. DAF GAIN</td> <td style="text-align: center;">□□</td> <td>V. PCC PARALLEL</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. DAF POSI</td> <td style="text-align: center;">□□</td> <td>V. PCC CORNER</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>V. DAF GAIN</td> <td style="text-align: center;">□□</td> <td>V. PCC BALANCE</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>V. DAF POSI</td> <td style="text-align: center;">□□</td> <td>EHT</td> <td style="text-align: center;">□□</td> </tr> </table> All datas (except *) are memorized.		G2 9300K	*1A	G2 6500K	*1B	ABL 9300K	*2A	ABL 6500K	*2B	R SUBCONT 9300K	*3A	R SUBCONT 6500K	*3B	G SUBCONT 9300K	*4A	G SUBCONT 6500K	*4B	B SUBCONT 9300K	*5A	B SUBCONT 6500K	*5B	R LOW LIGHT 9300K	*6A	R LOW LIGHT 6500K	*6B	G LOW LIGHT 9300K	*7A	G LOW LIGHT 6500K	*7B	CONTRAST	□□	V. CPCC	□□	BRIGHTNESS	□□	V. PCC CENTER	□□	G1	□□	V. PCC TRAPEZOID	□□	H. DAF GAIN	□□	V. PCC PARALLEL	□□	H. DAF POSI	□□	V. PCC CORNER	□□	V. DAF GAIN	□□	V. PCC BALANCE	□□	V. DAF POSI	□□	EHT	□□	<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="7">JOB CODE</th></tr> <tr><td>E2</td><td>E3</td><td>EE</td><td>K2</td><td>KE</td><td>N4</td><td>N5</td></tr> <tr><td>N8</td><td>N9</td><td>N10</td><td>NE</td><td>P4</td><td>P5</td><td>PE</td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </table>	JOB CODE							E2	E3	EE	K2	KE	N4	N5	N8	N9	N10	NE	P4	P5	PE							
G2 9300K	*1A	G2 6500K	*1B																																																																																			
ABL 9300K	*2A	ABL 6500K	*2B																																																																																			
R SUBCONT 9300K	*3A	R SUBCONT 6500K	*3B																																																																																			
G SUBCONT 9300K	*4A	G SUBCONT 6500K	*4B																																																																																			
B SUBCONT 9300K	*5A	B SUBCONT 6500K	*5B																																																																																			
R LOW LIGHT 9300K	*6A	R LOW LIGHT 6500K	*6B																																																																																			
G LOW LIGHT 9300K	*7A	G LOW LIGHT 6500K	*7B																																																																																			
CONTRAST	□□	V. CPCC	□□																																																																																			
BRIGHTNESS	□□	V. PCC CENTER	□□																																																																																			
G1	□□	V. PCC TRAPEZOID	□□																																																																																			
H. DAF GAIN	□□	V. PCC PARALLEL	□□																																																																																			
H. DAF POSI	□□	V. PCC CORNER	□□																																																																																			
V. DAF GAIN	□□	V. PCC BALANCE	□□																																																																																			
V. DAF POSI	□□	EHT	□□																																																																																			
JOB CODE																																																																																						
E2	E3	EE	K2	KE	N4	N5																																																																																
N8	N9	N10	NE	P4	P5	PE																																																																																
S-8	Input signal confirmation screen after selection of 4) Adjust Factory preset	Signal of MODE-3/-9/-12: <input type="button" value="F4"/> => S-9 Signals other than MODE-3/-9/-12: <input type="button" value="F4"/> Error display <input type="button" value="E"/> => S-1																																																																																				
Input any PRESET timing that you want to adjust. Then hit RETURN key. It's not PRESET timing !! Check your timing !!! Error display Hit RETURN key.		<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="7">JOB CODE</th></tr> <tr><td>J2</td><td>M2</td><td>M5</td><td>M7</td><td></td><td></td><td></td></tr> </table>	JOB CODE							J2	M2	M5	M7																																																																									
JOB CODE																																																																																						
J2	M2	M5	M7																																																																																			
S-9	Adjusting screen of 4) Adjust Factory preset	Select mode: ① The cell moves the item with an arrow key. ② The adjusting mode of the item is selected by <input type="button" value="F4"/> . Adjusting mode: ① Adjust with <input type="button" value="←"/> and <input type="button" value="→"/> . ② Return to ① with <input type="button" value="F4"/> . After completing adjustment: <input type="button" value="E"/> => S-10 <input type="button" value="Q"/> => S-1 (Adjusting data is not registered.) Note: H PSI/V. SIZE MSB on the screen varies largely, and LSB little. Make adjustment in combination of MSB and LSB.																																																																																				
<< HV3 ADJUST PROGRAM PRESET MENU >> (e:exit . q:quit) <Ve.r8.2> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;">H. SIZE</td> <td style="width: 33%; text-align: center;">□□</td> <td style="width: 33%;">V. PCC</td> <td style="width: 33%; text-align: center;">□□</td> </tr> <tr> <td>H. POSI MSB</td> <td style="text-align: center;">□□</td> <td>V. PCC TRAPEZIDO</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. POSI LSB</td> <td style="text-align: center;">□□</td> <td>V. PCC PARALLEL</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>V. SIZE MSB</td> <td style="text-align: center;">□□</td> <td>H. DAF GAIN</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>V. SIZE LSB</td> <td style="text-align: center;">□□</td> <td>H. DAF POSI</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>V. POSI</td> <td style="text-align: center;">□□</td> <td>V. DAF GAIN</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>H. MOIRE</td> <td style="text-align: center;">□□</td> <td>V. DAF POSI</td> <td style="text-align: center;">□□</td> </tr> <tr> <td>V. MOIRE</td> <td style="text-align: center;">□□</td> <td></td> <td></td> </tr> </table>		H. SIZE	□□	V. PCC	□□	H. POSI MSB	□□	V. PCC TRAPEZIDO	□□	H. POSI LSB	□□	V. PCC PARALLEL	□□	V. SIZE MSB	□□	H. DAF GAIN	□□	V. SIZE LSB	□□	H. DAF POSI	□□	V. POSI	□□	V. DAF GAIN	□□	H. MOIRE	□□	V. DAF POSI	□□	V. MOIRE	□□			<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="7">JOB CODE</th></tr> <tr><td>J3</td><td>J4</td><td>M3</td><td>M5</td><td>M7</td><td></td><td></td></tr> </table>	JOB CODE							J3	J4	M3	M5	M7																																								
H. SIZE	□□	V. PCC	□□																																																																																			
H. POSI MSB	□□	V. PCC TRAPEZIDO	□□																																																																																			
H. POSI LSB	□□	V. PCC PARALLEL	□□																																																																																			
V. SIZE MSB	□□	H. DAF GAIN	□□																																																																																			
V. SIZE LSB	□□	H. DAF POSI	□□																																																																																			
V. POSI	□□	V. DAF GAIN	□□																																																																																			
H. MOIRE	□□	V. DAF POSI	□□																																																																																			
V. MOIRE	□□																																																																																					
JOB CODE																																																																																						
J3	J4	M3	M5	M7																																																																																		
S-10	Screen after adjustment of 4) Adjust Factory preset	<input type="button" value="Y"/> => S-9 <input type="button" value="N"/> => S-1																																																																																				
Another timing adjust ? (y/n)		<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr><th colspan="7">JOB CODE</th></tr> <tr><td>JE</td><td>J4</td><td>M6</td><td>ME</td><td></td><td></td><td></td></tr> </table>	JOB CODE							JE	J4	M6	ME																																																																									
JOB CODE																																																																																						
JE	J4	M6	ME																																																																																			

S-11	Operating screen of 6) Clear User preset	Cleared <input type="checkbox"/> Y => S-1 Not cleared <input type="checkbox"/> N => S-1																		
Erase All 'User Preset DATA' . Okay ? (y/n) _		JOB CODE <table border="1"><tr><td></td><td></td><td></td><td></td><td></td><td></td></tr></table>																		
S-12	Operating screen of 7) Save data to FILE	Key in the file name after []: . Data display => S-1																		
EEPROM -> FILE NAME (q or Q escape) [] : _		JOB CODE <table border="1"><tr><td>T2</td><td></td><td></td><td></td><td></td><td></td></tr></table>	T2																	
T2																				
S-13	Adjusting mode setting menu of 7) Special ADJUST	Key-in the No. of adjusting item. After completing adjustment: <input type="checkbox"/> E <input type="checkbox"/> J => S-1																		
<< SPECIAL ADJUST MENU >> 1: VIDEO 1.0Vp-p ADJUST 2: DAF ADJUST 3: COLOR ADJUST 4: V. OSC ADJUST 5: 6: 7: 8: 9: Final TUNE Which data do you wanna change (1 - 9 . e:exit) ? -> _		JOB CODE <table border="1"><tr><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>F2</td><td>FE</td><td>G2</td><td>GE</td><td>Q2</td><td>QE</td></tr><tr><td>RE</td><td></td><td></td><td></td><td></td><td></td></tr></table>							F2	FE	G2	GE	Q2	QE	RE					
F2	FE	G2	GE	Q2	QE															
RE																				
S-14	Setting menu of 1:VIDEO 1.0Vp-p ADJUST	(Method of use) 1) Set the video level to 1.0V with the OSD, <input type="checkbox"/> J. 2) Adjustment is automatic. When this message appears, <input type="checkbox"/> J. 3) When this message has appeared, <input type="checkbox"/> J => S-13.																		
<< VIDEO LEVEL ADJUST MODE >> Please set video level at 1.0Vpp then hit return key ! (1) Please adjust CONTRAST (1.0Vpp) using CURSOR KEY. If you finished adjustment HIT RETURN KEY ! (2) Contrast (1.0Vpp) = Contrast (0.7Vpp) x a7/ff (3)		JOB CODE <table border="1"><tr><td>Q4</td><td>Q5</td><td></td><td></td><td></td><td></td></tr></table>	Q4	Q5																
Q4	Q5																			
S-15	Adjusting screen of 2:DAF ADJUST	Select mode: ① The cell moves the item with an arrow mark key. ② The item is set in the adjusting mode by <input type="checkbox"/> J. Adjusting mode: ③ Adjust with <input type="checkbox"/> L and <input type="checkbox"/> R. ④ Return to ① with <input type="checkbox"/> J. After completing adjustment: <input type="checkbox"/> E => S-13																		
Adjust DAF data. Then hit 'E' key. H. DAF GAIN : <input type="checkbox"/> <input type="checkbox"/> H. DAF POSI : <input type="checkbox"/> <input type="checkbox"/> V. DAF GAIN : <input type="checkbox"/> <input type="checkbox"/> V. DAF POSI : <input type="checkbox"/> <input type="checkbox"/>		JOB CODE <table border="1"><tr><td>G5</td><td>G7</td><td></td><td></td><td></td><td></td></tr></table>	G5	G7																
G5	G7																			
S-16	Mode setting screen of 4:V. OSC ADJUST	The cell moves VSR2 and VSR4 with <input type="checkbox"/> L and <input type="checkbox"/> R. <input type="checkbox"/> J => S-17 <input type="checkbox"/> E => S-13																		
<< HV3 ADJUST PROGRAM V.OSC MENU >> (e:exit) <Ve.r8.2> VSR2 VSR4		JOB CODE <table border="1"><tr><td>F3</td><td>F6</td><td>FE</td><td></td><td></td><td></td></tr></table>	F3	F6	FE															
F3	F6	FE																		
S-17	Input signal confirmation screen of 4:V. OSC ADJUST	After confirming that the displayed signal is fed, <input type="checkbox"/> J. Note: VSR2 requires the signals of HV3-2A and VSR4 requires the signal of HV3-4A. When the signal is different. Error display <input type="checkbox"/> J => S-13																		
fH = (39.00 kHz fV (77.1Hz)When WSR2 is selected. fH = (64.50 kHz fV (165.0Hz)When WSR4 is selected. Please input 'THIS' timing. Then HIT RETURN key !! << WARNING !! >> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> sync Error !! Error display		JOB CODE <table border="1"><tr><td>F4</td><td>F7</td><td></td><td></td><td></td><td></td></tr></table>	F4	F7																
F4	F7																			
S-18	Adjusting screen of 4:V. OSC ADJUST	Move the cell to the data side by <input type="checkbox"/> J and adjust with <input type="checkbox"/> L and <input type="checkbox"/> R. Data is adjusted by <input type="checkbox"/> J after adjustment, and the cell returns to V. OSC. <input type="checkbox"/> E => S-16																		
<< HV3 ADJUST PROGRAM V.OSC MENU >> (e:exit) <Ve.r8.2> V. OSC <input type="checkbox"/> <input type="checkbox"/>		JOB CODE <table border="1"><tr><td>F5</td><td>F7</td><td></td><td></td><td></td><td></td></tr></table>	F5	F7																
F5	F7																			

S-19	Operating screen of 9: Final TUNE	<p>① - ③ Automatic processing</p> <p>④ Selects either Y or N, <input type="checkbox"/> .</p> <p>⑤ Select 1, <input type="checkbox"/> => S-13</p> <table border="1" data-bbox="895 495 1423 533"> <tr> <td>JOB CODE</td> <td>R3</td> <td>R4</td> <td></td> <td></td> <td></td> </tr> </table>	JOB CODE	R3	R4			
JOB CODE	R3	R4						
<p>tuning start !</p> <p>< loading EEPROM data ></p> <p>wait a moment .. end (1)</p> <p>< tuning EEPROM data ></p> <p>wait a moment .. end (2)</p> <p>< saving data to EEPROM ></p> <p>wait a moment .. end (3)</p> <p>CANCEL USER PRESET DATA (y/n)? -> _ (4)</p> <p>< SET FLAG ></p> <p>1: SET</p> <p>2:</p> <p>SELECT FLAG -> _ (5)</p>		<p>When the display of microcomputer version is made and when an error is generated, the error code and the error contents are displayed.</p> <p><input type="checkbox"/> => S-1</p> <table border="1" data-bbox="895 792 1423 831"> <tr> <td>JOB CODE</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table>	JOB CODE					
JOB CODE								
S-20	Operating screen of 10) Show Version & error	<p>Y => S-13 (nothing happened)</p> <p>N => S-13 (data convert)</p> <table border="1" data-bbox="895 1099 1423 1137"> <tr> <td>JOB CODE</td> <td>N14</td> <td>NE</td> <td></td> <td></td> <td></td> </tr> </table>	JOB CODE	N14	NE			
JOB CODE	N14	NE						
<p>ID DATA = <input type="checkbox"/> Version No. 8</p> <p>err code = <input type="checkbox"/></p> <p><input type="checkbox"/> Error contents</p> <p>Hit any key ></p> <p>Calculate COLOR 6550k data automatically, OK (y/n)?</p> <p>finished, (Hit return key)_ Completion display</p>								

3. Purity adjustment

The CRT is an ITC assembly, however, here is the explanation for readjustment just in case.

If color shading is apparent, make the following adjustment.

3.1.

- (1) Verify that no unusual magnetic fields are near the Display unit (magnetic screwdrivers, table magnets, etc.). If possible, use a wooden workbench for this procedure.


- (2) Degauss the magnetism of chassis and CRT with external degaussing coil.

- (3) Adjust the purity magnet until each of the red, green and blue channels is free of color shading.

Make the following adjustment if color shading cannot be corrected by the above, or if the CRT or deflection yoke has been replaced.

3.2.

- (1) Keep the convergence yoke and deflection yoke in the positions shown below.




CY tightening torque: 8^{+2}_{-1} kgf-cm

DY tightening torque: 18 ± 2 kgf-cm

- (2) Make sure that this adjustment is done later than 30 minutes after power on.
- (3) Degauss the magnetism of chassis and CRT with an external degaussing coil.
- (4) Verify that static convergence is roughly matched. If it is misaligned, adjust static convergence of Red color and Blue color with Four-pole magnet A. For this adjustment Four-pole magnet B which is with deflection yoke must be put together.

- (5) Remove the wedge from the deflection yoke, and pull the deflection yoke fully to the front.


- (6) Display green color solely with the signal generator. Adjust the purity magnet so that the center of the screen displays a pure green disk. Slide the deflection yoke rearward until the four corners shaded and check its area's uniformity.



- (7) After the adjustment of step 5, readjust the static convergence if some gap was found.

Static convergence alignment for this step is to be performed with Four-pole magnet A and Six-pole magnet.

- (8) Display red disk. Adjust the purity magnets so as that red disk is as the center of the screen simultaneously. If red shifted, move a little its position in opposite direction.



- (9) Green again.

Slide the deflection yoke rearward until the screen appears green on the whole, and fasten it there.

- (10) Confirm purity in each direction by rotating the set to direction of East, West, South, and North after degauss by external degaussing coil.

- (11) If magnetism remains even after the adjustment, use the compensation magnet to obtain purity.

The final confirmation method for purity

In the natural magnetic field, rotate the monitor in the direction of East, West, South and North.

Earth's magnetic field may cause magnetism on the monitor. Confirm that the automatic degaussing circuit built in the monitor can erase the amount of magnetism which was introduced with above rotation.

4. Convergence adjustment

The CRT is an ITC assembly, however, here is the explanation for readjustment just in case.

- (1) Make sure that this adjustment is done later than 30 minutes after power on. Check general ability coarse adjustment and purity adjustment finished.
- (2) Degauss the magnetism of chassis and CRT with degaussing coil. (CRT board also)
- (3) Apply mixed crosshatch signals of red and blue from the signal generator. Nudge the deflection yoke to equal its inclination up and down, right and left with a temporary wedge between CRT and the top of the yoke
- (4) Match the red and blue images at the center of the screen by rotating the Four-pole magnet A (See STEP-1 in figure for examples). For this adjustment Four-pole magnet B be put together.
- (5) Apply mixed crosshatch signal consists of red, blue and green from the signal generator.
- (6) Match the red, green and blue images at the center of the screen by rotating the Six-pole magnet. (See STEP-2 in figure for examples)
- (7) If lines are twisted either lefthand or righthand (See the STEP-3 in figure for examples) perform the following:
 - a. Use Four-pole magnet B to shift convergence of horizontal lines by 5 to 6 mm at the center of the screen. (For twisted lefthand lines shift blue line downward and red line upward. For twisted righthand lines shift red line downward and blue line upward. Do not shift convergence of vertical lines.)
 - b. Then realign convergence with Four-pole magnet A.
- (8) Loosen the deflection yoke fastening screw and gently nudge the yoke up and down to achieve the best overall convergence on the edges of the screen (See STEP-4 in figure for examples). Insert wedge at the top of the deflection yoke so that the convergence will not deviate due to an unsteady deflection yoke.
- (9) Gently nudge the yoke from side to side to achieve the best overall convergence on the edges of the screen (See STEP-5 in figure for examples). Insert wedges at the left side and right side of the deflection yoke so that the convergence will not deviate due to an unsteady deflection yoke. (Do not apply silicon adhesive to the wedges to prevent them from slipping out).

- (10) Check that the image is horizontal.

If needed, rotate the deflection yoke.

- (11) Recheck the purity adjustment. If purity was adversely affected repeat the purity adjustment, then recheck convergence when finished.
- (12) Retighten the deflection yoke fastening screw. Do not overtighten the screw, as this can damage the CRT.

Tightening torque: 18 ± 2 kgf-cm

- (13) Align the horizontal line convergence at the center of the screen with the Differential coil (See STEP-6 in figure for examples).
- (14) Align the horizontal line convergence at the top and bottom of the screen with the Differential resistor VR. (See STEP-7 in figure for examples). (blue one)
- (15) Recheck convergence at the center of the screen. If needed, realign with the Four-pole magnet A and the Six-pole magnet. Fasten up the magnet stopper for the inside magnets not to move.
- (16) Insert wedges as shown in STEP-8 of figure (at the left bottom, right bottom, left top, right top, and top of the deflection yoke). Secure them with silicon adhesive and polyester tape. Remove any temporary wedges while keeping convergence aligned.
- (17) If the convergence on the fringe areas is still not acceptable, place one or more Permalloys around the funnel to achieve the best effect. Then press these Permalloys onto the funnel. Verify convergence around all edges of the screen. Secure them with polyester tape. (See STEP-9 in figure for examples.)

NOTE

In the above step, do not place the Permalloys closer than 20 mm from the HV anode cap. Do not tape them over any paper labels or secure them with silicon adhesive.

- (18) After completion of adjustment, apply white lacquer to the movable portions of the deflection and convergence yokes to secure them.

Adjustment part	Misconvergence pattern Wedge inserting position	Adjustment part	Misconvergence pattern Wedge inserting position
Four-pole magnet B	STEP-1 	Deflection yoke	STEP-5 <p>Tilting the yoke left Tilting the yoke right</p> <p>Rear view of the CRT</p>
Six-pole magnet	STEP-2 		STEP-6
Four-pole magnet B	STEP-3 <p>Beams are twisted lefthand Beams are twisted righthand</p> <p>for example (lefthand)</p> <p>with four-pole magnet B with four-pole magnet A</p>	Differential coil	STEP-7
Deflection yoke	STEP-4 <p>Tilting the yoke up Tilting the yoke down</p> <p>Rear view of the CRT</p>	Differential resistor VR3	STEP-8 <p>Wedge spacing and how to tape</p>
		Permalloy	STEP-9


CHECK ITEM

These items are intended for a recheck after adjustment and for a check of the following function operations:

1. Resolution check
2. Brightness variation check
3. Gradation check
4. Brightness check
5. Deflection linearity check
6. Distortion check
7. Image stability check
8. Blinking image check
9. Circuit operation check
10. Specific function check
11. Power save function check

1. Resolution Check

- (1) Apply resolution check pattern.



- (2) Check with the normal signal and inverted signal. Check to be sure that display color between dots is uniform and that there are no color difference and spotty display color.
- (3) Check the entire image quality including resolution.

2. Brightness Variation Check

- (1) Cause the white full dot pattern to be displayed with the Mode-12 signal.
- (2) Set the contrast to a maximum. Set the brightness to the center.
- (3) Make sure that a brightness difference between the center and periphery is $<65\%$ with the horizontal magnetic field in the condition of $\pm 30 \mu T$.

3. Gradation Check

- (1) Cause the 16 grayscale to be displayed with the Mode-3 signal. (White gradation waves.)
- (2) Set the contrast to a maximum and the brightness to the center.
- (3) At this time, the 1st gradation (black level) cannot be seen and the 2nd gradation must be barely lit.
- (4) With the brightness set to the center, vary the contrast from the maximum point and the gradation tracking must be good at that time.

Note: If hint (particularly the gray, which is a middle color) is different, make adjustment of the white balance once again.

- (5) With the contrast set to a maximum, vary the brightness from the maximum point to the minimum point and check to be sure that the brightness of the low gradation portion changes.

Note: Check both the color select 9300K and 6550K.

4. Brightness Check


- (1) Cause the white full-flat field pattern to be displayed with the Mode-3 signal.
- (2) Make sure that the brightness value is $< 15 \text{ cd/m}^2$ when the contrast is set to a minimum and the brightness to the center.

5. Deflection Linearity Check

- (1) Display the green only crosshatch pattern.

$$\text{Horizontal linearity} = \frac{X_{\text{max.}} - X_{\text{min.}}}{X_{\text{max.}} + Y_{\text{min.}}} \times 100\%$$

$$\text{Vertical linearity} = \frac{Y_{\text{max.}} - Y_{\text{min.}}}{Y_{\text{max.}} + Y_{\text{min.}}} \times 100\%$$



- (2) To confirm the horizontal deflection linearity, proceed in the next input signal modes:

Mode-1 $\leq 6\%$

Mode-2 $\leq 5\%$

Mode-3 $\leq 5\%$

To confirm the vertical deflection linearity, proceed in the following input signal modes:

$$\left. \begin{array}{ll} \text{HV3-1} & \text{HV3-4} \\ \text{Mode-1} & \text{Mode-2} \\ \text{Mode-3} & \end{array} \right\} \leq 5\%$$

6. Distortion Check

- (1) Apply the signal of the following mode and supply the green crosshatch pattern.


Mode-1

Mode-2

Mode-3

- (2) Make sure that each value comes within the value indicated above.


• Total distortion



$$IAB - CDI \leq 3.0 \text{ mm}$$


$$IAC - BDI \leq 3.0 \text{ mm}$$

• Pincushion



$$a, b, c, d \leq 1.5 \text{ mm}$$

• Rotation




$$C, D \leq 3.0 \text{ mm}$$

7. Image Stability Check

- (1) Check to be sure that the size variations are < 2 mm for horizontal size and < 1.5 mm for vertical size when the white full dot pattern of Mode-3/Mode-12 is displayed and the AC voltage is changed to 90 ~ 264 V.
- (2) Make sure that the size-variations are < 2 mm for horizontal size and < 1.5 mm for vertical size when contrast is changed to a minimum from maximum at the AC voltage of 120 V/240V.

8. Blinking Image Check

- (1) Apply blinking pattern signal. (100%)



- (2) Check the image stability at Mode-1 and Mode-3. Check if image changes due to blinking meets the standards below using the microscope.

9. Circuit Operation Check

- (1) Check the protection operation at fH not covered in the specifications.
- (2) Apply fH = 28 KHz and 66 KHz signal and check to be sure that sync flows.

10. Specific Function Check

- (1) Create the crosshatch pattern using the Mode-3 signal of the preset timing.
- (2) Vary the variations of the vertical size and the deviation of the horizontal size and check to be sure that the horizontal size and horizontal position variations meet the values given below.


Vertical size	→ ± 20 mm or more
Vertical position	→ up and down 5 mm or more
Horizontal size	→ MIN. < 280 mm MAX. > 316 mm
Horizontal position	→ left 40 mm or more
Horizontal position	→ right 40 mm or more

11. Power Save Function Check

The power consumption must meet the specifications when the horizontal/vertical sync signals are changed as shown below.


H. SYNC	OFF	ON	OFF
V. SYNC	ON	OFF	OFF
SPEC	$< 30W$	$< 30W$	$< 8W$

SHEET (2) H/V SYNC / ON SCREEN DISPLAY CONTROL




BLOCK DIAGRAM


SHEET (3) VIDEO OUT




SHEET (4) MICRO PROCESSOR / DIGITAL ANALOG CONVERTER / SIGNAL IN




SHEET(5) H OSC / V OSC, OUTPUT




SHEET (7) POWER SUPPLY




SHEET (9) H OUTPUT / GEOMETRY CONTROL




SHEET(6) DEGAUSS



SHEET(8) EHT CHOPPOR




SHEET(10) DAF




MAIN BOARD (Solder side)




MAIN BOARD (Parts side)



VIDEO BOARD (Solder side)




VIDEO BOARD (Parts side)



SCHEMATIC DIAGRAM










IMPORTANT SAFETY NOTICE

The component identified by shading or international symbol  on the following schematic diagrams incorporate special features important for protection from X-Radiation, fire and electrical shock hazards. When servicing it is essential that only manufacturer's specified parts be used for those critical components.

NOTES:











1. RESISTOR

All resistors are carbon 1/4W resistor, unless otherwise noted by the following marks.
Unit of resistance is ohm (Ω), (K = 1,000, M = 1,000,000)

- | | | | |
|---|---------------------------|---|--|
|  | : Non Flammable |  | : Solid |
|  | : Metal Oxide |  | : Metal (Precision and high stability) |
|  | : Wire Wound |  | : Thermistor |
|  | : Fusible |  | : Positive coefficient Thermistor |
|  | : Flame Proof Rectangular | | |

2. CAPACITOR

All capacitors are ceramic 50V capacitor, unless otherwise noted by the following marks.
Unit of capacitance is μF , unless otherwise noted.

- | | | | |
|---|----------------------------|---|-----------------------|
|  | : Electrolytic |  | : Polyester |
|  | : Tantalum |  | : Metalized Polyester |
|  | : Bipolar |  | : Polypropylene |
|  | : Polystyrene |  | : Mica |
|  | : Temperature Compensation |  | : Ceramic |
| | |  | : Ceramic (SL) |

3. COIL

Unit of inductance is μH , unless otherwise noted.

4. VOLTAGE MEASUREMENT

Voltage is measured by a digital meter receiving normal signal.


5. This schematic diagram is the latest at the time of printing and is subject to change without notice.

SERVICE NOTES :


This model has a section that does not share a common ground with the power supply section. The different sections are referred to as the HOT section and the COLD section in the precautions below.

- Do not touch the HOT section and the COLD section at the same time. You may receive an electric shock.
- Do not short the HOT section to the COLD section. This could blow the fuse or damage parts.
- Never measure the HOT section and the COLD section at the same time when using tools such as oscilloscopes or multi-meters.
- Always unplug the unit before beginning any operation such as removing the chassis.


TVC80206 (IC901)




TDA9302H (IC401)




STR-S6533 (IC820)




MB88346BPFTF (IC502, IC751, IC1306)



M52326SP (IC201)




EY07P (IC1302)





MODEL No. : TX-D1732
(TX-D1732-G/-U/-SW/-A/-K/-J)
TX-D1732B
TX-D1732P
TX-D1732N
TX-D1732NM
H703(TX-D1732NE)
1764(TX-D1732V-M/-E/-A)


CHASSIS No. : HV3
CHASSIS FAMILY No. : 17HV3























— TROUBLE SHOOTING HINTS —

