

UHF/VHF TUNER/TV DEMODULATOR SCHEMATIC DIAGRAM

(D,E)

5


4

3

2

1

TO MAIN		P201	
PIN- 5	VIDEO	5	
PIN- 4	34 CH	4	
PIN- 3	TV (H) VCR (L)	3	
PIN- 2	UNSW +5V (VIDEO)	2	
PIN- 1	AUDIO	1	



IMPORTANT NOTICE:

1 IF PARTS OF TUNER AND FS SECTION ARE REPLACED INDIVIDUALLY, THE FCC SPECIFICATIONS WILL NOT BE SATISFIED. DURING SERVICING, PLEASE REPLACE AS A UNIT.

2 SINCE THE UHF/VHF TUNER/TV DEMODULATOR UNIT HAS ALREADY BEEN PRE-ADJUSTED AT THE FACTORY, DO NOT TRY TO ADJUST THE UHF/VHF TUNER/TV DEMODULATOR UNIT. THE UHF/VHF TUNER/TV DEMODULATOR UNIT REPLACEMENT PART IS AVAILABLE ONLY AS A COMPLETE ASSEMBLY UNIT.

P701		TO MAIN	
14	AFC	PIN- 14	
15	SW +12V	PIN- 15	
16	AUDIO	PIN- 16	
17	VIDEO	PIN- 17	
18	UNSW +5V (SYS.CTL)	PIN- 18	
19	GND	PIN- 19	

P7601		TO TV MAIN	
6	+30V	PIN- 6	
7	SW +12V	PIN- 7	
8	SERIAL CLOCK	PIN- 8	
9	TUNER SIGNAL (L)	PIN- 9	
10	CH FREQUENCY LOCK (L)	PIN- 10	
11	SERIAL DATA 0	PIN- 11	
12	UNSW +5V (SYS.CTL)	PIN- 12	
13	DTS CS (H)	PIN- 13	

UNLESS OTHERWISE SPECIFIED:  
WATTAGE OF RESISTORS ARE 1/8W AND 1/4W.