

Mobile-phone abbreviations demand explanation

by Noel Boutin
University of Sherbrooke, Quebec, Canada

The cellular mobile-telephone system is becoming a reality [*Electronics*, May 24, 1979, p. 158]. As with most areas of specialized technology, this one possesses its own technical jargon—an amalgam of telephone, data-transmission, and computer vocabularies. The following list of 80 widely used abbreviations and acronyms covers the ones most likely to be encountered by the increasing number of engineers who will either need to be familiar with or will be directly engaged in work on such a cellular phone system.

AMA	automatic message accounting	IMTS	improved mobile telephone system
AMPS	Advanced Mobile Phone Service (Bell System)	LRI	locating receiver interface
AWC	additional word coming	LRR	locating radio receiver
BCH	Bose-Chandhuri-Hocquenghem error-correcting code	LSF	line-supervision frame
CCIS	common-channel interoffice signaling	MATS	maintenance and traffic simulator
CCITT	International Consultative Committee on Telegraphy and Telephony	MCL	mobile communications laboratory
CCM	central control and monitoring	MCG	mobile call generator
CCS	customer calling service	MCU	monitor and control unit
CIR	carrier-to-interference ratio	MERT	multienvironment real time
CMAX	number of setup channels to scan	modem	modulator-demodulator
CNR	carrier-to-noise ratio	Moses	mobile-office simulated environment system
CPA	common paging and access	MPSC	mobile phone service center
CTB	cellular test bed	MRT	mean recovery time
CU	control unit	MSA	mobile service area
D	distance between the centers of nearest cochannel cells	MTBF	mean time between failures
DDT	display, debugging, and test unit	MTF	maintenance test frame
DF	data frame	MTFC	maintenance test-frame controller
DM	data memory	MTL	mobile telephone laboratory
DMU	data-manipulation unit	MTSO	mobile telecommunications switching office
DPLMRS	domestic public land mobile-radio service	MUT	mean up time
D/R	cochannel reuse ratio	MW	message waiting
DRS	data-retrieval system	N	Number of cells per cluster
DT	down time	\bar{N}	mean value of environmental noise
ESS	electronic switching system	\bar{N}_p	mean value of weighted peak noise
ETSL	extended telephone simulation language	NAM	number assignment module
f_{RMS}^2	mean-squared frequency deviation	No SVC	no service
HCMTS	high-capacity mobile telecommunications system	NRZ	nonreturn to zero
HF	hands free	PA/C	power amplifier and combiner
\bar{I}	mean value of interfering signal	Procon	programmable controller
		PSU	program storage unit
		R	cell radius
		R-BPF	receiving bandpass filter
		RCC	radio common carrier
		RCS	Rayleigh channel simulator
		RSSI	received signal strength indicator
		SAT	supervisory audio tone
		Sinad	(Signal + noise + distortion) ÷ (noise + distortion)
		\bar{S}_m	mean value of maximum signal
		S/I	rf signal-to-interface ratio
		\bar{S}_s	mean value of serving signal
		ST	signaling tone
		TAC	terminal access circuit
		T-BPF	transmitting-bandpass filter
		TM	telemetry site
		T-R	transmit-receive
		TR	transceiver
		TSU	trunk switching unit
		VRD	voice receive data
		VTDI	voice-transmitter data interface
		WB	wideband
		WSU	writable store unit