PLAYMASTER MOSFET AMPLIFIER: I am constructing your latest Playmaster amplifier and have come across two problems that you may be able to help straighten out.

Firstly, I can see no use for connection pin 27 on the PCB overlay; I gather it may have something to do with the input selector wiring. Would you please explain. Secondly, can the choke as used in the March '81 guitar amp be used in the Mosfet amp; it would save us the trouble of winding it ourselves if it is suitable. (A.H., Adamstown Heights, NSW).

• Pin 27 was originally provided for in the design of the PCB so that the preamplifier output leads could be shielded if necessary. However, in the final design, pin 27 was not used. And yes, the choke used in the guitar amplifier can be used in the Playmaster Mosfet stereo amplifier.