


SPRING REVERB UNIT



820R = R10
 1K = R4, R11, R18, R22,
 R24, R25
 3K6 = R8, R9
 6K8 = R17
 10K = R12
 11K = R5, R6, R7
 22K = R1, R2, R14, R15,
 R19, R20
 47K = R21
 68K = R16
 100K = R3, R13, R23
 ...
 4n7 = C4
 47n = C3
 100n = C9, C11
 10u = C1, C2, C5, C6,
 C7, C12, C13, C14
 100u = C8, C10
 ...
 10K = VR1, VR4, VR5, VR6
 100K = VR2
 470K = VR3
 100K = TR1
 ...
 TL072 = IC1
 NE5532 = IC2, IC3



SPRING REVERB UNIT

PCB 50x85 mm

