






(Front Loading Parts)





<Loading Parts>

<Senser Parts>

<Cylinder Parts>







CASSETTE DECK MECHANISM 59228

Ref. No.	Part No.	Description
1	62D80598240A	CYLINDER ASS'Y
2	62D80590118	UPPER DRUM
3	62D805901304	LOWER DRUM ASS'Y
4	62D80590101	CYLINDER MOUNT
5	62D805901305	VIDEO OUT PCB ASS'Y
6	62D99730000	W TAMS SCREW 2.6X6
7	62D60040902	MOTOR TM84
8	62D90550000	SCREW 2.6X20
9	62D90980000	TAMS SCREW 2.6X6
10	62D99720000	BIND TAMS SCREW 3X8
11	62D92050000	C TAPPING SCREW 3X10
12	62D95520000	SCREW (FOR CAMERA) 2X5 (NO.1)
13	62D96650000	CAP SCREW 2.6X3
14	62D80590154	DRAM EARTH FLAT SPRING
15	62D91920000	C TAPPING SCREW 2.6X5
16	62D80590102	DRAM EARTH BRACKET
17	62D805901347	DM PCB C ASS'Y
18	62D91920000	C TAPPING SCREW 2.6X5
19	62D80590126	DRAM EARTH
20	62D97150000	WASHER 2.6
23	62D80590171	CONNECTOR BRACKET
32	62D805902301	OPEN ANGLE ASS'Y
33	62D91910000	C TAPPING SCREW 2.6X4
34	62D80590229	TRACKING ADJUSTER
35	62D80000314	TAPE GUIDE
36	62D80590226	TAPE GUIDE SPRING
37	62D80000319	GUIDE CAP
38	62D80000328A	TAPE GUIDE FLANGE (C)
39	62D80000329	TAPE GUIDE FLANGE (D)
40	62D94530000	NUT 3.0
41	62D80590223	DAMPER RUBBER
51	62D805903501	LOADING BASE SEMI-ASS'Y
52	62D80590304	LOADING BLOCK (L)
53	62D80590305	LOADING BLOCK (R)
54	62D80000337	ROLLER POST ST
55	62D80000337	ROLLER POST ST
56	62D96650000	CUP SCREW 2.6X3
57	62D9C170273	SCREW (FOR) CAMERA 2X2.7
58	62D91920000	C TAPPING SCREW 2.6X5
59	62D805903502	LOADING PLATE (L) SEMI-ASS'Y
60	62D80590314	LOADING BOSS
61	62D80590308	LOADING GEAR SPRING (L)
62	62D80590306	T LOADING GEAR (L)
63	62D805903503	LOADING PLATE (R) SEMI-ASS'Y
64	62D80590309	LOADING GEAR SPRING (R)
65	62D80590307	T LOADING GEAR (R)

CASSETTE DECK MECHANISM 59228

Ref. No.	Part No.	Description
66	62D98840000	P WASHER CUT 2.6X6X0.5
67	62D805903301	LOADING BASE ASS'Y
68	62D805903302	LOADING GEAR (L) ASS'Y
69	62D805903303	LOADING GEAR (R) ASS'Y
81	62D805904307	HEAD BASE ASS'Y
82	62D62041508	ACE HEAD HV224206
83	62D805904502	HEAD BASE SEMI ASS'Y
84	62D80000626	AZIMUTH SPRING SCREW
85	62D80000604	AZIMUTH SPRING
86	62D99530000	NYLON NUT M3
88	62D97050000	LONG LOCK SCREW 2.6X7
89	62D99992025	SCREW 3X6 (SHARP TYPE)
90	62D80590415	HEAD SPRING
95	62D99530000	NYLON NUT M3
96	62D80590405	IMPEDANCE ROLLER
97	62D80590406	IMPEDANCE ROLLER SLEEVE
98	62D80590407	TAPE GUIDE FLANGE (A)
99	62D80590409	TAPE GUIDE FLANGE SPRING
121	62D805905301	REEL ASS'Y
122	62D99120000	R WASHER 3.1X6X0.5
131	62D805906301	PINCH ROLLER ARM ASS'Y
132	62D805906501	PINCH ROLLER ARM SEMI-ASS'Y
133	62D90380000	SCREW 2.6X4
134	62D80000922	PINCH ROLLER (A)
135	62D99990311	P WASHER CUT 5X8X0.5
136	62D90960000	TAMS SCREW 2.6X4
137	62D80590618	COLLAR
138	62D80590605	P ACTUATE ANGLE
139	62D80590619	P ANGLE HOLDER
140	62D80590620	P ROLLER SPRING
141	62D80590624	P SLIDE PLATE A
142	62D80590618	COLLAR
143	62D91920000	C TAPPING SCREW 2.6X5
144	62D80590606	JOINT PLATE
145	62D80590604	P ACTUATE ARM
146	62D80590609	P ACTUATE ARM SPRING
147	62D80590612	P CLANK
148	62D80590613	P CLANK COLLAR
149	62D99991810	C TAPPING FH SCREW (FOR CAMERA) 2.6X4
150	62D80590610	P SLIDER
151	62D80590623	P SLIDER SPRING
152	62D80590611	P SLIDER COLLAR
153	62D91920000	C TAPPING SCREW 2.6X5
154	62D805906502	P CAM LEVER SEMI-ASS'Y
155	62D80590617	P CAM LEVER COLLAR
156	62D91920000	C TAPPING SCREW 2.6X5

CASSETTE DECK MECHANISM 59228

Ref. No.	Part No.	Description
157	62D80590625	P SLIDE PLATE B
171	62D805907302	CAPSTAN MOTOR ASS'Y
172	62D80590714	FLYWHEEL CAPSTAN
173	62D80590710	MAIN BELT
174	62D805907303	FL ANGLE ASS'Y
175	62D92020000	C TAPPING SCREW 3X5
176	62D99120000	R WASHER 3.1X6X0.5
177	62D805907301	METAL HOUSING ASS'Y
178	62D91950000	C TAPPING SCREW 2.6X8
179	62D91050000	TAMS SCREW 3X4
180	62D99990603	NYLON WASHER 2.92X5X0.5
191	62D805908501	BT ARM SEMI-ASS'Y
192	62D91910000	C TAPPING SCREW 2.6X4
193	62D80590809	BACK TENSION SUPPORT
194	62D91910000	C TAPPING SCREW 2.6X4
195	62D80590815	BAND HOLDER COLLAR
196	62D805908302	BT BAND ASS'Y
197	62D80590817	BAND HOLDER SPRING
198	62D80590813	BACK TENSION SPRING
199	62D99990315	P WASHER CUT 2.1X4X0.5
200	62D80590810	BT CHANGE PLATE
202	62D80590823	BT RETURN LEVER
203	62D80590618	COLLAR
204	62D91920000	C TAPPING SCREW 2.6X5
205	62D80590819	BT ACTUATE PLATE
206	62D80590818	BT ACTUATE LEVER
207	62D80590821	BT ACTUATE PLATE COLLAR
208	62D80590820	BT ACTUATE PLATE SPRING
209	62D80590618	COLLAR
210	62D98400000	S TAPPING SCREW (FOR CAMERA) 2.6X3.5
211	62D91920000	C TAPPING SCREW 2.6X5
221	62D805909316	SUB PLATE ASS'Y
222	62D805909501	SUB PLATE SEMI ASS'Y
223	62D90770000	TAMS SCREW 2X4
224	62D91920000	C TAPPING SCREW 2.6X5
225	62D80001025	WAVE WASHER
226	62D80590906A	REEL DRIVE GEAR
227	62D95000000	E RING S 1.5
228	62D98530000	NYLON WASHER 3.1X6X0.3
229	62D805909310	CLUTCH ASS'Y
230	62D99990604	NYLON WASHER 2.98X6X0.3
231	62D805909301	MIDDLE PULLEY ASS'Y
232	62D98840000	P WASHER CUT 2.6X6X0.5
233	62D80590917	DRIVE BELT
234	62D805909303	P GEAR ARM ASS'Y
235	62D80590920A	PLAY GEAR

CASSETTE DECK MECHANISM 59228

Ref. No.	Part No.	Description
236	62D805909304	RF GEAR ARM ASS'Y
237	62D80590922A	FF GEAR
238	62D97430000	P WASHER CUT 1.6X3.8X0.3
239	62D805909314	P GEAR ASS'Y
240	62D805909315	RF GEAR ASS'Y
251	62D80591019	BRAKE SHOE
252	62D80591001	S BRAKE SHOE
253	62D80591002	BRAKE ARM SPRING
254	62D80591003	T BRAKE ARM
255	62D805910301	S BRAKE ARM ASS'Y
256	62D805910302	T BRAKE ARM ASS'Y
257	62D80591016	BRAKE LIFTER
258	62D80591017	L BRAKE ACTUATOR
259	62D80591014	TRIGGER HOOK
260	62D80591013	TRIGGER LEVER
261	62D80591011	BRAKE PLATE
262	62D80591009	BRAKE ACTUATE BASE
263	62D805910303	T SOFT BRAKE ASS'Y
264	62D805910304	S SOFT BRAKE ASS'Y
265	62D99740000	SL FH SCREW (FOR CAMERA) 2X3
266	62D80591007	T SOFT BRAKE ARM COLLAR
267	62D80591018	L BRAKE ACTUATOR SPRING
268	62D80591006	T SOFT BRAKE ARM SPRING
269	62D80591022	S SOFT BRAKE SPRING
270	62D98760000	P WASHER CUT 2.1X5X0.5
271	62D80591023	TRIGGER LEVER SPRING
272	62D80591010	BRAKE ACTUATE BASE SPRING
273	62D80591012	BRAKE PLATE SPRING
281	62D805911301	LM ASS'Y
282	62D805911302	TRIGGER BEARING ASS'Y
283	62D80591103	LOADING PULLEY
284	62D97430000	P WASHER CUT 1.6X3.8X0.3
285	62D80591106	LOADING BELT
286	62D80591112	SEARCH ARM (B)
287	62D98840000	P WASHER CUT 2.6X6X0.5
288	62D80591104	LOADING GEAR
289	62D98760000	P WASHER CUT 2.1X5X0.5
290	62D80591113	BRAKE ACTUATE ARM
291	62D80591114	EJECT ARM
293	62D80591101	LOADING CAM
294	62D80591102	S BRUSH
295	62D91050000	TAMS SCREW 3X4
296	62D99990310	P WASHER CUT 2.6X8X0.5
312	62D805912501	LOADING LEVER SEMI-ASS'Y
313	62D80591213	CAM ROLLER
314	62D80591209	L GEAR PLATE

CASSETTE DECK MECHANISM 59228

Ref. No.	Part No.	Description
315	62D80591210	L GEAR PLATE COLLAR
316	62D92030000	C TAPPING SCREW 3X6
317	62D805912502	LOADING ACTUATE LEVER SEMI ASS'Y
318	62D805912503	LOADING ACTUATOR SEMI ASS'Y
319	62D80591205	LOADING ACTUATOR SPRING
320	62D80591211	LOADING LEVER REINFORCE PLATE
321	62D90780000	TAMS SCREW 2X5
322	62D80591212	L GEAR PLATE SPRING
336	62D68080804	DEW SENSOR EYH-S10R
337	62D90960000	TAMS SCREW 2.6X4
338	62D805913302	BASE PLATE ASS'Y
339	62D98030000	S TAPPING SCREW (FOR CAMERA) 2.6X5
340	62D91920000	C TAPPING SCREW 2.6X5
345	62D805913303	LAMP ASS'Y
348	62D68080803	REEL SENSOR
361	62D80591508	EJECT ACTUATOR
362	62D80590618	COLLAR
363	62D91920000	C TAPPING SCREW 2.6X5
364	62D80591507	L BRAKE PLATE
365	62D80590618	COLLAR
366	62D91920000	C TAPPING SCREW 2.6X5
367	62D805915303	E IDLER ARM ASS'Y
368	62D805915502	E IDLER ARM SEMI ASS'Y
369	62D80591515	EJECT PULLEY
370	62D97430000	P WASHER CUT 1.6X3.8X0.3
371	62D80591511	IDLER ARM SPRING
372	62D98760000	P WASHER CUT 2.1X5X0.5
373	62D80591506	FL BELT
390	62D805916337	FRONT LOADING ASS'Y
391	62D805916318	C LOAD BRACKET ASS'Y
392	62D805916319	F LOADING CLUTCH ASS'Y
393	62D805916333	FL PCB ASS'Y
394	62D805916316	SENSOR PCB RM ASS'Y
395	62D805916506	C LOAD BRACKET SEMI ASS'Y
396	62D80591634	IN SW LEVER
397	62D80591633	S SW LEVER
398	62D80591606	F WORM BEARING (A)
399	62D97430000	P WASHER CUT 1.6X3.8X0.3
400	62D90960000	TAMS SCREW 2.6X4
401	62D90780000	TAMS SCREW 2X5
411	62D805916306	CASSETTE HOLDER ASS'Y
412	62D80002203	CASSETTE HOLDER
413	62D80002213	SLIDE PLATE
414	62D80002212	C LOCK PLATE (A)
415	62D80590618	COLLAR
416	62D80591629	LOCK SPRING

CASSETTE DECK MECHANISM 59228

Ref. No.	Part No.	Description
417	62D99680000	SL SCREW (FOR CAMERA) 2.6X3
420	62D805916307	FRONT ANGLE ASS'Y
421	62D80591618	FRONT ANGLE
422	62D80591625	TAPE GUIDE (R)
423	62D80591624	TAPE GUIDE (L)
430	62D805916308	SIDE PLATE (R) ASS'Y
431	62D805916502	SIDE PLATE (R) SEMI ASS'Y
432	62D80591628	CASSETTE PUSH PLATE
433	62D98330000	SCREW (FOR CAMERA) 2.3X2
434	62D80002225	OPEN LEVER
435	62D80002244	OPEN LEVER SPRING
436	62D80002242	OPEN LEVER COLLAR
437	62D99670000	SL SCREW (FOR CAMERA) 2X4
438	62D80002216	LOCK RELEASE LEVER
439	62D80002275	GUIDE ROLLER
440	62D80002223	GUIDE ROLLER
445	62D805916309	SIDE PLATE (L) ASS'Y
446	62D805916503	SIDE PLATE (L) SEMI ASS'Y
447	62D80591628	CASSETTE PUSH PLATE
448	62D98330000	SCREW (FOR CAMERA) 2.3X2
449	62D80002266	C LOCK PLATE (L)
450	62D80591630	LOCK PLATE SPRING (L)
451	62D80001963	LOCK PLATE COLLAR
452	62D99660000	SL SCREW (FOR CAMERA) 2X2.5
453	62D80002275	GUIDE ROLLER
460	62D805916339	FRAME (R) ASS'Y
461	62D805916507	FRAME (R) SEMI ASS'Y
462	62D805916321	WORM WHEEL ASS'Y
463	62D80591636	WORM WHEEL
464	62D80591645	FRICTION GEAR
465	62D80591631	FRICTION SPRING
466	62D805916312	LIFT GEAR (R) ASS'Y
467	62D80002215	LIFT GEAR (R)
468	62D80002211	LIFT ARM
469	62D80002245	LP SPRING
470	62D80002226	OPEN LEVER GUIDE
471	62D80002224	GUIDE SLEEVE
472	62D95040000	E RING S2.5
480	62D805916338	FRAME (L) ASS'Y
481	62D805916508	FRAME (L) SEMI ASS'Y
482	62D805916301	SENSOR PCB (LM) ASS'Y
483	62D805916314	LIFT GEAR (L) ASS'Y
484	62D80002214	LIFT GEAR L
485	62D80002211	LIFT ARM
486	62D80002245	LP SPRING
487	62D80591667	LIFT LEVER

CASSETTE DECK MECHANISM 59228

Ref. No.	Part No.	Description
488	62D80591668	LIFT LEVER SPRING
489	62D95040000	E RING S2.5
490	62D90990000	TAMS SCREW 2.6X7
491	62D80002224	GUIDE SLEEVE
498	62D80002265	TOP STAY
499	62D80591619	END SENSOR WIRE
500	62D80591609	REAR ANGLE
501	62D80591666	UPPER PLATE
502	62D80591660	SYNCHRONIZE SHAFT
503	62D80591617	SYNCHRONIZE GEAR (A)
504	62D95040000	E RING S2.5
505	62D90960000	TAMS SCREW 2.6X4
506	62D95560000	SCREW (FOR CAMERA) 2.6X3
507	62D99910000	SCREW (FOR CAMERA) 2.3X2.5 (NO.3)
508	62D91920000	C TAPPING SCREW 2.6X5
509	62D80591672	DAMPER MAT
531	62D80591703	RG SLIDE PLATE
532	62D80591711	RG SLIDE SPRING
533	62D80591710	RG SLIDE PLATE COLLAR
534	62D90770000	TAMS SCREW 2X4
535	62D80591709	RG SLIDE BASE
536	62D805917501	RG ARM SEMI ASS'Y
537	62D98840000	P WASHER CUT 2.6X6X0.5
538	62D80591701	RG ACTUATE ARM
539	62D98760000	P WASHER CUT 2.1X5X0.5
540	62D80591702	RG ACTUATOR