



NOTES

- 1) SV1(A) 1) RECORD/PLAYBACK SWITCH (PLAYBACK POSITION)
- 2) SV2(A) B) ALCO N/OFF SWITCH (OFF POSITION)
- 3) SV3 PA ON/OFF SWITCH (OFF POSITION)
- 4) SV4 AC/DC SWITCH (AC POSITION)
- 5) SW5 OPERATION SWITCH (OFF POSITION)

SHARP/TC.

MODEL RD-667AV 1

Specifications or wiring diagrams of this model are subject to change for the improvement without prior notice.

TMAPC1129AFZZ