Click "Sync Release" Button

on the Main Menu to get the latest supported parts and program features




Note: An active internet connection is required for a successful Sync Release




LTpowerCAD II 2.0 Listed and Supported Parts

Buck Converters:



LTpowerCAD II 2.0 Supported Parts

Boost Converters:



Note: This list was generated on 06/06/2013. Many new parts could be added to the library after that. Click "Sync-Release" to update LTpowerCAD library & functions.

