

Digital Lighting Controller, October-December 2010: when operating the unit with four slaves, it may be necessary to leave the 10k Ω “chain length sense” resistor off one of the four slave boards for correct operation. You can check this by plugging in three slaves, then four; if it works with three but not four, remove that resistor from the fourth slave.