

- In Fig. 4 of my “Musical Instrument Phase Shifter” (October 1988) the symbol for D3 was omitted, though the correct designation and component type are shown in the appropriate location in the line below D2. This diode connects into the circuit with its cathode going to the ac adapter input jack and its anode going to the input pin of IC5 and negative plate of C12. Failure to include D3 in the circuit can destroy C12, IC5 and possibly other components. Note also that IC5 is a 7915 voltage regulator.

C.R. Fischer