

In "Space War Game" (April 1976), type numbers were inadvertently omitted in the Parts List for *IC7* through *IC10*. Integrated circuits *IC7* and *IC8* are 4023's, *IC9* and *IC10* 4001's.

In "Tips and Techniques," June, 1976, the circuit for Alan Kong's tip is incorrect. To add a tail to a seven-segment "9", the bottom resistor should be connected to the "g" segment output, not the "d" segment output. The other input is correctly shown connected to the "a" segment output, and the collector of the top transistor is properly connected to the "d" segment driver. The circuit for adding a top tail to a seven-segment "6" is correct.

**POPULAR ELECTRONICS**