











AC Signal Return Path Caps

Note: Similar AC signal return path caps must be included on the motherboard near the connector.



These two mounting holes are located near the front panel of the CM-1.



These two mounting holes are located at the "back" of the CM-1, near the main interface connectors.



This resistor is loacated near the front panel of the CM-1 and connects signal ground with chassis ground.



Power Decoupling Caps



CobraNet

Title: Module Interface Connector

Peak Audio, Inc.
1790 30th Street, Suite 414
Boulder, CO 80301
303-449-9337

Filename: connector.sch
Sheet: 3 of 8
Date: 21-Aug-2000

(C) 2000, Peak Audio, Inc.