



Bluetooth Controlled Relays Elektor Magazine 6/2016, p. 104 (150648)

FEEDBACK. The Bluetooth relay controller only worked for me after I programmed the ATtiny85 to run with a clock frequency of 1 MHz and not 8 MHz as suggested in the Arduino sketch.

I used the Arduino IDE to program the microcontroller; it was first necessary to install the following package in the IDE using the board manager: <https://github.com/SpenceKonde/ATTinyCore>

Hans Schneider

Our developer Roy Aarts used the 'attiny' board package maintained by David A. Mellis: https://raw.githubusercontent.com/damellis/attiny/ide-1.6.x-boards-manager/package_damellis_attiny_index.json

After installation, use the Arduino IDE Boards Manager and select:

Tools → Board → ATtiny25/45/85

Tools → Processor → ATtiny85

Tools → Clock → Internal 8 MHz

Clemens Valens, Technical Manager Elektor Labs