


SERVICE INFORMATION - SHIELD KIT FOR 19A100

TO INSTALL SHIELD on MONITOR switch, Dukane part No. 680-194, in Hodel 19A:00 Dual Channel Adapter, proceed as follows:

- 1. MONITOR switch is accessible directly from the back of the console or rack on the Duel Channel Adapter located below Master Control Panel. Dual Channel Adapter is fastened together with the Master Control Panel in a console or rack.
- 2. Use a switch wrench, such as a Pioneer "Knurl-Tite" or a Walsco No. 2583 wrench, to fit and turn the knurled 15/32-32 ring nut which holds the MONITOR switch on the Dual Channel Adapter front panel.
- 3. Unfasten the MONITOR switch and carefully bring switch assembly through the back of the opening in the front panel into the space behind front panel.
- 4. Temporarily take off lockwasher that was between switch assembly and the back of the front panel.
- 5. Place shield over switch handle so that threaded switch mount extends through hold in shield; switch wiring should extend through open end of shield at back of switch.
- 6. Put on lockwasher previously removed, and
- 7. Carefully replace MONITOR switch with shield and lockwasher on through opening in front panel; shield should be positioned so that top and both sides are covered with shield, and the open side in the shield is at the bottom.
- B. Lockwasher should be between front of shield and back side of front panel to form a good grounding device through the enamel.
- 9. Fasten MONITOR switch in place with knurled ring nut taken off previously; Eighten nut carefully so as not to scratch ename! surface of front panel.



TECHNICAL SERVICES - DUKAME CORPORATION - St. Charles, Illinois - 60174 404-289