

**ETI-723, Feb. '82, 'Selectacall', p.44:** For some totally unfathomable reason, the introduction to this project does not actually refer to this project but to commercial 'selcall' systems. Ggaahh! The last two lines of the intro should read: "... then this simple accessory allows you to turn down the volume, notifying you when that 'certain party' calls — no tones or funny noises required".

**Series 5000 Preamp, Oct. '81:** The 400 Hz oscillator set-up procedure is as follows, not as per page 12 in Dec. '81. Take your multimeter, set to read ac volts, and connect it to one of the output sockets. Set the TAPE switch to OSC. and adjust RV4 to obtain 1.2 Vac (RMS) on the meter.