


HAMPTON BAY®

USE AND CARE GUIDE

SOLAR GLOBE 30-LED STRING LIGHT



Questions, problems, missing parts? Before returning to the store,
• call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HOMEDEPOT.CA

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this solar string light. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Planning Installation.....	3
Safety Information.....	2	Package Contents.....	3
Warranty.....	2	Installation.....	4
1-YEAR LIMITED WARRANTY.....	2	Maintenance.....	4
What is Covered.....	2	Care and Cleaning.....	4
What is Not Covered.....	2	Troubleshooting.....	5
Pre-Installation.....	3		

Safety Information

Please read and understand this entire manual before attempting to assemble, operate, or install the product.

For best performance, this solar light should be:

- Installed in a location with full and direct sunlight.
- Installed in a location with minimal interference from other light sources.
- Not installed in a shady area.



DANGER: Use only a similar rating and type of battery as the one that comes with the fixture (AA 1.2v 600 mAh Ni-Mh rechargeable). Do not mix old and new batteries.



WARNING: Do not open, short circuit, or mutilate batteries as injury may occur.



CAUTION: Always dispose of recyclable batteries at a proper battery disposal facility. Do not dispose in fire or attempt to open a sealed battery.



NOTE: To allow the batteries to reach full capacity and perform correctly, switch ON and place the solar light in full sunlight for the first 12 hours. Failure to do so can shorten the life of the batteries or operation of the light. On cloudy or rainy days it may take several days for the batteries to fully charge.

Warranty

1-YEAR LIMITED WARRANTY

WHAT IS COVERED

This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect, or mishandling.

WHAT IS NOT COVERED

This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and /or weathering, as this is considered normal wear and tear.


Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HamptonBay.com.

Pre-installation

PLANNING INSTALLATION

- Before beginning installation of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble, install, or operate the product.


PACKAGE CONTENTS



Part	Description	Quantity
A	Solar panel with 30-LED globe string	1
B	Solar panel tube	1
C	Ground stake	1
D	1.2v AA 600mAh Ni-Mh battery (pre-assembled)	1

PREPARING FOR INSTALLATION

- Read all instructions before assembly and installation.
- Remove all the parts from the box. Inspect each part for defects that may have occurred during shipping.
- The OFF/ON switch is on the back of the solar panel (A). Switch ON to activate the batteries.




Installation

- Connect the solar panel (A) to the tube (B).
- Connect the tube (B) to the ground stake (C).
- Insert the ground stake (C) firmly into the ground at the installation location. If the ground is too hard, soak the ground with water to soften the ground or drive a metal rod or screwdriver into the ground to create a hole for the ground stake assembly.



NOTE: Do not use a hammer. If the ground is hard, use water to soften or a trowel to loosen the soil.



Maintenance

- Clean the solar panel with a damp towel to ensure optimum performance of the solar pathway light. Do not use any type of solvent for cleaning and be careful not to put too much pressure on the panel while cleaning.

Care and Cleaning

Winter tips

- Keep debris and snow off the solar panel to allow the battery to recharge. If the lights have been covered by snow for a long time, allow the battery to recharge in full, direct sunlight for 10-12 hours, so they can maintain maximum capacity.

Troubleshooting

Problem	Possible Cause	Solution
The solar light does not turn on at night or the amount of time that it operates during the night is shorter.	The battery is not fully charged.	Ensure the solar light is located in an area where it can receive the maximum amount of full, direct sunlight every day. If the solar light does not receive enough sunlight during a day (e.g. due to cloudy or overcast weather conditions), it will be recharged on the next sunny day and resume normal operation. Keeping the solar panel clean is equally important to ensure the maximum charging performance.
	The solar light is installed close to other light sources which are causing the photocell to turn the fixture off.	Relocate the fixture to a place with no other light sources, or remove the other light sources from the fixture location.
	The battery is reaching the end of its useful life.	Replace the rechargeable battery with a rechargeable battery that has a similar rating and type. Do not use a non-rechargeable battery.
	There is not enough direct sunlight.	Ensure the solar light is not installed in a shaded area, such as in the shadows or trees or a house.
	The switch is NOT on.	Verify that the switch is ON.

HAMPTON BAY.

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HOMEDPOT.CA

Retain this manual for future use.